

XM-320 Position Module



**User Guide
Firmware Revision 5**

1440-TPS02-01RB

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication SGI-1.1 available from your local Rockwell Automation sales office or online at <http://literature.rockwellautomation.com>) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.





In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.



Throughout this manual, when necessary, we use notes to make you aware of safety considerations.

WARNING 	Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.
IMPORTANT	Identifies information that is critical for successful application and understanding of the product.
ATTENTION 	Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence
SHOCK HAZARD 	Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.
BURN HAZARD 	Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.

Allen-Bradley, Rockwell Automation, and XM are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Safety Approvals

The following information applies when operating this equipment in hazardous locations.		Informations sur l'utilisation de cet équipement en environnements dangereux.	
<p>Products marked "CL I, DIV 2, GP A, B, C, D" are suitable for use in Class I Division 2 Groups A, B, C, D, Hazardous Locations and nonhazardous locations only. Each product is supplied with markings on the rating nameplate indicating the hazardous location temperature code. When combining products within a system, the most adverse temperature code (lowest "T" number) may be used to help determine the overall temperature code of the system. Combinations of equipment in your system are subject to investigation by the local Authority Having Jurisdiction at the time of installation.</p>		<p>Les produits marqués "CL I, DIV 2, GP A, B, C, D" ne conviennent qu'à une utilisation en environnements de Classe I Division 2 Groupes A, B, C, D dangereux et non dangereux. Chaque produit est livré avec des marquages sur sa plaque d'identification qui indiquent le code de température pour les environnements dangereux. Lorsque plusieurs produits sont combinés dans un système, le code de température le plus défavorable (code de température le plus faible) peut être utilisé pour déterminer le code de température global du système. Les combinaisons d'équipements dans le système sont sujettes à inspection par les autorités locales qualifiées au moment de l'installation.</p>	
<div style="background-color: black; color: white; padding: 2px; font-weight: bold; margin-bottom: 5px;">WARNING</div> 	<p>EXPLOSION HAZARD -</p> <ul style="list-style-type: none"> Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous. Do not disconnect connections to this equipment unless power has been removed or the area is known to be nonhazardous. Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product. Substitution of components may impair suitability for Class I, Division 2. If this product contains batteries, they must only be changed in an area known to be nonhazardous. 	<div style="background-color: black; color: white; padding: 2px; font-weight: bold; margin-bottom: 5px;">AVERTISSEMENT</div> 	<p>RISQUE D'EXPLOSION –</p> <ul style="list-style-type: none"> Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher l'équipement. Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher les connecteurs. Fixer tous les connecteurs externes reliés à cet équipement à l'aide de vis, loquets coulissants, connecteurs filetés ou autres moyens fournis avec ce produit. La substitution de composants peut rendre cet équipement inadapté à une utilisation en environnement de Classe I, Division 2. S'assurer que l'environnement est classé non dangereux avant de changer les piles.

IMPORTANT

Wiring to or from this device, which enters or leaves the system enclosure, must utilize wiring methods suitable for Class I, Division 2 Hazardous Locations, as appropriate for the installation in accordance with the product drawings as indicated in the following table.

Model	Catalog Number	Haz Location Drawings*		Model	Catalog Number	Haz Location Drawings*	
		w/o Barriers	w/ Barriers			w/o Barriers	w/ Barriers
XM-120	1440-VST0201RA	48178-HAZ	48179-HAZ	XM-320	1440-TPS0201RB	48238-HAZ	48239-HAZ
XM-121	1440-VLF0201RA			XM-360	1440-TPR0600RE	48295-HAZ	48299-HAZ
XM-122	1440-VSE0201RA			XM-361	1440-TUN0600RE		
XM-123	1440-VAD0201RA			XM-361	1440-TTC0600RE		
XM-160	1440-VDRS0600RH	51263-HAZ	51264-HAZ	XM-440	1440-RMA0004RC	48240-HAZ	N/A
XM-161	1440-VDRS0606RH			XM-441	1440-REX0004RD	48241-HAZ	N/A
XM-162	1440-VDRP0600RH			XM-442	1440-REX0304RG	48642-HAZ	N/A
XM-220	1440-SPD0201RB			48640-HAZ	48641-HAZ		

* Drawings are available on the included CD

Introduction	Chapter 1	
	Introducing the XM-320 Position Module	1
	XM-320 Module Components.	3
	Using this Manual.	4
	Organization.	4
	Document Conventions	5
Installing the XM-320 Position Module	Chapter 2	
	XM Installation Requirements.	8
	Wiring Requirements.	8
	Power Requirements	8
	Grounding Requirements	10
	Mounting the Terminal Base Unit.	15
	DIN Rail Mounting	16
	Interconnecting Terminal Base Units	17
	Panel/Wall Mounting	18
	Connecting Wiring for Your Module	19
	Terminal Block Assignments.	20
	Connecting the Power Supply.	22
	Connecting the Relays	23
	Connecting the Short Circuit Protected Output	26
	Connecting the Remote Relay Reset Signal	27
	Connecting the Setpoint Multiplication Switch	29
	Connecting the 4-20mA Outputs	29
	Connecting the Transducer	30
	PC Serial Port Connection	36
	DeviceNet Connection	38
	Mounting the Module	39
	Module Indicators	41
	Basic Operations	43
	Powering Up the Module	43
	Manually Resetting Relays	43
Configuration Parameters	Chapter 3	
	Channel Parameters	46
	Measurement Mode Parameter	49
	Normal Mode.	49
	Head-To-Head Mode	51
	Radial Cancel Mode.	54
	Alarm Parameters.	55
	Relay Parameters	58
	4-20mA Output Parameters.	62
	Triggered Trend Parameters	63
	I/O Data Parameters	65

	Data Parameters	66
	Channel Data	66
	Alarm and Relay Status	67
	Device Mode Parameters	68
Specifications	Appendix A	69
	Appendix B	
DeviceNet Information	Electronic Data Sheets	73
	Changing Operation Modes	73
	Transition to Program Mode	74
	Transition to Run Mode	74
	XM Services	75
	Invalid Configuration Errors	76
	XM-320 I/O Message Formats	77
	Poll Message Format	77
	COS Message Format	78
	Bit-Strobe Message Format	79
	ADR for XM Modules	80
	Appendix C	
DeviceNet Objects	Identity Object (Class ID 01H)	84
	Class Attributes	84
	Instance Attributes	84
	Status	84
	Services	85
	DeviceNet Object (Class ID 03H)	85
	Class Attributes	86
	Instance Attributes	86
	Services	87
	Assembly Object (Class ID 04H)	87
	Class Attributes	87
	Instances	87
	Instance Attributes	88
	Assembly Instance Attribute Data Format	88
	Services	90
	Connection Object (Class ID 05H)	90
	Class Attributes	90
	Instances	91
	Instance Attributes	91
	Services	92

Discrete Input Point Object (Class ID 08H)	92
Class Attributes	92
Instance Attributes	93
Services	93
Analog Input Point Object (Class ID 0AH)	93
Class Attributes	93
Instances	94
Instance Attributes	94
Services	94
Parameter Object (Class ID 0FH)	95
Class Attributes	95
Instances	96
Instance Attributes	97
Services	98
Acknowledge Handler Object (Class ID 2BH)	98
Class Attributes	98
Instances	98
Instance Attributes	98
Services	99
Alarm Object (Class ID 31DH)	99
Class Attributes	99
Instances	99
Instance Attributes	99
Services	101
Device Mode Object (Class ID 320H)	101
Class Attributes	101
Instance Attributes	101
Services	102
Relay Object (Class ID 323H)	102
Class Attributes	103
Instances	103
Instance Attributes	103
Services	104
Transducer Object (Class ID 328H)	105
Class Attributes	105
Instances	105
Instance Attributes	105
Services	106
4-20mA Output Object (Class ID 32AH)	106
Class Attributes	106
Instances	107
Instance Attributes	107
Services	107
Glossary	109
Index	115

Introduction

This chapter provides an overview of the XM-320 Position module. It also discusses the components of the module.

For information about	See page
Introducing the XM-320 Position Module	1
XM-320 Module Components	3
Using this Manual	4

Introducing the XM-320 Position Module

The XM-320 Position module is a 2-channel general purpose monitor. It is a member of the Allen-Bradley™ XM® Series, a family of DIN rail mounted condition monitoring and protection modules that operate both in stand-alone applications or integrate with Programmable Logic Controllers (PLCs) and control system networks.

The XM-320 supports the following measurements:

- **Axial Position (Thrust)** - Axial position (thrust) is a measurement of the relative position of the thrust collar to the thrust bearing. It is a measurement that may be made in both the active and inactive thrust directions. The primary purpose of this measurement is to monitor thrust bearing wear and to insure against axial rubs. It is recommended that at least two separate transducers monitor axial position so that the redundancy will give added protection.

Most steam turbine rotors operate within the total clearance between thrust shoes (float). Normally this clearance is anywhere from 0.010 to 0.024 inches. The axial measurements are obtained by mounting a non-contact probe axially, looking at the thrust collar or shaft. The sensor provides a continuous measurement of the rotor position with respect to the thrust bearing. In most applications, the thrust detector is located in close proximity to the thrust bearing, normally located in the turbine front standard.

- **Cam (Valve) Position** - Valve position is a measurement of the main steam inlet valve stem position. The valve position measurement provides the operator with the current load on the machine.

The amount of the steam valve opening, speed, governor, and relay valve position indication assists the operator in controlling the unit during startup and emergencies. When used in conjunction with data from other related Turbine Supervisory Instrumentation (TSI) indicators, load, or steam flow related machinery conditions can be diagnosed.

- **Shell (Case) Expansion** - Shell (Case) expansion is a measurement of the thermal growth of the case from its fixed point outward. Steam temperature swings widely between startup, shutdown, and various operating conditions. The high pressure turbine end must move axially as expansion and contraction occurs. Continuous indication of shell thermal growth enables the operator to accelerate or change turbine load without excessive distortion of the machine shell.

- **Differential Expansion** - Differential expansion (DE) is a measurement of the differences between the thermal growth of the rotor compared to the case.

Differential expansion monitoring provides the machine operator with continuous indication of the critical clearances between the expanding rotor and blades with respect to the expanding shell or casing. Proper coordination of machine parameters enables safe machine acceleration and operation during load changes and emergencies. To prevent axial rubs it is important that the rotor and case grow at the same rate.

Differential expansion is most important during a turbine “cold” startup. The rotor is fixed axially by the thrust bearing. The thrust bearing moves as the case expands – thus the need to monitor the difference in thermal expansion. Ideally, differential expansion should indicate zero change in the gap relationship between the two surfaces. When the shell growth leads or lags the rotor growth, or conversely the rotor expansion leads or lags the shell growth, an expansion differential occurs.

The XM-320 accepts input from linear variable differential transformers (LVDT), non-contact eddy current probes, rotary cam (valve) potentiometers, or any voltage output position measurement device.


The XM-320 also includes a single on-board relay, expandable to five, two 4-20mA outputs, and a buffered output for each input. The module can collect trend data on event, and monitor up to two alarms making it a complete position monitoring system. The module can operate stand-alone, or it can be deployed on a standard or dedicated DeviceNet network where it can provide real-time data and status information to other XM modules, PLCs, DCS, and Condition Monitoring Systems.

The XM-320 module is configurable over a DeviceNet network or using a serial connection to a PC or laptop. Refer to Chapter 3 for a list of the XM-320 configuration parameters.


XM-320 Module Components

The XM-320 consists of a terminal base unit and an instrument module. The XM-320 Position Module and the XM-941 Position Terminal Base are shown below.

Figure 1.1 XM-320 Module Components



XM-941 Position Module Terminal Base Unit
Cat. No. 1440-TB-B



XM-320 Position Module
Cat. No. 1440-TPS02-01RB

- XM-941 Position Module Terminal Base Unit - A DIN rail mounted base unit that provides terminations for all field wiring required by XM Position modules, including the XM-320.

- XM-320 Position Module - Mounts on the XM-941 terminal base unit via a keyswitch and a 96-connector. The XM-320 contains the measurement electronics, processor, relay, and serial interface port for local configuration.

IMPORTANT

The XM-441 Expansion Relay module may be connected to the XM-320 module via the XM-941 terminal base unit.

When connected to the XM-320, the Expansion Relay module simply “expands” the capability of the XM-320 by adding four additional epoxy-sealed relays. The XM-320 controls the Expansion Relay module by extending to it the same logic and functional controls as the XM-320 module’s on-board relay.

Using this Manual

This manual introduces you to the XM-320 Position module. It is intended for anyone who installs, configures, or uses the XM-320 Position module.

Organization

To help you navigate through this manual, it is organized in chapters based on these tasks and topics.

Chapter 1 “Introduction” contains an overview of this manual and the XM-320 module.

Chapter 2 “Installing the XM-320 Position Module” describes how to install, wire, and use the XM-320 module.

Chapter 3 “Configuration Parameters” provides a complete listing and description of the XM-320 parameters. The parameters can be viewed and edited using the XM Serial Configuration Utility software and a personal computer.

Appendix A “Specifications” lists the technical specifications for the XM-320 module.

Appendix B “DeviceNet Information” provides information to help you configure the XM-320 over a DeviceNet network.

Appendix C “DeviceNet Objects” provides information on the DeviceNet objects supported by the XM-320 module.

For definitions of terms used in this Guide, see the Glossary at the end of the Guide.

Document Conventions

There are several document conventions used in this manual, including the following:

The XM-320 Position Module is referred to as XM-320, Position module, module, or device throughout this manual.

TIP

A tip indicates additional information which may be helpful.

EXAMPLE

This convention presents an example.

Installing the XM-320 Position Module

This chapter discusses how to install and wire the XM-320 Position Module. It also describes the module indicators and the basic operations of the module.

For information about	See page
XM Installation Requirements	8
Mounting the Terminal Base Unit	15
Connecting Wiring for Your Module	19
Mounting the Module	39
Module Indicators	41
Basic Operations	43

ATTENTION**Environment and Enclosure**

This equipment is intended for use in a Pollution Degree 2 Industrial environment, in overvoltage Category II applications (as defined in IED publication 60664–1), at altitudes up to 2000 meters without derating.

This equipment is supplied as “open type” equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present, and appropriately designed to prevent personal injury resulting from accessibility to live parts. The interior of the enclosure must be accessible only by the use of a tool. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

See NEMA Standards publication 250 and IEC publication 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosures.

XM Installation Requirements

This section describes wire, power and grounding requirements, and instructions for an XM system.

Wiring Requirements

Use solid or stranded wire. All wiring should meet the following specifications:

- 14 to 22 AWG copper conductors without pretreatment; 8 AWG required for grounding the DIN rail for electromagnetic interference (emi) purposes
- Recommended strip length 8 millimeters (0.31 inches)
- Minimum insulation rating of 300V
- Soldering the conductor is forbidden
- Wire ferrules can be used with stranded conductors; copper ferrules recommended

ATTENTION

See the XM Documentation and Configuration Utility CD for Hazardous Locations installation drawings. The XM Documentation and Configuration Utility CD is packaged with the XM modules.


Power Requirements

Before installing your module, calculate the power requirements of all modules interconnected via their side connectors. The total current draw through the side connector cannot exceed 3A. Refer to the specifications for the specific modules for power requirements.

ATTENTION

A separate power connection is necessary if the total current draw of the interconnecting modules is greater than 3A.

Figure 2.1 is an illustration of wiring modules using separate power connections.

Figure 2.1 XM Modules with Separate Power Connections**Power Supply Requirements****XM Power Supply Requirements**

Protection	Listed Class 2 rated supply, or Fused* ITE Listed SELV supply, or Fused* ITE Listed PELV supply
Output Voltage	24 Vdc \pm 10%
Output Power	100 Watts Maximum (~4A @ 24 Vdc)
Static Regulation	\pm 2%
Dynamic Regulation	\pm 3%
Ripple	< 100mVpp
Output Noise	Per EN50081-1
Overshoot	< 3% at turn-on, < 2% at turn-off
Hold-up Time	As required (typically 50mS at full rated load)

* When a fused supply is used the fuse must be a 5 amp, listed, fast acting fuse such as provided by Allen-Bradley part number 1440-5AFUSEKIT

IMPORTANT

See Application Technique "XM Power Supply Solutions", publication ICM-AP005A-EN-E, for guidance in architecting power supplies for XM systems.

Grounding Requirements


Use these grounding requirements to ensure safe electrical operating circumstances, and to help avoid potential emi and ground noise that can cause unfavorable operating conditions for your XM system.

DIN Rail Grounding

The XM modules make a chassis ground connection through the DIN rail. The DIN rail must be connected to a ground bus or grounding electrode conductor using 8 AWG or 1 inch copper braid. See Figure 2.2.

Use zinc-plated, yellow-chromated steel DIN rail (Allen-Bradley part no. 199-DR1 or 199-DR4) or equivalent to assure proper grounding. Using other DIN rail materials (e.g. aluminum, plastic, etc.), which can corrode, oxidize, or are poor conductors can result in improper or intermittent platform grounding.


Figure 2.2 XM System DIN Rail Grounding



1 Use 14 AWG wire.

The grounding wire can be connected to the DIN rail using a DIN Rail Grounding Block (Figure 2.3).

Figure 2.3 DIN Rail Grounding Block



Panel/Wall Mount Grounding

The XM modules can also be mounted to a conductive mounting plate that is grounded. See Figure 2.5. Use the grounding screw hole provided on the terminal base to connect the mounting plate the Chassis terminals.

Figure 2.4 Grounding Screw on XM Terminal Base





Figure 2.5 Panel/Wall Mount Grounding



1 Use 14 AWG wire.

24V Common Grounding

24V power to the XM modules must be grounded. When two or more power supplies power the XM system, ground the 24V Commons at a single point, such as the ground bus bar.

IMPORTANT

If it is not possible or practical to ground the -24Vdc supply, then it is possible for the system to be installed and operate ungrounded. However, if installed ungrounded then the system must not be connected to a ground through any other circuit unless that circuit is isolated externally. Connecting a floating system to a non-isolated ground could result in damage to the XM module(s) and/or any connected device. Also, operating the system without a ground may result in the system not performing to the published specifications regards measurement accuracy and communications speed, distance or reliability.

IMPORTANT


The 24V Common and Signal Common terminals are internally connected. They are isolated from the Chassis terminals unless they are connected to ground as described in this section. See Terminal Block Assignments on page 20 for more information.

Transducer Grounding

Make certain the transducers are electrically isolated from earth ground. Cable shields must be grounded at one end of the cable, and the other end left floating or not connected. It is recommended that where possible, the cable shield be grounded at the XM terminal base (Chassis terminal) and not at the transducer.

DeviceNet Grounding

The DeviceNet network is functionally isolated and must be referenced to earth ground at a single point. XM modules do not require an external DeviceNet power supply. Connect DeviceNet V- to earth ground at one of the XM modules, as shown in Figure 2.6.

Figure 2.6 Grounded DeviceNet V- at XM Module**ATTENTION**

Use of a separate DeviceNet power supply is not permitted. See Application Technique "XM Power Supply Solutions", publication ICM-AP005A-EN-E, for guidance in using XM with other DeviceNet products.

For more information on the DeviceNet installation, refer to the ODVA Planning and Installation Manual - DeviceNet Cable System, which is available on the ODVA web site (<http://www.odva.org>).

Switch Input Grounding

The Switch Input circuits are functionally isolated from other circuits. It is recommended that the Switch RTN signal be grounded at a single point. Connect the Switch RTN signal to the XM terminal base (Chassis terminal) or directly to the DIN rail, or ground the signal at the switch or other equipment that is wired to the switch.

Mounting the Terminal Base Unit

The XM family includes several different terminal base units to serve all of the measurement modules. The XM-941 terminal base, Cat. No. 1440-TB-B, is the only terminal base unit used with the XM-320.

The terminal base can be DIN rail or wall/panel mounted. Refer to the specific method of mounting below.

ATTENTION



The XM modules make a chassis ground connection through the DIN rail. Use zinc plated, yellow chromated steel DIN rail to assure proper grounding. Using other DIN rail materials (e.g. aluminum, plastic, etc.), which can corrode, oxidize or are poor conductors can result in improper or intermittent platform grounding.

You can also mount the terminal base to a grounded mounting plate. Refer to Panel/Wall Mount Grounding on page 12.

DIN Rail Mounting

Use the steps below to mount the XM-941 terminal base unit on a DIN rail (A-B pt no. 199-DR1 or 199-DR4).


1. Position the terminal base on the 35 x 7.5mm DIN rail (A).



Position terminal base at a slight angle and hook over the top of the DIN rail.

2. Slide the terminal base unit over leaving room for the side connector (B).

3. Rotate the terminal base onto the DIN rail with the top of the rail hooked under the lip on the rear of the terminal base.



4. Press down on the terminal base unit to lock the terminal base on the DIN rail. If the terminal base does not lock into place, use a screwdriver or similar device to open the locking tab, press down on the terminal base until flush with the DIN rail and release the locking tab to lock the base in place.

Interconnecting Terminal Base Units


Follow the steps below to install another terminal base unit on the DIN rail.

IMPORTANT

Make certain you install the terminal base units in order of left to right.

1. Position the terminal base on the 35 x 7.5mm DIN rail (A).
2. Make certain the side connector (B) is **fully retracted** into the base unit.
3. Slide the terminal base unit over tight against the neighboring terminal base. Make sure the hook on the terminal base slides under the edge of the terminal base unit.
4. Press down on the terminal base unit to lock the terminal base on the DIN rail. If the terminal base does not lock into place, use a screwdriver or similar device to open the locking tab, press down on the terminal base until flush with the DIN rail and release the locking tab to lock the base in place.

5. Gently push the side connector into the side of the neighboring terminal base unit to complete the backplane connection.




Panel/Wall Mounting

Installation on a wall or panel consists of:

- laying out the drilling points on the wall or panel
- drilling the pilot holes for the mounting screws
- installing the terminal base units and securing them to the wall or panel

Use the following steps to install the terminal base on a wall or panel.

1. Lay out the required points on the wall/panel as shown in the drilling dimension drawing below.




2. Drill the necessary holes for the #6 self-tapping mounting screws.
3. Secure the terminal base unit using two #6 self-tapping screws.
4. To install another terminal base unit, retract the side connector into the base unit. Make sure it is **fully retracted**.
5. Position the terminal base unit up tight against the neighboring terminal base. Make sure the hook on the terminal base slides under the edge of the terminal base unit.
6. Gently push the side connector into the side of the neighboring terminal base to complete the backplane connection.
7. Secure the terminal base to the wall with two #6 self-tapping screws.

Connecting Wiring for Your Module

Wiring to the module is made through the terminal base unit on which the module mounts. The XM-320 is compatible only with the XM-941 terminal base unit, Cat. No. 1440-TB-B.


Figure 2.7 XM-941 Terminal Base Unit




XM-941, Cat. No. 1440-TB-B

Terminal Block Assignments

The terminal block assignments and descriptions for the XM-320 module are shown below.

ATTENTION	The terminal block assignments are different for different XM modules. The following table applies only to the XM-320. Refer to the installation instructions for the specific XM module for its terminal assignments.
	

WARNING	EXPLOSION HAZARD
	Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous. Do not disconnect connections to this equipment unless power has been removed or the area is known to be nonhazardous. Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product.

Terminal Block Assignments

No.	Name	Description
0	Xducer 1 (+)	Transducer 1 connection
1	Xducer 2 (+)	Transducer 2 connection
2	Protected Output 1 (+)	Short Circuit Protected Output 1, positive side
3	Protected Output 2 (+)	Short Circuit Protected Output 2, positive side
4	No Connection	
5	No Connection	
6	Xducer V (+)	Transducer power supply output, positive side

Terminal Block Assignments

No.	Name	Description
7	TxD	PC serial port, transmit data
8	RxD	PC serial port, receive data
9	XRTN	Circuit return for TxD and RxD
10	Chassis	Connection to DIN rail ground spring or panel mounting hole
11	4-20mA 1 (+)	4-20mA output 600 ohm maximum load
12	4-20mA 1 (-)	
13	Chassis	Connection to DIN rail ground spring or panel mounting hole
14	Chassis	Connection to DIN rail ground spring or panel mounting hole
15	Chassis	Connection to DIN rail ground spring or panel mounting hole
16	Xducer 1 (-)	Transducer 1 connection
17	Xducer 2 (-)	Transducer 2 connection
18	Protected Output 1 (-)	Short Circuit Protected Output 1, negative side
19	Protected Output 2 (-)	Short Circuit Protected Output 2, negative side
20	No Connection	
21	No Connection	
22	Xducer V (-)	Transducer power supply output, negative side
23	CAN_High	DeviceNet bus connection, high differential (white wire)
24	CAN_Low	DeviceNet bus connection, low differential (blue wire)
25	+24V Out	Internally connected to 24V In (terminal 44) Used to daisy chain power if XM modules are not plugged into each other
26	DNet V (+)	DeviceNet bus power input, positive side (red wire)
27	DNet V (-)	DeviceNet bus power input, negative side (black wire)
28	24V Common	Internally connected to 24V Common (terminals 43 and 45) Used to daisy chain power if XM modules are not plugged into each other
29	4-20mA 2 (+)	4-20mA output 600 ohm maximum load
30	4-20mA 2 (-)	
31	Chassis	Connection to DIN rail ground spring or panel mounting hole
32	Chassis	Connection to DIN rail ground spring or panel mounting hole
33	Chassis	Connection to DIN rail ground spring or panel mounting hole
34	Chassis	Connection to DIN rail ground spring or panel mounting hole
35	Chassis	Connection to DIN rail ground spring or panel mounting hole
36	Chassis	Connection to DIN rail ground spring or panel mounting hole
37	Chassis	Connection to DIN rail ground spring or panel mounting hole
38	Chassis	Connection to DIN rail ground spring or panel mounting hole

Terminal Block Assignments


No.	Name	Description
39	SetPtMult	Switch input to activate Set Point Multiplication (active closed)
40	Switch RTN	Switch return, shared between SetPtMult and Reset Relay
41	Reset Relay	Switch input to reset internal relay (active closed)
42	Reserved	
43	24V Common	Internally DC-coupled to circuit ground
44	+24V In	Connection to primary external +24V power supply, positive side
45	24V Common	Connection to external +24V power supply, negative side (internally DC-coupled to circuit ground)
46	Relay N.C. 1	Relay Normally Closed contact 1
47	Relay Common 1	Relay Common contact 1
48	Relay N.O. 1	Relay Normally Open contact 1
49	Relay N.O. 2	Relay Normally Open contact 2
50	Relay Common 2	Relay Common contact 2
51	Relay N.C. 2	Relay Normally Closed contact 2

Connecting the Power Supply

Power supplied to the module must be nominally 24 Vdc ($\pm 10\%$) and must be a Class 2 rated circuit.

Wire the DC-input power supply to the terminal base unit as shown in Figure 2.8.

Figure 2.8 DC Input Power Supply Connections



IMPORTANT

A Class 2 circuit can be provided by use of an NEC Class 2 rated power supply, or by using a SELV or PELV rated power supply with a 5 Amp current limiting fuse installed before the XM module(s).

IMPORTANT

24Vdc needs to be wired to terminal 44 (+24 V In) to provide power to the device and other XM modules linked to the wired terminal base via the side connector.

ATTENTION

The power connections are different for different XM modules. Refer to the installation instructions for your specific XM module for complete wiring information.

Connecting the Relays

The XM-320 has both Normally Open (NO) and Normally Closed (NC) relay contacts. Normally Open relay contacts close when the control output is energized. Normally Closed relay contacts open when the control output is energized.

The alarms associated with the relay and whether the relay is normally de-energized (non-failsafe) or normally energized (failsafe) depends on the configuration of the module. Refer to Relay Parameters on page 58 for details.

Table 2.1 shows the on-board relay connections for the XM-320.

IMPORTANT

All XM relays are double pole. This means that each relay has two contacts in which each contact operates independently but identically. The following information and illustrations show wiring solutions for both contacts; although, in many applications it may be necessary to wire only one contact.

TIP

The Expansion Relay module may be connected to the XM-320 to provide additional relays. Refer to the XM-441 Expansion Relay Module User Guide for wiring details.

IMPORTANT The NC/NO terminal descriptions (page 22) correspond to a de-energized (unpowered) relay.

When the relay is configured for non-failsafe operation, the relay is normally de-energized.

When the relay is configured for failsafe operation, the relay is normally energized, and the behavior of the NC and NO terminals is inverted.


Table 2.1 Relay Connections for XM-320

Configured for Failsafe Operation		Wire Contacts	Relay 1 Terminals	
Nonalarm	Alarm		Contact 1	Contact 2
Closed	Opened	COM	47	50
		NO	48	49
Opened	Closed	COM	47	50
		NC	46	51


Configured for Non-failsafe Operation		Wire Contacts	Relay 1 Terminals	
Nonalarm	Alarm		Contact 1	Contact 2
Closed	Opened	COM	47	50
		NC	46	51
Opened	Closed	COM	47	50
		NO	48	49

Figures 2.9 and 2.10 illustrate the behavior of the NC and NO terminals when the relay is wired for failsafe, alarm or nonalarm condition or non-failsafe, alarm or nonalarm condition.

**Figure 2.9 Relay Connection - Failsafe, Nonalarm Condition
Non-failsafe, Alarm Condition**




**Figure 2.10 Relay Connection - Failsafe, Alarm Condition
Non-failsafe, Nonalarm Condition**




Alternate Relay Wiring

Figures 2.11 and 2.12 show how to wire both ends of a single external indicator to the XM terminal base for failsafe, nonalarm or alarm condition, or non-failsafe, nonalarm or alarm condition.

**Figure 2.11 Relay Connection - Failsafe, Nonalarm Condition
Non-failsafe, Alarm Condition**



**Figure 2.12 Relay Connection - Failsafe, Alarm Condition
Non-failsafe, Nonalarm Condition**




Connecting the Short Circuit Protected Output

The XM-320 provides short circuit protected outputs of all transducer input signals. The protected output connections may be used to connect the module to portable data collectors or other online systems.

Figure 2.13 shows the short circuit protected output connections for the XM-320.

Figure 2.13 Short Circuit Protected Output Connections



Connecting the Remote Relay Reset Signal

If you set the module relay to latching and the relay activates, the relay stays activated even when the condition that caused the alarm has ended. The remote relay reset signal enables you to reset your module relay remotely after you have corrected the alarm condition. This includes latched relays in the Expansion Relay module when it is attached to the XM-320.

TIP


You can discretely reset a relay using the serial or remote configuration tool.

TIP

If you set a module relay to latching, make sure that any linked relays, such as relays in an XM-440 Master Relay Module, are **not** configured as latching. When both relays are set to latching, the relay in each module will have to be independently reset when necessary.

Wire the Remote Relay Reset Signal to the terminal base unit as shown in Figure 2.14.

Figure 2.14 Remote Relay Reset Signal Connection



ATTENTION



The Switch Input circuits are functionally isolated from other circuits. It is recommended that the Switch RTN signal be grounded at a signal point. Connect the Switch RTN signal to the XM terminal base (Chassis terminal) or directly to the DIN rail, or ground the signal at the switch or other equipment that is wired to the switch.


A single switch contact can also be shared by multiple XM modules wired in parallel as shown in Figure 2.15.

ATTENTION



The relay reset connections may be different for different XM modules. Figure 2.15 applies only to the XM-320 module. Refer to the installation instructions for the module for its terminal assignments.

Figure 2.15 Typical Multiple XM Modules Remote Relay Reset Signal Connection




Connecting the Setpoint Multiplication Switch


You can configure the module to multiply the alarm setpoints, or inhibit the alarms during the start-up period. This can be used to avoid alarm conditions that may occur during startup, for example, when the monitored machine passes through a critical speed.

Wire the Setpoint Multiplication switch to the terminal base unit as shown in Figure 2.16.

Figure 2.16 Setpoint Multiplication Connection



ATTENTION




The Switch Input circuits are functionally isolated from other circuits. It is recommended that the Switch RTN signal be grounded at a signal point. Connect the Switch RTN signal to the XM terminal base (Chassis terminal) or directly to the DIN rail, or ground the signal at the switch or other equipment that is wired to the switch.

Connecting the 4-20mA Outputs

The module includes an isolated 4-20mA per channel output into a maximum load of 600 ohms. The measurements that the 4-20mA output tracks and the signal levels that correspond to the 4mA and 20mA are configurable. Refer to 4-20mA Output Parameters on page 62 for a description of the 4-20mA parameters.

Wire the 4-20mA outputs to the terminal base unit as shown in Figure 2.17.

Figure 2.17 4-20mA Output Connections**ATTENTION**

The 4-20mA outputs are functionally isolated from other circuits. It is recommended that the outputs be grounded at a single point. Connect the 4-20mA (-) to the XM terminal base (Chassis terminal) or directly to the DIN rail, or ground the signal at the other equipment in the 4-20mA loop.

Connecting the Transducer

The XM-320 will accept signals from a linear variable differential transformer (LVDT), non-contact eddy current probe, or a rotary cam (valve) potentiometer.

Connecting a Non-contact Sensor

The following figures show the wiring from a non-contact sensor to the terminal base unit of the XM-320 module.

ATTENTION

You may ground the cable shield at either end of the cable. Do not ground the shield at both ends. Recommended practice is to ground the cable shield at the XM-320 terminal base and not at the transducer. Any convenient Chassis terminal may be used (see Terminal Block Assignments on page 20).

Figure 2.18 Non-contact sensor to channel 1 wiring





Figure 2.19 Non-contact sensor to channel 2 wiring



Connecting an LVDT

The following figures show the wiring from a linear variable differential transformer (LVDT) to the terminal base unit of the XM-320.

ATTENTION

You may ground the cable shield at either end of the cable. Do not ground the shield at both ends. Recommended practice is to ground the cable shield at the XM-320 terminal base and not at the transducer. Any convenient Chassis terminal may be used (see Terminal Block Assignments on page 20).




Figure 2.20 LVDT to channel 1 wiring





Figure 2.21 LVDT to channel 2 wiring



Connecting a Cam Potentiometer

The following figures show the wiring from a cam potentiometer to the terminal base unit of the XM-320.

ATTENTION You may ground the cable shield at either end of the cable. Do not ground the shield at both ends. Recommended practice is to ground the cable shield at the XM-320 terminal base and not at the transducer. Any convenient Chassis terminal may be used (see Terminal Block Assignments on page 20).




Figure 2.22 Cam potentiometer to channel 1 wiring





Figure 2.23 Cam potentiometer to channel 2 wiring



Connecting a Non-contact Sensor and an LVDT

The figure below shows the wiring of a non-contact sensor to channel 1 and an LVDT to channel 2 of the XM-320.

ATTENTION


You may ground the cable shield at either end of the cable. Do not ground the shield at both ends. Recommended practice is to ground the cable shield at the XM-320 terminal base and not at the transducer. Any convenient Chassis terminal may be used (see Terminal Block Assignments on page 20).

IMPORTANT

The +24V LVDT powered from pin 25 **does not** utilize the redundant power connection to the XM-320. So if primary 24V power is lost, the +24V sensor will lose power regardless of whether the XM-320 remains powered through the redundant power terminals.

If redundant power is required then use a redundant power supply (Allen-Bradley 1606-series is recommended).

Figure 2.24 Non-contact sensor and LVDT wiring



PC Serial Port Connection

The XM-320 includes a serial port connection that allows you to connect a PC to it and configure the module's parameters. There are two methods of connecting an external device to the module's serial port.


- Terminal Base Unit** - There are three terminals on the terminal base unit you can use for the serial port connection. They are TxD, RxD, and RTN (terminals 7, 8, and 9, respectively). If these three terminals are wired to a DB-9 female connector, then a standard RS-232 serial cable with 9-pin (DB-9) connectors can be used to connect the module to a PC (no null modem is required).

The DB-9 connector should be wired to the terminal base unit as follows.

<u>XM-320 Terminal Base Unit</u> <u>(Cat. No. 1440-TB-B)</u>	<u>DB-9 Female Connector</u>
TX Terminal (terminal 7) -----	Pin 2 (RD - receive data)
RX Terminal (terminal 8) -----	Pin 3 (TD - transmit data)
RTN Terminal (terminal 9) -----	Pin 5 (SG - signal ground)

- **Mini-Connector** - The mini-connector is located on the top of the XM-320, as shown below.

Figure 2.25 Mini Connector



A special cable (Cat. No. 1440-SCDB9FXM2) is required for this connection. The connector that inserts into the PC is a DB-9 female connector, and the connector that inserts into the module is a USB Mini-B male connector.

WARNING



If you connect or disconnect the serial cable with power applied to the module or the serial device on the other end of the cable, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

IMPORTANT

If 24V Common is not referenced to earth ground, we recommend you use an RS-232 isolator, such as Phoenix PSM-ME-RS232/RS232-P (Cat. No. 1440-ISO-232-24), to protect both the XM module and the computer.

DeviceNet Connection

The XM-320 includes a DeviceNet™ connection that allows the module to communicate directly with a programmable controller, distributed control system (DCS), or another XM module.

DeviceNet is an open, global, industry-standard communications network designed to provide an interface through a single cable from a programmable controller to a smart device such as the XM-320 module. As multiple XM modules are interconnected, DeviceNet also serves as the communication bus and protocol that efficiently transfers data between the XM modules.

Connect the DeviceNet cable to the terminal base unit as shown.

Connect	To	Terminal Base Unit
Red Wire	DNet V+	26 (optional—see note)
White Wire	CAN High	23
Bare Wire	Shield (Chassis)	10
Blue Wire	CAN Low	24
Black Wire	DNet V-	27

IMPORTANT

The DeviceNet power circuit through the XM module interconnect, which is rated at only 300 mA, is not intended or designed to power DeviceNet loads. Doing so could damage the module or terminal base.

To preclude this possibility, even unintentionally, it is recommended that DeviceNet V+ be left unconnected.

ATTENTION



You must ground the DeviceNet shield at only one location. Connecting the DeviceNet shield to terminal 10 will ground the DeviceNet shield at the XM-320 module. If you intend to terminate the shield elsewhere, do not connect the shield to terminal 10.

ATTENTION



The DeviceNet network must also be referenced to earth at only one location. Connect DNet V- to earth or chassis at one of the XM modules.

ATTENTION

The DNet V+ and DNet V- terminals are inputs to the XM module. Do not attempt to pass DeviceNet power through the XM terminal base to other non-XM equipment by connecting to these terminals. Failure to comply may result in damage to the XM terminal base and/or other equipment.

IMPORTANT

Terminate the DeviceNet network and adhere to the requirements and instructions in the ODVA Planning and Installation Manual - DeviceNet Cable System, which is available on the ODVA web site (<http://www.odva.org>).

The device is shipped from the factory with the network node address (MAC ID) set to 63. The network node address is software settable. You can use the XM Serial Configuration Utility or RSNetWorx for DeviceNet (Version 3.0 or later) to set the network node address. Refer to the appropriate documentation for details.

IMPORTANT

The baud rate for the XM-320 is set by way of “baud detection” (Autobaud) at power-up.

Mounting the Module

The XM-320 mounts on the XM-941 terminal base unit, Cat. No. 1440-TB-B. You should mount the module after you have connected the wiring on the terminal base unit.

ATTENTION

The XM-320 is compatible only with the XM-941 terminal base unit. The keyswitch on the terminal base unit should be at position 4 for the XM-320.

Do not attempt to install XM-320 modules on other terminal base units.

Do not change the position of the keyswitch after wiring the terminal base.

ATTENTION

This module is designed so you can **remove and insert it under power**. However, when you remove or insert the module with power applied, I/O attached to the module can change states due to its input/output signal changing conditions. Take special care when using this feature.


WARNING

When you insert or remove the module while power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

IMPORTANT

Install the overlay slide label to protect serial connector and electronics when the serial port is not in use.

1. Make certain the keyswitch (A) on the terminal base unit (C) is at position 4 as required for the XM-320.




2. Make certain the side connector (B) is pushed all the way to the left. **You cannot install the module unless the connector is fully extended.**
3. Make sure that the pins on the bottom of the module are straight so they will align properly with the connector in the terminal base unit.
4. Position the module (D) with its alignment bar (E) aligned with the groove (F) on the terminal base.
5. Press firmly and evenly to seat the module in the terminal base unit. The module is seated when the latching mechanism (G) is locked into the module.
6. Repeat the above steps to install the next module in its terminal base.

Module Indicators

The XM-320 has six LED indicators, which include a module status (MS) indicator, a network status (NS) indicator, a status indicator for each channel (CH1 and CH2), an activation indicator for the Setpoint Multiplier, and a status indicator for the Relay. The LED indicators are located on top of the module.

Figure 2.26 LED Indicators



The following tables describe the states of the LED status indicators.

Module Status (MS) Indicator

Color	State	Description
No color	Off	No power applied to the module.
Green	Flashing Red	Module performing power-up self test.
	Flashing	Module operating in Program Mode ¹ .
	Solid	Module operating in Run Mode ² .
Red	Flashing	<ul style="list-style-type: none"> Application firmware is invalid or not loaded. Download firmware to the module. Firmware download is currently in progress. The module power voltage is incorrect.
	Solid	An unrecoverable fault has occurred. The module may need to be repaired or replaced.

1 Program Mode - Typically this occurs when the module configuration settings are being updated with the XM Serial Configuration Utility. In Program Mode, the module does not perform its usual functions. The signal processing/measurement process is stopped, and the status of the alarms is set to the disarm state to prevent a false alert or danger status.

2 Run Mode - In Run Mode, the module collects measurement data and monitors each measurement device.

Network Status (NS) Indicator

Color	State	Description
No color	Off	Module is not online. <ul style="list-style-type: none"> • Module is autobauding. • No power is applied to the module, look at Module Status LED.
Green	Flashing	Module is online (DeviceNet) but no connections are currently established. ¹
	Solid	Module is online with connections currently established.
Red	Flashing	One or more I/O connections are in the timed-out state.
	Solid	Failed communications (duplicate MAC ID or Bus-off).

¹ Normal condition when the module is not a slave to an XM-440, PLC, or other master device.

Channel 1 and Channel 2 Status Indicators

Color	State	Description
No Color	Off	<ul style="list-style-type: none"> • Normal operation within alarm limits on the channel. • No power applied to the module, look at Module Status LED.
Yellow	Solid	An alert level alarm condition exists on the channel (and no transducer fault or danger level alarm condition exists).
Red	Solid	A danger level alarm condition exists on the channel (and no transducer fault condition exists).
	Flashing	A transducer fault condition exists on the channel.

Setpoint Multiplier Indicator

Color	State	Description
Yellow	Off	Setpoint multiplier is not in effect.
	Solid	Setpoint multiplier is in effect.

Relay Indicator

Color	State	Description
Red	Off	On-board relay is not activated.
	Solid	On-board relay is activated.

Basic Operations

Powering Up the Module

The XM-320 performs a self-test at power-up. The self-test includes an LED test and a device test. During the LED test, the indicators will be turned on independently and in sequence for approximately 0.25 seconds.

The device test occurs after the LED test. The Module Status (MS) indicator is used to indicate the status of the device self-test.


MS Indicator State	Description
Flashing Red and Green	Device self test is in progress.
Solid Green or Flashing Green	Device self test completed successfully, and the firmware is valid and running.
Flashing Red	Device self test completed, the hardware is OK, but the firmware is invalid. Or, the firmware download is in progress.
Solid Red	Unrecoverable fault, hardware failure, or Boot Loader program may be corrupted.

Refer to Module Indicators on page 41 for more information about the LED indicators.

Manually Resetting Relays

The XM-320 has an external reset switch located on top of the module, as shown in Figure 2.27.

Figure 2.27 Reset Switch



The switch can be used to reset all latched relays in the module. This includes the relays in the Expansion Relay Module when it is connected to the XM-320.

IMPORTANT

The Reset switch resets the relays only if the input is no longer in alarm or the condition that caused the alarm is no longer present.

Configuration Parameters

This chapter provides a complete listing and description of the XM-320 parameters. The parameters can be viewed and edited using the XM Serial Configuration Utility software and a personal computer. If the module is installed on a DeviceNet network, configuring can also be performed using a network configuration tool such as RSNetWorx (Version 3.0 or later). Refer to your configuration tool documentation for instructions on configuring a device.

For information about	See page
Channel Parameters	46
Measurement Mode Parameter	49
Alarm Parameters	55
Relay Parameters	58
4-20mA Output Parameters	62
Triggered Trend Parameters	63
I/O Data Parameters	65
Data Parameters	66
Device Mode Parameters	68

IMPORTANT

The appearance and procedure to configure the parameters may differ in different software.

Channel Parameters

The Channel parameters define the characteristics of the transducers you will be using with the XM-320. Use the parameters to configure the transducer sensitivity, operating range, power requirements, measurement mode, and calibration offset. There are two instances of the parameters, one for each channel.

TIP

The Channel LED will flash red when a transducer fault condition exists on a channel even if you are not using the channel. You can keep the Channel LED from flashing red on unused channels by setting the channel's **Fault High** and **Fault Low** to greater than zero and less than zero, respectively. For example, set **Fault High** to +18 volts and set **Fault Low** to -18 volts.

Channel Parameters

Parameter Name	Description	Values/Comments										
Channel Name (XM Serial Configuration Utility only)	A descriptive name to help identify the channel in the XM Serial Configuration Utility.	Maximum 18 characters										
Sensitivity	The sensitivity of the transducer in millivolts per Eng. Units .	This value can be found on the transducer's data sheet.										
Eng. Units	Defines the native units of the transducer. Your choice controls the list of possible selections available in the Output Data Units parameter. It also affects other module parameters, for example the Alert and Danger Threshold, Measurement Value, 4–20 mA Output .	Options: mils (1/1000 inch) mm (millimeter) degrees %										
Output Data Unit	The data units of the measured values.	The available options depend on the Eng. Units selection. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Eng. Units</th> <th>Output Data Unit Options</th> </tr> </thead> <tbody> <tr> <td rowspan="2">mils</td> <td>mils</td> </tr> <tr> <td>mm</td> </tr> <tr> <td rowspan="2">mm</td> <td>mm</td> </tr> <tr> <td>mils</td> </tr> <tr> <td>deg</td> <td>deg</td> </tr> </tbody> </table>	Eng. Units	Output Data Unit Options	mils	mils	mm	mm	mm	mils	deg	deg
Eng. Units	Output Data Unit Options											
mils	mils											
	mm											
mm	mm											
	mils											
deg	deg											
Fault High	The maximum expected DC bias voltage from the transducer.	Volts										
Fault Low	The minimum, or most negative, expected DC bias voltage from the transducer.	Note: A voltage reading outside this range constitutes a transducer fault.										

Channel Parameters

Parameter Name	Description	Values/Comments	
DC Bias Time Constant	The time constant used for exponential averaging (low pass filtering) of the transducer DC bias measurement. The corner frequency for the low pass filter is $1 / (2\pi \times \text{DC Bias Time Constant})$. The greater the value entered, the longer the settling time of the measured value to a change in the input signal. See example table below.	Seconds	
	Time Constant (seconds)	-3dB Frequency (Hz)	Settling (seconds)
	1	0.159	2.2
	2	0.080	4.4
	3	0.053	6.6
	4	0.040	8.8
	5	0.032	11
	6	0.027	13.2
	7	0.023	15.4
	8	0.020	17.6
	9	0.018	19.8
10	0.016	22	
Target Angle	Sets the angle between the shaft and the target surface. The target surface moves with the shaft. The transducer is mounted perpendicular to the target surface.	degrees	
Upscale	Sets the movement of the target relative to the transducer that is considered positive displacement.	Options: Away Towards	
Calibration Offset (XM Serial Configuration Utility only)	Enter the position of the current Transducer DC Bias reading.	mils	

Channel Parameters

Parameter Name	Description	Values/Comments
Calibration Bias	<p>Sets the zero or green position. The zero position is the normal operating position. Setting the zero position compensates for the static gap. This allows the module to display only the displacement around the zero position.</p> <p>Use one of the formulas below to calculate the Calibration Bias. The formula that you use depends on the Upscale setting and whether Fault High and Fault Low are both less than or equal to zero (0).</p> <p>Upscale set to "Towards" Formula Calibration bias = Transducer DC Bias + (Sensitivity x Calibration Offset) x sin (Target Angle)</p> <p>Upscale set to "Away" Formula Calibration Bias = Transducer DC Bias - (Sensitivity x Calibration Offset) x sin (Target Angle)</p> <p>If Fault High and Fault Low are both less than or equal to 0, use one of these formulas:</p> <p>Upscale set to "Towards" Formula Calibration bias = Transducer DC Bias - (Sensitivity x Calibration Offset) x sin (Target Angle)</p> <p>Upscale set to "Away" Formula Calibration Bias = Transducer DC Bias + (Sensitivity x Calibration Offset) x sin (Target Angle)</p>	<p>Volts</p> <p>Note: Check with the manufacturer about operating thrust position and acceptable tolerances before making any adjustments.</p>
Calculate Bias (XM Serial Configuration Utility only)	Automatically calculates the Calibration Bias value.	

Measurement Mode Parameter

The Measurement Mode parameter controls how the two axial sensors are used to calculate the position measurement. Use this parameter to configure the mode of operation.


Measurement Mode

Parameter Name		Description	Values/Comments
XM Configuration Utility	EDS File	Select the mode of the two axial sensors. <ul style="list-style-type: none"> • Normal - The two sensors are used independently to perform two separate position measurements. See page 49 for more information about this mode. • Head-to-Head - The two sensors are used together, facing each other on either side of the target, to perform a single position measurement. This mode can be used to extend the measurable range beyond that of a single sensor. See page 51 for more information about this mode. • Radial Cancel - The two sensors are used together to perform a single position measurement. The second sensor is set up to measure the radial movement of the target. The radial movement is then subtracted from the position measurement performed by the first sensor. See page 54 for more information about this mode. 	Options: Normal Head-to-Head Radial Cancel
Mode	Measurement Mode		

Normal Mode

In normal mode the module behaves as a two channel differential unit with the probes mounted on the casing and measuring the shaft position relative to the casing. Positioning of probes is critical to ensure that valid shaft movement cannot at any time damage the probes. Selection of probe type and range is obviously important. The static gaps of the probes are automatically subtracted from the measurement in order that the system can measure small movements relative to the total gaps.

When using this mode, the module uses straight targets, angled targets, or mixed target types, as shown in Figure 3.1.

Figure 3.1 Normal Mode

The XM-320 provides monitoring facilities for the following machine measurements when in normal mode.

- Axial (thrust) Position
- Differential Expansion
- Case Expansion
- Valve Position


IMPORTANT

For the valve position measurement, **Sensitivity** must be set to "deg."

Head-To-Head Mode

The head-to-head mode allows extended range operation by using two probes in a “back to back” arrangement shown in the illustration in Figure 3.2. This mode can be used when the machine does not have enough space for larger diameter probes. It is not necessary for the scales to be symmetrical in this mode, and probes of different voltage sensitivities can be used within the one module.

Figure 3.2 Head-to-Head Mode



In head-to-head mode, the XM-320 provides monitoring facilities for complementary differential expansion measurements.


TIP

In head-to-head mode, all position measurements are stored in channel 1.

Head-to-Head Example

This head-to-head application measures a total displacement of 1000 mils on a shaft collar using two 500 mil probes with a standard sensitivity of 30mV/mil (or 0.030V/mil). See Figure 3.3.

Figure 3.3 Head-to-Head Mode



Note: The direction of differential growth for an upscale reading is away from Probe A and towards Probe B.

The chart below shows gap-to-instrument reading-to-voltage outputs for typical 500 mil transducers with an offset of 150 mils. Note that the offset gap of a transducer is the gap closest to the transducer where the transducer’s response to gap change becomes non-linear and not useful for measurement.

Probe A			Probe B		
Gap	Reading	Voltage	Gap	Reading	Voltage
150	0	-2.8	150	0	-3
250	100	-5.8	250	100	-6
400	250	-10.3	400	250	-10.5
550	400	-14.8	550	400	-15
650	500	-17.8	650	500	-18

IMPORTANT Make certain the shaft is in its correct cold position or compensate for the actual shaft axial position if it is known. You can put the shaft into position by mechanically moving it up against the active thrust shoe, or use the actual thrust position to offset the transducer gap settings so that they will be correct when the rotor is in the cold position.

Install and gap the probes for their cold gap settings using the information provided from previous installations or data provided in the Turbine manual. This example assumes that the correct cold set point (Green line) is 250 mils, the rotor is placed against the active thrust shoes, and the measurement range is 0 to 1000 mils.

Calculate and set the transducers as follows:

1. To determine the placement of Probe A, add the Cold Set Point to the Transducer Offset, then add the Axial Position from the Active Face.

$$\text{Probe A Gap} = 250 + 150 + 0 = 400 \text{ mils}$$

2. To determine the placement of Probe B, subtract the Cold Set Point from the Full Scale Reading, then add the Transducer Offset and the Axial Position from the Active Face.

$$\text{Probe B Gap} = 1000 - 250 + 150 + 0 = 900$$

3. Enter the following data on the Channels property page in the XM-320 Position Module Configuration Tool.

Channel 1 (Probe A)		Channel 2 (Probe B)	
Sensitivity	30	Sensitivity	30
Eng. Units	mils	Eng. Units	mils
Output Data Unit	mils	Output Data Unit	mils
Fault Low	-18 ¹	Fault Low	-18.2 ¹
Fault High	-2.6 ²	Fault High	-2.8 ²
DC Bias Time Constant	1	DC Bias Time Constant	1
Target Angle	90	Target Angle	90
Upscale	Away	Upscale	Towards
Calibration Offset	250	Calibration Offset	1000
Calibration Bias	Press Calculate Bias	Calibration Bias	-33 (You must enter value using formula below)
Mode	Head-to-Head		

- 1 This value is .2 volts below the lowest voltage the transducer will output for this measurement taken from the calibration chart.
- 2 This value is .2 volts above the highest voltage the transducer will output for this measurement taken from the calibration chart.

Calibration Bias Calculation

Since Probe B is gapped beyond the operating range, you must manually calculate the calibration bias as well as the transducer DC bias.

1. To determine the Transducer DC Bias, subtract Position B Gap from Transducer Offset, multiply by the Sensitivity and then add the Transducer Offset voltage.

$$\text{Transducer DC Bias} = 0.03 \times (150 - 900) - 3 = -25.5$$

2. Use the following formula to calculate the Calibration Bias:

$$\text{Calibration Bias} = \text{Transducer DC Bias} - (\text{Sensitivity} \times \text{Calibration Offset}) \times \sin(\text{Target Angle})$$

$$\text{Calibration Bias} = -25.5 - (0.03 \times 250) \times \sin(90) = -33$$

IMPORTANT


The formula used to calculate the Calibration Bias depends on the **Upscale** setting and whether **Fault High** and **Fault Low** are less than or equal to zero (0). Press F1 on the Channels property page for a description of the formulas.

Radial Cancel Mode

In radial cancel mode, the movement of the shaft is detected by measuring the gap between the probe tip and a ramp of known and consistent angle to the center line of the shaft. If two ramps are present they should be measured as shown below. The potential "lift" error of shaft position caused by jacking oil pressure is eliminated in the module calculations.

Where only one ramp is available, the "lift" error must be taken into account, and this is achieved by using a second probe operating on a portion of the shaft which is parallel to the center line.

Figure 3.4 Radial Cancel Mode



The XM-320 provides monitoring facilities for the following machine measurements when in radial cancel mode.

- Standard Single Ramp Differential Expansion
- Non-standard Single Ramp Differential Expansion
- Dual Ramp Differential Expansion

TIP In radial cancel mode, all position measurements are stored in channel 1.

Alarm Parameters

The Alarm parameters control the operation of the alarms (alert and danger level) and provide alarm status. The XM-320 provides two alarms, one per channel. Use these parameters to configure the alarms.

Alarm Parameters

Parameter Name	Description	Values/Comments						
Number (1-2) (XM Serial Configuration Utility only)	Sets the alarm to be configured in the XM Serial Configuration Utility. There are two alarms in the XM-320, one for each channel.	Options: 1 (Channel 1 alarm) 2 (Channel 2 alarm)						
Name (XM Serial Configuration Utility only)	A descriptive name to identify the alarm in the XM Serial Configuration Utility.	Maximum 18 characters						
Enable	Enable/disable the selected alarm. Note: The Alarm Status is set to Disarm when the alarm is disabled.	<table border="1"> <thead> <tr> <th>XM Configuration Utility</th> <th>EDS Filet</th> </tr> </thead> <tbody> <tr> <td>Check to Enable</td> <td>Enabled</td> </tr> <tr> <td>Clear to Disable</td> <td>Disabled</td> </tr> </tbody> </table>	XM Configuration Utility	EDS Filet	Check to Enable	Enabled	Clear to Disable	Disabled
XM Configuration Utility	EDS Filet							
Check to Enable	Enabled							
Clear to Disable	Disabled							

Alarm Parameters

Parameter Name	Description	Values/Comments
Condition	<p>Controls when the alarm should trigger.</p> <ul style="list-style-type: none"> • Greater than - Triggers the alarm when the measurement value is greater than or equal to the Alert and Danger Threshold values. The Danger Threshold value must be greater than or equal to the Alert Threshold value for the trigger to occur. • Less than - Triggers the alarm when the measurement value is less than or equal to the Alert and Danger Threshold values. The Danger Threshold value must be less than or equal to the Alert Threshold value for the trigger to occur. • Inside range - Triggers the alarm when the measurement value is equal to or inside the range of the Alert and Danger Threshold values. The Danger Threshold (High) value must be less than or equal to the Alert Threshold (High) value AND the Danger Threshold (Low) value must be greater than or equal to the Alert Threshold (Low) value for the trigger to occur. • Outside range - Triggers the alarm when the measurement value is equal to or outside the range of the Alert and Danger Threshold values. The Danger Threshold (High) value must be greater than or equal to the Alert Threshold (High) value, AND the Danger Threshold (Low) value must be less than or equal to the Alert Threshold (Low) value for the trigger to occur. 	Options: Greater Than Less Than Inside Range Outside Range
Alert Threshold (High)	<p>The threshold value for the alert (alarm) condition.</p> <p>Note: This parameter is the greater (High) threshold value when Condition is set to "Inside Range" or "Outside range."</p>	Same measurement unit as Output Data Unit selection for specified channel.
Danger Threshold (High)	<p>The threshold value for the danger (shutdown) condition.</p> <p>Note: This parameter is the greater (High) threshold value when Condition is set to "Inside Range" or "Outside Range."</p>	Same measurement unit as Output Data Unit selection for specified channel.
Alert Threshold (Low)	<p>The lesser threshold value for the alert (alarm) condition.</p> <p>Note: This value is not used when Condition is set to "Greater Than" or "Less Than."</p>	Same measurement unit as Output Data Unit selection for the specified channel.
Danger Threshold (Low)	<p>The lesser threshold value for the danger (shutdown) condition.</p> <p>Note: This value is not used when Condition is set to "Greater Than" or "Less Than."</p>	Same measurement unit as Output Data Unit selection for the specified channel.

Alarm Parameters

Parameter Name	Description	Values/Comments
Hysteresis	<p>The amount that the measurement value must fall (below the threshold) before the alarm condition is cleared. For example, Alert Threshold = 120 and Hysteresis = 2. The alarm (alert) activates when the measured value is 120 and will not clear until the measured value is 118.</p> <p>Note: The Alert and Danger Thresholds use the same hysteresis value.</p> <p>Note: For the Outside Range condition, the hysteresis value must be less than Alert Threshold High – Alert Threshold Low.</p>	<p>Same measurement unit as Output Data Unit selection for the specified channel.</p>
Startup Period	<p>The length of time that the Threshold Multiplier is applied to the thresholds. The startup period begins when the setpoint multiplier switch is reopened (pushbutton disengaged or toggle switch flipped to off).</p>	<p>Enter a value from 0 to 1092 minutes, adjustable in increments of 0.1 minutes.</p>
Threshold Multiplier	<p>The action to take when the setpoint multiplier switch is closed (pushbutton engaged or toggle switch flipped to on) and during the startup period once the switch is reopened. The module applies the multiplier to the alarm thresholds during this time to avoid false alarms at resonance frequencies.</p> <p>Note: The multiplication may have the opposite of the intended affect under certain circumstances. For example, if the Condition is set to "Less Than" and the thresholds are positive, then multiplication of the threshold values increases the likelihood of the measured value being within the alarm range. Therefore, you may want to disable the alarms during the startup period.</p>	<p>Enter any fractional value between 0 and 10.</p> <p>Enter 0 (zero) to disabled the alarm during the startup period.</p>

Relay Parameters

The Relay parameters control the operation of the on-board relay, as well as the relays on the Expansion Relay (XM-441) module. Use these parameters to configure which alarm(s) the relay is associated with as well as the behavior of the relay.

IMPORTANT

A relay can be defined, regardless of whether or not it is physically present. A non-physical relay is a virtual relay. When a relay (physical or virtual) activates, the module sends a Change of State (COS) message to its master, which acts on the condition as necessary. An XM-440 Master Relay Module can activate its own relays in response to a relay (physical or virtual) activation at any of its slaves.

Relay Parameters

Parameter Name	Description	Values/Comments						
Number (XM Serial Configuration Utility only)	Sets the relay to be configured in the XM Serial Configuration Utility.	<p>Number 1 is the on-board relay. Numbers 2 through 5 are either relays on the Expansion Relay module when it's connected to the module or virtual relays.</p> <p>Virtual relays are non-physical relays. Use them when you want the effect of the relay (monitor alarms, activation delay, and change status) but do not need an actual contact closure. For example, a PLC or controller monitoring the relay status.</p> <p>Note: The Relay Installed parameter indicates whether a relay is a virtual relay or a physical relay on a module.</p>						
Name (XM Serial Configuration Utility only)	A descriptive name to help identify the relay in the XM Serial Configuration Utility.	Maximum 18 characters						
Enable	<p>Enable/disable the selected relay.</p> <p>Note: The Relay Current Status is set to "Not Activated" when the relay is disabled. See page 66.</p>	<table border="1"> <thead> <tr> <th>XM Configuration Utility</th> <th>EDS File</th> </tr> </thead> <tbody> <tr> <td>Check to Enable</td> <td>Enabled</td> </tr> <tr> <td>Clear to Disable</td> <td>Disabled</td> </tr> </tbody> </table>	XM Configuration Utility	EDS File	Check to Enable	Enabled	Clear to Disable	Disabled
XM Configuration Utility	EDS File							
Check to Enable	Enabled							
Clear to Disable	Disabled							

Relay Parameters

Parameter Name		Description	Values/Comments	
XM Configuration Utility	EDS File	Controls whether an explicit reset is required to deactivate the relay after the alarm subsides.	XM Configuration Utility	EDS File
Latching	Latching Option		Check means latching (relay must be explicitly reset)	Latching
			Clear means non-latching (relay is reset once the alarm condition has passed)	Nonlatching
Activation Delay		Enter the length of time for which the Activation Logic must be true before the relay is activated. This reduces nuisance alarms caused by external noise and/or transient vibration events.	Enter a value from 0 to 25.5 seconds, adjustable in increments of 0.1 seconds. Default is 1 second	
XM Configuration Utility	EDS File	Sets the relay activation logic. <ul style="list-style-type: none"> • A or B - Relay is activated when either Alarm A or Alarm B meets or exceeds the selected Alarm Status condition(s). • A and B - Relay is activated when both Alarm A and Alarm B meet or exceed the selected Alarm Status condition(s). • A Only - Relay is activated when Alarm A meets or exceeds the selected Alarm Status condition(s). 	Options: A only A or B A and B	
Activation Logic	Logic			
XM Configuration Utility	EDS File	Sets the alarm(s) that the relay will monitor. The alarm must be from the same device as the relay. When the Activation Logic is set to "A and B" or "A or B," you can select an alarm in both Alarm A and Alarm B . The system monitors both alarms. When the Activation Logic is set to "A only," you can select an alarm only in Alarm A .	Alarm Number 1 or 2	
Alarm A/B	Alarm Identifier A/B		Note: You can only select an alarm that is enabled.	

Relay Parameters

Parameter Name		Description	Values/Comments	
XM Configuration Utility	EDS File	<p>Sets the alarm conditions that will cause the relay to activate. You can select more than one.</p> <ul style="list-style-type: none"> • Normal - The current measurement is not in excess of any alarm thresholds. • Alert - The current measurement is in excess of the alarm level threshold(s) but not in excess of the danger level threshold(s). • Danger - The current measurement is in excess of the danger level threshold(s). • Disarm-The alarm is disabled or the device is in Program mode. • Xdcr Fault - A transducer fault is detected on the associated transducer. • Module Fault - Hardware or firmware failure, or an error has been detected and is preventing proper operation of the device. 	<p>Options: Normal Danger Xdcr Fault Alert Disarm Module Fault</p> <p>Check means enable. Clear means disable.</p>	
Alarm Status to Activate On	Alarm Levels			
Relay Installed		<p>Indicates whether the relay is a physical relay on a module or a virtual relay. If the relay is a physical relay, then you can set the Failsafe parameter.</p> <p>If the relay is a virtual relay, the Failsafe parameter is not used or it is disabled.</p>	XM Configuration Utility	EDS File
			Check = Physical Relay	Installed = Physical Relay
			Clear = Virtual Relay	Not Installed = Virtual Relay

Relay Parameters

Parameter Name		Description	Values/Comments	
XM Configuration Utility	EDS File	<p>Controls whether the relay is failsafe or nonfail-safe.</p> <p>Failsafe operation means that when in alarm, the relay contacts are in their "normal," de-energized, or "shelf-state" positions. In other words, normally closed relays are closed in alarm, and normally open relays are open in alarm. With failsafe operation, a power failure equals an alarm.</p> <p>The following are true of a relay in failsafe operation:</p> <ul style="list-style-type: none"> • The relay is energized when power is applied to the module. • The relay in a nonalarmed condition has power applied to the coil. • In alarm condition, power is removed from the relay coil, causing the relay to change state. <p>For nonfail-safe operation, the following are true:</p> <ul style="list-style-type: none"> • Under nonalarm conditions, the relay closes the circuit between the common and the N.C. (normally closed) terminals. • Under alarm conditions, the relay changes state to close the circuit between the common and the N.O. (normally open) terminals. <p>For failsafe operation, the following are true:</p> <ul style="list-style-type: none"> • Under nonalarm (with power applied to the unit) conditions, the relay closes the circuit between the common and the N.O. terminals. • Under alarm or loss-of-power conditions, the relay changes state to close the circuit between the common and the N.C. terminals. 	XM Configuration Utility	EDS File
Failsafe Relay	Failsafe Option		Check = Failsafe	Failsafe
			Clear = Nonfail-safe	Nonfailsafe

4-20mA Output Parameters

The 4-20mA output parameters define the characteristics of the two 4-20mA output signals. The parameters are the same for each output.

4-20mA Parameters

Parameter Name	Description	Values/Comments	
Enable	Enables/disables the 4-20 mA output.	XM Configuration Utility	EDS File
		Check to Enable	Enabled
		Clear to Disable	Disabled
Min Range	The measured value associated with the 4 mA.	Same measurement unit as Output Data Unit selection for the specified channel.	
Max Range	The measured value associated with the 20 mA.		

IMPORTANT

Measured values between **Min Range** and **Max Range** are scaled into the range from 4.0 to 20.0 to produce the output value. The **Min Range** value does not have to be less than the **Max Range** value. If the **Min Range** value is greater than the **Max Range** value, then the output signal is effectively inverted from the input signal.

IMPORTANT

The 4-20mA outputs are either on or off. When they are on, the 4-20mA outputs overshoot the 4 and 20mA limits by 10% when the measurement exceeds the minimum and maximum range. This means the minimum current produced is 3.6mA and the maximum current produced is 22mA.

When the 4-20mA outputs are off, they produce a current approximately 2.9mA. The 4-20mA outputs are off under the following conditions:

- The 4-20mA outputs are set to "Disable" (see **Enable** above).
- The module is in Program mode.
- A transducer fault occurs that affects the corresponding measurement.

Triggered Trend Parameters The XM-320 can collect a triggered trend. A triggered trend is a time-based trend that is collected when a relay on the XM-320 is activated, or the module receives a trigger event.

Once the triggered trend is configured, the XM-320 continuously monitors the trended measurements. When a trigger occurs, the XM-320 collects additional data as specified by the **Post Trigger** parameter.

The XM-320 can only store one triggered trend. Unless the triggered trend is latched, the trend data is overwritten with new data when the next trigger occurs.

The triggered trend parameters define the trend data that is collected by the module. Use these parameters to select the measurements included in the trend records, the interval between trend records, and which relay triggers (activates) the collection of the trend data.

IMPORTANT

The Triggered Trend parameters are not included in the EDS file and cannot be edited using generic configuration tools such as RSNetWorx for DeviceNet.

Triggered Trend Parameters

Parameter Name	Description	Values/Comments
Enable Triggered Trend Measurements	Enable/disable the triggered trend measurements. Select to configure the triggered trend measurements.	Check to enable. Clear to disable.
Select Measurements	Sets the measurements to be collected and stored in the module.	More than one measurement can be selected.
Number of Records	The maximum number of measurement sets that can be collected in the trend buffer. The measurement sets make up the trend data.	The Number of Records is automatically calculated based upon the number of Trended Measurements selected.
Latch Enable	Determines whether the trigger trend is latched or unlatched. Latched means that subsequent triggers are ignored after the initial trigger. This prevents the trend data from being overwritten with new data until the trigger is manually reset (click Reset Trigger button). Unlatched means that the trend data is overwritten with new data every time a trigger occurs.	Check means latched Clear means unlatched

Triggered Trend Parameters

Parameter Name	Description	Values/Comments
Relay Number	Sets the relay that triggers the trend to be collected.	<p>None means that the trend can only be triggered manually or by a trigger event (for example, XM-440).</p> <p>Relay Number 1 is the on-board relay. Numbers 2 through 5 are either relays on the Expansion Relay module when it's connected to the module or virtual relays.</p> <p>Note: The relay must be enabled. Refer to Relay Parameters on page 58.</p>
Record Interval	<p>The amount of time between consecutive trend records.</p> <p>Note: If you enter a Record Interval, the Trend Span is automatically updated.</p>	1 to 3600 seconds
Trend Span	<p>The total amount of time that can be covered by the trend data (Number of Records x Record Interval).</p> <p>Note: If you edit the Trend Span, the Record Interval is automatically updated.</p>	Seconds
Post Trigger	<p>The percentage of records to be collected once the trigger occurs. For example, if you set Post Trigger to 20%, then 80% of the records in the trend are before the trigger occurs, and 20% of the records in the trend are after the trigger occurs.</p> <p>This allows you to evaluate what happened after the trigger occurred.</p>	0 to 100 Percent
Status	Shows the status of the trend data.	<p>Possible status values:</p> <ul style="list-style-type: none"> • Not collected - No trend data is currently collected. • Collecting - A trigger has occurred and data (including post-trigger data) is being collected. • Collected - A trend has been saved to the buffer and is available to view and upload.
View Trend Data	Displays a plot of the collected trend data.	
Reset Trigger	Resets the trigger if Latch enabled is selected. This allows the module to overwrite the previous trend data when the next trigger occurs.	
Manual Trigger	Triggers the module to collect the trend data without relay activation.	

I/O Data Parameters

The I/O data parameters are used to configure the content and size of the DeviceNet I/O Poll response message.

IMPORTANT

The XM module must be free of Poll connections when configuring the **Poll Output (Poll Response Assembly)** and **Poll Size**. Any attempt to download the parameters while a master device has established the Poll connection with the XM module will result in an error.

To close an existing Poll connection with an XM-440, switch the XM-440 from Run mode to Program mode. Refer to Changing Operation Modes on page 73.

To close an existing Poll connection with other master devices, remove the module from the scan list or turn off the master device.

I/O Data Parameters

Parameter Name		Description	Values/Comments
COS Size (XM Serial Configuration Utility only)		The size (number of bytes) of the Change of State (COS) message.	The COS Size cannot be changed.
COS Output (XM Serial Configuration Utility only)		The Assembly instance used for the COS message. The COS message is used to produce the Alarm and Relay status for the module.	The COS Output cannot be changed. Refer to COS Message Format on page 78 for more information.
Poll Size		The size (number of bytes) of the Poll response message.	
XM Configuration Utility	EDS File	Sets the Assembly instance used for the Poll response message. Each Assembly instance contains a different arrangement of the Poll data.	Options: Assembly Instance 101 Custom Assembly
Poll Output	Poll Response Assembly	The Poll response message is used by the XM module to produce measured values. It can contain up to 31 REAL values for a total of 124 bytes of data.	Refer to Poll Message Format on page 77 for more information.
Assembly Instance Table (XM Serial Configuration Utility only)		Displays the format of the currently selected COS or Poll Assembly instance.	The highlighted (yellow) Assembly structure bytes are included in the I/O message.
Custom Assembly (XM Serial Configuration Utility only)		Defines a custom data format for the Poll response. The custom assembly can contain any of the measurement parameters included in Assembly instance 101, as well as alarm and relay configuration parameters.	You can select up to 20 parameters. Refer to Poll Message Format on page 77 for more information.

Data Parameters

The Data parameters are used to view the measured values of the input channels and the 4–20mA outputs, as well as to monitor the status of the channels, alarms, and relays.

TIP

To view all the data parameters in the XM Serial Configuration Utility, click the **View Data** tab.

Channel Data

Channel Data Parameters

Parameter Name		Description	Values/Comments
Channel Status		States whether a fault condition exists. If a fault exists, the measurement value may not be accurate.	
Measurement Value		Shows the current measurement value for the channel.	
XM Configuration Utility	EDS File	States whether a transducer fault exists.	Possible status values: No Fault Fault
Transducer Fault	Transducer Status		
Transducer DC Bias		Shows the measured average DC offset of the transducer signal. This value is compared with Fault High and Fault Low to determine whether the transducer is working properly.	
4-20mA Output A and B (XM Serial Configuration Utility only)		Shows the current output value in the range of 4.0 to 20.0mA.	

Alarm and Relay Status

Alarm and Relay Status Parameters

Parameter Name	Description	Values/Comments
Alarm Status	States the current status of the alarm.	<p>Possible status values.</p> <ul style="list-style-type: none"> • Normal - The alarm is enabled, the device is in Run mode, there is no transducer fault, and the current measurement is not within the Alert or Danger Threshold value(s). • Alert - The alarm is enabled, the device is in Run mode, there is no transducer fault, and the current measurement is in excess of the Alert Threshold value(s) but not in excess of the Danger Threshold value(s). • Danger - The alarm is enabled, the device is in Run mode, there is no transducer fault, and the current measurement is in excess of the Danger Threshold value(s). • Disarm-The alarm is disabled or the device is in Program mode. • Transducer Fault - The alarm is enabled, the device is in Run mode, and a transducer fault is detected on the associated transducer. • Module Fault - Hardware or firmware failure, or an error has been detected and is preventing proper operation of the device.
Relay Status	States the current status of the relay.	<p>Possible status values: Activated Not Activated</p>

Device Mode Parameters

The Device Mode parameters are used to control the functions and the behavior of the device.

IMPORTANT

The XM Serial Configuration Utility handles these parameters automatically and transparently to the user.

Device Mode Parameters

Parameter Name	Description	Values/Comments
Device Mode	Sets the current operation mode of the device. Refer to Changing Operation Modes on page 73 for more information.	Options: Run Mode Program Mode
Autobaud	Enables/disables autobaud. When autobaud is set to "Enabled," the module will listen to other devices on the network to determine the correct baud rate to use for communications. When autobaud is set to "Disabled," the module baud rate must be set manually.	Options: Enabled Disabled

Specifications

Appendix A lists the technical specifications for the XM-320 Position Module.

XM-320 Technical Specifications

Product Feature	Specification
Communications	
DeviceNet	<p>Standard DeviceNet protocol for all functions</p> <p><i>NOTE: The XM-320 uses only the DeviceNet protocol, not power. Module power is provided independently.</i></p> <p>Available Electronic Data Sheet (EDS) file provides support for most DeviceNet compliant systems</p> <p>Baud rate automatically set by bus master to 125kb, 250kb, 500kb</p>
Side Connector	<p>All XM measurement and relay modules include side connectors that allow interconnecting adjacent modules, thereby simplifying the external wiring requirements.</p> <p>The interconnect provides primary power, DeviceNet communications, and the circuits necessary to support expansion modules, such as the XM-441 Expansion Relay module.</p>
Serial	<p>RS-232 via mini-connector or terminal base unit</p> <p>Baud rate fixed at 19200</p> <p><i>NOTE: Local configuration via Serial Configuration Utility.</i></p>
Inputs	
2 Channels	<p>Eddy current transducer signals</p> <p>Linear variable differential transformer</p> <p>Voltage signals from any position measurement sensor</p>
Transducer Power	<p>Isolated 24 Volts that can be wired to be either +24V or -24V</p>
Voltage Range	<p>Selectable in software between -24V and +24V</p>
Sensitivity	<p>User configurable in software</p>
Input Impedance	<p>Greater than 100kohm</p>

XM-320 Technical Specifications

Product Feature		Specification
Outputs	4-20mA Outputs	Two isolated outputs 600 ohm max load
	Buffered Outputs	2 outputs; 1 per channel
Indicators	6 LEDs	Module Status - red/green Network Status - red/green Channel 1 Status - yellow/red Channel 2 Status - yellow/red Setpoint Multiplier - yellow Relay - red
Measurement Modes		Normal (two independent channels) Head-to-head Radial cancel
Delta Time Buffer	Number of Records	2048
	Delta Time Interval	1 to 3600 seconds
	Trigger Mode	Relay on the XM-320 module is activated, or by a trigger event (for example, DeviceNet command from a controller or host) <i>The data collected in the buffer is user configurable.</i>
Alarms	Number	2 alarm and danger pairs
	Operators	Greater than Less than Inside range Outside range
	Hysteresis	User configurable in software
	Startup Inhibit/Setpoint Multiplication	Period: 0 to 1092 minutes, adjustable in 0.1 minute increments Inhibit/multiplication function: Multiply by N (0 to 10, 0 = Disarm)
Relays	Number	Single on-board relay, two sets of contacts - DPDT (2 Form C) Four additional relays when interconnected to an XM-441 Expansion Relay module, or Four virtual relays whose status can be used by remote Control Systems or the XM-440 Master Relay module

XM-320 Technical Specifications

Product Feature	Specification
On-board Relay Rating	Maximum Voltage: 125V dc, 125V ac Maximum Current: 3.5A* Minimum Current: 0 Maximum Power: 60W, 62.5VA <i>*Max current is up to 40°C, then derates to 2A at 65°C.</i> Agency Rating: 120V ac @ 0.5A 110V dc @ 0.3A 30V dc @ 1.0A
Failsafe	Normally energized (failsafe), or Normally de-energized (non-fail-safe)
Latching	Latching, or Non-latching
Time Delay	0 to 25.5 seconds, adjustable in 100msec increments
Voting Logic	Single or paired "And" or "Or" logic applied to any alarm
Reset	Local reset switch on top of module Remote reset switch wired to terminal base Digital reset command via serial or DeviceNet interface
Activation On	Alarm Status: Normal Alert Danger Disarm Transducer fault Module fault
Non-Volatile Configuration	A copy of the module configuration is retained in non-volatile memory from where it is loaded upon power up* . <i>*The configuration stored in non-volatile memory can be deleted only by a module-reset command sent via the serial interface, using the Serial Configuration Utility, or via DeviceNet from any compliant software application.</i>
Power	
Module	+21.6 to 26.4V dc
Consumption	Maximum: 200mA Typical: 165mA

XM-320 Technical Specifications

Product Feature	Specification
Heat Production	Maximum: 5.28 Watts (18 BTU/hr) Typical: 3.96 Watts (13.5 BTU/hr)
Transducer	Isolated 24V dc, user configurable with wiring
Environmental	<p>Operating Temperature -20 to +65°C (-4 to +149°F)</p> <p>Storage Temperature -40 to +85°C (-40 to +185°F)</p> <p>Relative Humidity 95% non-condensing</p> <p><i>All printed circuit boards are conformally coated in accordance with IPC-A-610C.</i></p>
Physical	<p>Dimensions Height: 3.8in (97mm) Width: 3.7in (94mm) Depth: 3.7in (94mm)</p> <p>Terminal Screw Torque 7 pound-inches (0.6Nm)</p>
Approvals (when product or packaging is marked)	<p>UL UL Listed for Ordinary Locations</p> <p>UL UL Listed for Class I, Division 2 Group A, B, C, and D Hazardous Locations</p> <p>CSA CSA Certified Process Control Equipment</p> <p>CSA CSA Certified Process Control Equipment for Class I, Division 2 Group A, B, C, and D Hazardous Locations</p> <p>EEX* European Union 94/9/EEC ATEX Directive, compliant with EN 50021; Potentially Explosive Atmospheres, Protection "n"</p> <p>CE* European Union 89/336/EEC EMC Directive</p> <p>C-Tick* Australian Radiocommunications Act, compliant with: AS/NZS 2064, Industrial Emissions</p> <p><i>*See the Product Certification link at www.rockwellautomation.com for Declarations of Conformity, Certificates and other certification details.</i></p>

DeviceNet Information

Electronic Data Sheets

Electronic Data Sheet (EDS) files are simple text files used by network configuration tools such as RSNetWorx (Version 3.0 or later) to help you identify products and easily commission them on a network. The EDS files describe a product's device type, product revision, and configurable parameters on a DeviceNet network.

The EDS files for the XM modules are installed on your computer with the XM configuration software. The latest EDS files can also be obtained at <http://www.ab.com/networks/eds/> or by contacting your local Rockwell Automation representative.

Refer to your DeviceNet documentation for instructions on registering the EDS files.

Changing Operation Modes

XM modules operate in two modes.

Mode	Description
Run	The XM measurement modules collect measurement data and monitor each measurement device. The XM-440 establishes I/O connections with the XM measurement modules in its scan list and monitors their alarms, and controls its own relay outputs accordingly.
Program	The XM module is idle. The XM measurement modules stop the signal processing/measurement process, and the status of the alarms is set to the disarm state to prevent a false alert or danger status. The XM-440 closes the I/O connections with the XM measurement modules in its scan list and stops monitoring their alarms; relays are deactivated unless they are latched. Configuration parameters can be read, updated and downloaded to the XM module.

To change the operation mode of the module, use the Device Mode parameter in the EDS file. Note that the Stop and Start services described on page 75 can also be used to change the operation mode.

IMPORTANT

The XM Serial Configuration Utility software automatically puts XM modules in Program mode and Run mode without user interaction.

Transition to Program Mode

Parameter values can only be downloaded to an XM module while the module is in Program mode. Any attempt to download a parameter value while the module is in Run mode will result in a Device State Conflict error.

To transition an XM module from Run mode to Program mode on a DeviceNet network, set the **Device Mode** parameter to "Program mode" and click **Apply**. Note that you cannot change any other parameter until you have downloaded the Program mode parameter.

TIP

The Module Status indicator flashes green when the module is in Program mode.

Refer to your DeviceNet documentation for specific instructions on editing EDS device parameters.

TIP

You can also use the Stop service described on page 75 to transition XM modules to Program mode.

Transition to Run Mode

In order to collect data and monitor measurement devices, XM modules must be in Run mode. To transition an XM module from Program mode to Run mode on a DeviceNet network, set the **Device Mode** parameter to "Run mode" and click **Apply**.

TIP

The Module Status indicator is solid green when the module is in Run mode.

Refer to your DeviceNet documentation for specific instructions on editing EDS device parameters.

TIP

You can also use the Start service described on page 75 to transition XM modules to Run mode.

XM Services


The table below defines the services supported by the XM modules. The table includes the service codes, classes, instances, and attributes by their appropriate hexadecimal codes. Use the Class Instance Editor in RSNetWorx to execute these services, as illustrated in the example below.

XM Services

Action	Service Code (Hex)	Class (Hex)	Instance	Attribute	Data
Transition to Run Mode	Start (06)	Device Mode Object (320)	1	None	None
Transition to Program Mode	Stop (07)	Device Mode Object (320)	1	None	None
Save configuration to non-volatile memory (EEPROM)	Save (16)	Device Mode Object (320)	1	None	None
Delete saved configuration from non-volatile memory (EEPROM)	Delete (09)	Device Mode Object (320)	1	None	None
Reset a specific latched relay	Reset (05)	Relay Object (323)	Relay number 1-C for XM-440, 1-5 for XM-12X, XM-320 and XM-220, 1-8 for XM-36X and XM-16X	None	None
Reset all latched relays	Reset (05)	Relay Object (323)	0	None	None
Reset the Peak Speed (XM-12X only)	Reset (05)	Speed Measurement Object (325)	1, 2 for XM-220	None	None
Close the virtual setpoint multiplier switch to activate the alarm setpoint multipliers (not applicable to all XM modules)	Other (33)	Discrete Input Point Object (08)	1	None	None
Open the virtual setpoint multiplier switch to start the setpoint multiplier timers and eventually cancel alarm setpoint multiplication (not applicable to all XM modules)	Other (32)	Discrete Input Point Object (08)	1	None	None

Example

To save the configuration parameters to the non-volatile memory (EEPROM), fill in the Class Instance Editor as shown below.



Invalid Configuration Errors

A Start or Save service request to an XM module may return an Invalid Device Configuration error when there is a conflict amongst the configuration settings.

The general error code for the Invalid Device Configuration error is D0_{hex}. An additional error code is returned with the general error code to specify which configuration settings are invalid. The table below lists the additional error codes associated with the Invalid Device Configuration error.

Additional Error Codes returned with the Invalid Device Configuration Error (0xD0)

Error Code (Hex)	Description
01	No specific error information is available.
02	Mismatched transducer, channel, and/or measurement unit.
03	Inverted transducer fault high/low values.
04	Alarm thresholds conflict with the alarm condition.
05	Alarm speed range is invalid.
06	Band minimum frequency is greater than maximum frequency. Or, maximum frequency is greater than FMAX.
07	Relay is associated with an alarm that is not enabled.
08	Tachometer must be enabled for alarm or channel settings.
09	A senseless speed range is enabled on a speed alarm.

Additional Error Codes returned with the Invalid Device Configuration Error (0xD0)

Error Code (Hex)	Description
0A	Too many alarms associated with a single measurement.
0B	Invalid node address in the alarm list.
0C	Too many alarms in the alarm list. Or, no alarms in the alarm list.
0D	Alarm levels cannot be zero for alarms that are enabled.
0E	Too many slaves in the scanner's input data table.
0F	The FMAX and Number of Lines do not yield correct vector calculations.
10	Phase (vector) alarms prohibited with synchronous sampling and more than 1 tachometer pulse per revolution.
11	Order-base bands are prohibited on asynchronous channel.
12	Unsupported Sensor Type and Channel ID combination.
13	Invalid Alarm Type for the associated measurement ID.
14	Synchronous sampling is required for alarm on synchronous measurements.
15	Integration is not supported with the Bypass High Pass Filter option.

XM-320 I/O Message Formats

The XM-320 module supports Poll, Change of State (COS), and Bit-Strobe I/O messages. The Poll response message is used by the XM module to produce measured values, and the COS message is used to produce the Alarm and Relay Status. The Bit-Strobe message is used by a master device to send a trigger event to all the XM slaves on the network.

Poll Message Format

The XM-320 Poll request message contains no data. The Poll response message can contain up to 31 REAL values for a total of 124 bytes.

The XM-320 module provides one pre-defined (static) data format of the Poll response, as defined in Assembly instance 101. It also provides a dynamic Assembly instance, instance 199, with which you can define a custom data format for the Poll response. The dynamic Assembly instance can contain any of the measurement parameters included in Assembly instance 101, as well as several of the alarm and relay configuration parameters.

The default Assembly instance is 101 and the default size is 8 bytes. You can change the Assembly instance and define the custom Assembly instance using the configuration software. Refer to I/O Data Parameters on page 65.

The Poll response data can also be requested explicitly through Assembly Object (Class ID 0x4), Instance 101 (0x65), Data Attribute (3).

The following table shows the static data format of Assembly instance 101.

XM-320 I/O Poll Response Message Format

Byte	Definition
0–3	Channel 1 Position measurement value
4–7	Channel 2 Position measurement value

COS Message Format

The XM-320 COS message contains five bytes of data as defined in the table below. The COS data can also be requested explicitly through Assembly Object (Class ID 0x4), Instance 100 (0x64), Data Attribute (3).

XM-320 COS Message Format

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Relay 1 Status	Setpoint Multiplier Status	Alarm 2 Status		Alarm 1 Status			
1	Relay 2 Status	Reserved	Reserved		Reserved			
2	Relay 3 Status	Reserved	Reserved		Reserved			
3	Relay 4 Status	Reserved	Reserved		Reserved			
4	Relay 5 Status	Reserved	Reserved		Reserved			

XM Status Values

The following tables describe the XM Status values that are included in the COS messages.

Alarm Status Descriptions

Alarm Status Value	Description
0	Normal
1	Alert
2	Danger
3	Disarm
4	Transducer Fault (Sensor OOR)

Alarm Status Descriptions

Alarm Status Value	Description
5	Module Fault
6	Tachometer Fault
7	Reserved

Setpoint Multiplier Status Descriptions

Setpoint Multiplier Status Value	Description
0	Not Activated
1	Activated

Relay Status Descriptions


Relay Status Value	Description
0	Not Activated
1	Activated

Bit-Strobe Message Format

The Bit-Strobe command sends one bit of output data to each XM slave whose node address appears in the master's scanlist.

The Bit-Strobe command message contains a bit string of 64 bits (8 bytes) of output data, one output bit per node address on the network. One bit is assigned to each node address supported on the network (0..63) as shown in Figure B.1.

Figure B.1 Bit-Strobe Command



The XM modules use the bit received in a Bit-Strobe connection as a trigger event. When the bit number corresponding to the XM module's node address is set, the XM module will collect the triggered trend data.

Note that the XM modules do not send data in the Bit-Strobe response.

ADR for XM Modules

Automatic Device Replacement (ADR) is a feature of an Allen-Bradley DeviceNet scanner. It provides a means for replacing a failed device with a new unit, and having the device configuration data set automatically. Upon replacing a failed device with a new unit, the ADR scanner automatically downloads the configuration data and sets the node address.

IMPORTANT

It is recommended that ADR not be used in safety related applications. If the failure of the ADR server, and a subsequent power cycle, would result in the loss of protection for a machine, then ADR should not be implemented.

ADR can be used with XM modules but keep the following in mind when setting up the XM modules.

- The ADR scanner can not download the configuration data to an XM module if the module has a saved configuration in its non-volatile memory. This happens because the saved configuration is restored and the module enters Run mode when the power is cycled. (Configuration parameters cannot be downloaded while an XM module is in Run mode.) XM modules must be in Program mode for the ADR configuration to be downloaded and this occurs only when there is no saved configuration.

TIP

To delete a saved configuration from non-volatile memory, use the Delete service in RSNetWorx for DeviceNet or perform the following steps in the XM Serial Configuration Utility.

1. Save the current configuration to a file. From the **File** menu, click **Save As** and enter a file name for the configuration.
2. Reset the module to factory defaults. Click the **Module** tab and click the **Reset** button.
3. Reload the saved configuration. From the **File** menu, click **Open** and select the configuration file.
4. Make certain to disable auto save. From the **Device** menu, clear the **Auto Save Configuration** check mark.

- An XM module will enter Run mode automatically after the ADR scanner restores the module's configuration only if the module is in Run mode at the time the configuration is saved to the scanner. If the module is in Program mode when the configuration is saved, then the module will remain in Program after the configuration is downloaded by the ADR scanner.
- The ADR scanner saves and restores only the configuration parameters contained in the module's EDS file. Some XM parameters are not included in the EDS file because they are not supported by either the EDS specification or the tools that read the EDS files, for example RSNetWorx for DeviceNet. These configuration parameters will not be restored with ADR.

Below is a list of the configuration parameters that are not included in the EDS file and can not be saved or restored with ADR.

- Channel Name
 - Tachometer Name
 - Alarm Name
 - Relay Name
 - All Triggered Trend related parameters (see page 63)
 - All SU/CD Trend related parameters
 - Custom Assembly structure (see page 65)
- The ADR and trigger group functions cannot be used together. A module can have only one primary master so a module cannot be both configured for ADR and included in a trigger group. The ADR scanner must be the primary master for the modules configured for ADR. The XM-440 Master Relay module must be the primary master for modules included in a trigger group.

DeviceNet Objects

Appendix C provides information on the DeviceNet objects supported by the XM-320 module.

For information about	See page
Identity Object (Class ID 01H)	84
DeviceNet Object (Class ID 03H)	85
Assembly Object (Class ID 04H)	87
Connection Object (Class ID 05H)	90
Discrete Input Point Object (Class ID 08H)	92
Analog Input Point Object (Class ID 0AH)	93
Parameter Object (Class ID 0FH)	95
Acknowledge Handler Object (Class ID 2BH)	98
Alarm Object (Class ID 31DH)	99
Device Mode Object (Class ID 320H)	101
Relay Object (Class ID 323H)	102
Transducer Object (Class ID 328H)	105
4-20mA Output Object (Class ID 32AH)	106

TIP

Refer to the DeviceNet specification for more information about DeviceNet objects. Information about the DeviceNet specification is available on the ODVA web site (<http://www.odva.org>).

Identity Object (Class ID 01_H)

The Identity Object provides identification and general information about the device.

Class Attributes

The Identity Object provides no class attributes.

Instance Attributes

Table C.1 Identity Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Default Value
1	Get	Vendor ID	UINT	668 = Entek
2	Get	Device Type	UINT	109 (Specialty I/O)
3	Get	Product Code	UINT	23 (0x17) XM-320
4	Get	Revision: Major Minor	STRUCT OF USINT USINT	Value varies with each firmware revision. Value varies with each firmware revision.
5	Get	Status	WORD	
6	Get	Serial Number	UDINT	
7	Get	Product Name	SHORT_ STRING	"XM-320 Position Module"

Status

The **Status** is a 16 bit value. The following bits are implemented.

Table C.2 Identity Object Status

Bit	Name	Description
0	Owned	TRUE indicates that the module has an owner. More specifically, the Predefined Master/Slave Connection Set has been allocated to a master.
1		Reserved, set to 0
2	Configured	This bit is set whenever a saved configuration is successfully loaded from non-volatile memory. This bit is cleared whenever the default configuration is restored or loaded.
3		Reserved, set to 0

Table C.2 Identity Object Status

Bit	Name	Description
4	Boot Program	Vendor-specific, indicates that the boot program is running. The Main Application must be corrupt or missing.
5 - 7		Vendor-specific, not implemented
8	Minor Recoverable Fault	Set whenever there is a transducer or tachometer fault.
9	Minor Unrecoverable Fault	Not implemented
10	Major Recoverable Fault	Set when the module detects a major problem that the user may be able to recover from. The Module Status LED will flash red. An example of this condition is when the boot program is running.
11	Major Unrecoverable Fault	Set when there is a module status fault (Module Status LED is solid red).
12 - 15		Reserved, set to 0

Services

Table C.3 Identity Object Services

Service Code	Class/Instance Usage	Name
01 _h	Instance	Get_Attributes_All
05 _h	Instance	Reset
0E _h	Instance	Get_Attribute_Single
10 _h	Instance	Set_Attribute_Single ¹

¹ Attributes can only be set while the device is in Program Mode. See the description of the Device Mode Object for more information.

DeviceNet Object (Class ID 03_H)

The DeviceNet Object is used to provide the configuration and status of a physical attachment to DeviceNet.

Class Attributes

Table C.4 DeviceNet Object Class Attributes

Attr ID	Access Rule	Name	Data Type	Default Value
1	Get	Revision	UINT	2

Instance Attributes

Table C.5 DeviceNet Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Default Value
1	Get/Set	MAC ID ¹	USINT	63
2	Get/Set	Baud Rate ²	USINT	0
3	Get	Bus-Off Interrupt	BOOL	0
4	Get/Set	Bus-Off Counter	USINT	0
5	Get	Allocation Information	STRUCT of BYTE USINT	0 255
100	Get/Set	Autobaud Disable	BOOL	0 (Ignore attribute 2 and always autobaud)

- 1 Setting the MAC ID causes the device to reset automatically, after which it will go online with the new MAC ID.
- 2 The Baud Rate setting can not be set while **Autobaud Disable** is equal to 0. The new baud rate will not take effect until the module is reset.

The **MAC ID**, **Baud Rate**, and **Autobaud Disable** settings are stored in non-volatile memory so they do not reset to the default with each power cycle. The **Baud Rate** attribute supports the following settings:

- 0 = 125 kbps
- 1 = 250 kbps
- 2 = 500 kbps

The **Baud Rate** setting is used only when automatic baud rate detection is disabled (**Autobaud Disable** = 1). When **Autobaud Disable** is set to zero (0), the module ignores its **Baud Rate** setting and performs automatic baud rate detection instead. This means that the module will determine the network baud rate by listening for network traffic before attempting to go online.

Services

Table C.6 DeviceNet Object Services

Service Code	Class/Instance Usage	Name
0E _h	Class/Instance	Get_Attribute_Single
10 _h	Instance	Set_Attribute_Single ¹
4B _h	Instance	Allocate_Master/Slave_Connetion_Set
4C _h	Instance	Release_Group_2_Identifier_Set

¹ Attributes can only be set while the device is in Program Mode. See the description of the Device Mode Object for more information.

Assembly Object (Class ID 04_H)

The Assembly Object binds attributes of multiple objects to allow data to or from each object to be sent or received in a single message.

The XM-320 module provides both static and dynamic assemblies.

Class Attributes

Table C.7 Assembly Object Class Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
1	Get	Revision	UINT	Revision of the implemented object.	2

Instances

Table C.8 Assembly Object Instances

Instance	Name	Type	Description
100	Default COS Message	Input	Alarm and Relay Status values
101	Default Poll Response Message	Input	Measurement values
102 - 106	Alternate Poll Response Message	Input	Measurement values
199	Alternate Dynamic Poll Response Message	Input	User configurable measurement values and configuration parameters

Instance Attributes

Table C.9 Assembly Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Value
1	Get	Number of Members in list	UINT	Only supported for Dynamic Assembly instance
2	Set	Member List	Array of STRUCT:	Only supported for Dynamic Assembly instance
		Member Data Description	UINT	Size of member data value in bits
		Member Path Size	UINT	
		Member Path	Packed EPATH	
3	Get	Data	Defined in tables on the following pages.	

Assembly Instance Attribute Data Format

Instance 100 - Alarm and Relay Status

This assembly is sent using COS messaging when any of the Alarm or Relay Status values change.

Table C.10 Instance 100 Data Format (Alarm and Relay Status Values Assembly)

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	Relay 1 Status	Set Point Multiplier	Alarm 2 Status			Alarm 1 Status		
1	Relay 2 Status	0	0			0		
2	Relay 3 Status	0	0			0		
3	Relay 4 Status	0	0			0		
4	Relay 5 Status	0	0			0		

Instance 101 - Measurement Values

This is the default assembly instance that is sent using the I/O Poll Response message when an I/O Poll Request is received from a DeviceNet Master.

Table C.11 Instance 101 Data Format (Measurement Values Assembly)

Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0 - 3	Transducer 1 Position value							
4 - 7	Transducer 2 Position value							

Instance 199 - Dynamic Assembly

This Assembly instance can be created and configured with the XM Serial Configuration Utility or RSMACC Enterprise Online Configuration Utility. Using the configuration software, you determine the format of the data. This assembly instance can be selected to be sent in response to an I/O Poll request from a Master.

The dynamic Assembly can include all of the measurement values included in Assembly instance 101. In addition, the dynamic Assembly can include the following configuration parameters.

Table C.12 Instance 199 Component Mapping

EPATH (where ii = instance number)	Class Name	Class Number	Instance Number	Attribute Name	Attribute Number	Data Type
21 1D 03 24 ii 30 04	Alarm	31D _h	1 - 2	Alarm Enable	4	BOOL
21 1D 03 24 ii 30 07	Alarm	31D _h	1 - 2	Condition	7	USINT
21 1D 03 24 ii 30 08	Alarm	31D _h	1 - 2	Alert Threshold (High)	8	REAL
21 1D 03 24 ii 30 09	Alarm	31D _h	1 - 2	Danger Threshold (High)	9	REAL
21 1D 03 24 ii 30 0A	Alarm	31D _h	1 - 2	Alert Threshold Low	10	REAL
21 1D 03 24 ii 30 0B	Alarm	31D _h	1 - 2	Danger Threshold Low	11	REAL
21 1D 03 24 ii 30 0C	Alarm	31D _h	1 - 2	Hysteresis	12	REAL
21 1D 03 24 ii 30 0D	Alarm	31D _h	1 - 2	Threshold (Set Point) Multiplier	13	REAL
21 1D 03 24 ii 30 0E	Alarm	31D _h	1 - 16	Startup Period	14	UINT
21 23 03 24 ii 30 04	Relay	323 _h	1 - 5	Relay Enable	4	BOOL
21 23 03 24 ii 30 05	Relay	323 _h	1 - 5	Latch Enable	5	BOOL
21 23 03 24 ii 30 06	Relay	323 _h	1 - 5	Failsafe Enable	6	BOOL
21 23 03 24 ii 30 07	Relay	323 _h	1 - 5	Delay	7	UINT
21 23 03 24 ii 30 09	Relay	323 _h	1 - 5	Alarm Level	9	BYTE

Table C.12 Instance 199 Component Mapping

EPATH (where ii = instance number)	Class Name	Class Number	Instance Number	Attribute Name	Attribute Number	Data Type
21 0F 00 24 ii 30 01	Param	0F _h	6 - 10	Parameter Value (Alarm Identifier A)	1	USINT
21 0F 00 24 ii 30 01	Param	0F _h	11 - 15	Parameter Value (Alarm Identifier B)	1	USINT
21 23 03 24 ii 30 0C	Relay	323 _h	1 - 5	Logic	12	USINT
21 23 03 24 ii 30 0E	Relay	323 _h	1 - 5	Relay Installed	14	BOOL

The dynamic Assembly instance must be instantiated with a call to the class level Create service. Then the structure can be defined with the Set_Attribute_Single service for the Member List attribute. Only one dynamic Attribute instance is supported so subsequent calls to the Create service will return a Resource Unavailable (0x02) error. The Delete service can be used to destroy the dynamic Assembly instance so that it can be re-created.

Services

Table C.13 Assembly Object Services

Service Code	Class/Instance Usage	Name
0E _h	Class/Instance	Get_Attribute_Single
10 _h	Instance	Set_Attribute_Single
08 _h	Class	Create
09 _h	Instance	Delete

Connection Object (Class ID 05_H)

The Connection Object allocates and manages the internal resources associated with both I/O and Explicit Messaging Connections.

Class Attributes

The Connection Object provides no class attributes.

Instances

Table C.14 Connection Object Instances

Instance	Description
1	Explicit Message Connection for pre-defined connection set
2	I/O Poll Connection
3	I/O Strobe Connection
4	I/O COS (change of state) Connection
11 - 17	Explicit Message Connection

Instance Attributes

Table C.15 Connection Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description
1	Get	State	USINT	State of the object.
2	Get	Instance Type	USINT	Indicates either I/O or Messaging Connection.
3	Get	Transport Class Trigger	BYTE	Defines behavior of the Connection.
4	Get	Produced Connection ID	UINT	Placed in CAN Identifier Field when the Connection transmits.
5	Get	Consumed Connection ID	UINT	CAN Identifier Field value that denotes message to be received.
6	Get	Initial Comm Characteristics	BYTE	Defines the Message Group(s) across which productions and consumptions associated with this Connection occur.
7	Get	Produced Connection Size	UINT	Maximum number of bytes transmitted across this Connection.
8	Get	Consumed Connection Size	UINT	Maximum number of bytes received across this Connection.
9	Get/Set	Expected Packet Rate	UINT	Defines timing associated with this Connection.
12	Get/Set	Watchdog Time-out Action	USINT	Defines how to handle Inactivity/Watchdog timeouts.
13	Get	Produced Connection Path Length	UINT	Number of bytes in the production_connection_path attribute.
14	Get	Produced Connection Path	Array of USINT	Specifies the Application Object(s) whose data is to be produced by this Connection Object. See DeviceNet Specification Volume 1 Appendix I.

Table C.15 Connection Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description
15	Get	Consumed Connection Path Length	UINT	Number of bytes in the consumed_connection_path attribute.
16	Get	Consumed Connection Path	Array of USINT	Specifies the Application Object(s) that are to receive the data consumed by this Connection Object. See DeviceNet Specification Volume 1 Appendix I.
17	Get	Production Inhibit Time	UINT	Defines minimum time between new data production.

Services

Table C.16 Connection Object Services

Service Code	Class/Instance Usage	Name
05 _h	Instance	Reset
0E _h	Instance	Get_Attribute_Single
10 _h	Instance	Set_Attribute_Single

Discrete Input Point Object (Class ID 08_H)

The Discrete Input Point Object stores information about the value of the Setpoint Multiplier signal.

Class Attributes

Table C.17 Discrete Input Object Class Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
1	Get	Revision	UINT	Revision of the implemented object.	2

Instance Attributes

Table C.18 Discrete Input Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
3	Get	Value	BOOL	Setpoint Multiplier	0 = Off 1 = On
199	Set	Backdoor Service	USINT	Setting this attribute is equivalent to requesting the specified service.	Set to one of the following values to perform the specified service: 0x32 = Open 0x33 = Close

Services

Table C.19 Discrete Input Object Services

Service Code	Class/Instance Usage	Name	Description
0E _h	Class/Instance	Get_Attribute_Single	Returns the contents of the specified attribute.
10 _h	Instance	Set_Attribute_Single	Sets the contents of the specified attribute.
32 _h	Instance	Open	Opens the virtual Setpoint Multiplier switch.
33 _h	Instance	Close	Closes the virtual Setpoint Multiplier switch.

Analog Input Point Object (Class ID 0A_H)

The Analog Input Point Object models simple analog measurements performed by the XM-320 module.

Class Attributes

Table C.20 Analog Input Point Object Class Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
1	Get	Revision	UINT	Revision of the implemented object.	2

Instances

Table C.21 Analog Input Point Object Instances

Instance	Name	Description
1	Position	Position measurement for transducer 1.
2	Position	Position measurement for transducer 2.

Instance Attributes

Table C.22 Analog Input Point Object Class Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
3	Get	Value	REAL	The position measurement value.	The raw measured value plus any offset specified by Calibration Bias .
4	Get	Status	BOOL	Indicates if a fault or alarm has occurred.	0 = Operating without alarms or faults 1 = Alarm or fault condition exists. The Value attribute may not represent the actual field value.
8	Get	Value Data Type	USINT	Determines the data type of the Value .	1 = REAL
122	Get/Set	Calibration Bias	REAL	Offset added into the raw measured value.	Used to set the "zero point."
147	Get/Set	Data Units	ENGUNIT	The units context of the Value attribute.	See DeviceNet Specification Volume 1 Appendix.

Services

Table C.23 Analog Input Point Object Services

Service Code	Class/Instance Usage	Name	Description
0E _h	Class/Instance	Get_Attribute_Single	Returns the contents of the specified attribute.
10 _h	Instance	Set_Attribute_Single	Sets the contents of the specified attribute. ¹

¹ Attributes can only be set while the device is in Program Mode. See the description of the Device Mode Object for more information.

Parameter Object (Class ID 0F_H)

The Parameter Object provides the interface to the XM-320 configuration data. There are 15 Parameter Object instances implemented in the XM-320 module.

Parameter Object instances 1-4 and 6-15 are implemented to provide an alternate method of setting the configuration parameters with EPATH or ENGUNIT data types.

Instance 5 of the Parameter Object is for setting the device "Mode." The Mode setting determines how the two position sensors are used:

- **Normal** - The two sensors are used independently to perform two separate position measurements.
- **Head-to-Head** - The two sensors are used together, facing each other on either side of the target, to perform a single position measurement. This mode can be used to extend upon the range of a single sensor.
- **Radial Cancel** - The two sensors are used together to perform a single position measurement. The second sensor is setup in such a way that it can measure the radial movement of the target. The radial movement can then be subtracted out of the position measurement performed by the first sensor.

Class Attributes

Table C.24 Parameter Object Class Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
2	Get	Max Instance	UINT	Maximum instance number of an object in this class.	Total number of parameter object instances.
8	Get	Parameter Class Descriptor	WORD	Bits that describe the parameter.	Bit 0 Supports Parameter Instances Bit 1 Supports Full Attrib. Bit 2 Must do non-volatile store Bit 3 Params in non-volatile
9	Get	Config. Assembly Instance	UINT		Set to 0

Instances

There are 15 instances of this object.

Table C.25 Parameter Object Instances

Instance	Read Only	Name	Data Type	Valid Values	Default Value
1	No	Transducer 1 Sensitivity Units	USINT	0 = mils 1 = degrees of rotation 2 = mm 3 = percent	0
2	No	Transducer 2 Sensitivity Units	USINT	0 = mils 1 = degrees of rotation 2 = mm 3 = percent	0
3	No	Position Measurement 1 Units	USINT	0 = mils 1 = degrees of rotation 2 = mm 3 = percent	0
4	No	Position Measurement 2 Units	USINT	0 = mils 1 = degrees of rotation 2 = mm 3 = percent	0
5	No	Mode	USINT	0 = Normal 1 = Head-to-Head 2 = Radial Cancel	0
6	No	Relay 1 Alarm Identifier A	USINT	0 = Alarm 1 1 = Alarm 2	0
7	No	Relay 2 Alarm Identifier A	USINT	0 = Alarm 1 1 = Alarm 2	0
8	No	Relay 3 Alarm Identifier A	USINT	0 = Alarm 1 1 = Alarm 2	0
9	No	Relay 4 Alarm Identifier A	USINT	0 = Alarm 1 1 = Alarm 2	0
10	No	Relay 5 Alarm Identifier A	USINT	0 = Alarm 1 1 = Alarm 2	0
11	No	Relay 1 Alarm Identifier B	USINT	0 = Alarm 1 1 = Alarm 2	0
12	No	Relay 2 Alarm Identifier B	USINT	0 = Alarm 1 1 = Alarm 2	0
13	No	Relay 3 Alarm Identifier B	USINT	0 = Alarm 1 1 = Alarm 2	0
14	No	Relay 4 Alarm Identifier B	USINT	0 = Alarm 1 1 = Alarm 2	0
15	No	Relay 5 Alarm Identifier B	USINT	0 = Alarm 1 1 = Alarm 2	0

Table C.25 Parameter Object Instances

Instance	Read Only	Name	Data Type	Valid Values	Default Value
16	No	Poll Connection Produced Connection Path	USINT	101, 199 (Assembly Object instance number)	101
17	No	Poll Connection Produced Connection Size	UINT	4 - 124	8

Instance Attributes

Table C.26 Parameter Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
1	Set	Parameter Value		Actual value of parameter	See Table C.25 for a list of valid values for each instance.
2	Get	Link Path Size	USINT	Size of Link Path	0 (These Parameter instances do not link directly to another object attribute.)
3	Get	Link Path	ARRAY of DeviceNet path	DeviceNet path to the object for the Parameter value.	
		Segment Type/Port	BYTE	See DeviceNet Specification Volume 1 Appendix I for format.	
		Segment Address		See DeviceNet Specification Volume 1 Appendix I for format.	
4	Get	Descriptor	WORD	Description of Parameter	Bit 0 = Settable Path support Bit 1 = Enum Strings support Bit 2 = Scaling support Bit 3 = Scaling Links support Bit 4 = Read Only Bit 5 = Monitor Bit 6 = Ext. Prec. scaling
5	Get	Data Type	EPATH	Data Type Code	See DeviceNet Specification Volume 1 Appendix J, Section J-6.
6	Get	Data Size	USINT	Number of Bytes in Parameter value.	

Services

Table C.27 Parameter Object Services

Service Code	Class/Instance Usage	Name	Description
0E _h	Class/Instance	Get_Attribute_Single	Returns the contents of the specified attribute.
10 _h	Class	Set_Attribute_Single	Sets the contents of the specified attribute. ¹

¹ Attributes can only be set while the device is in Program Mode. See the description of the Device Mode Object for more information.

Acknowledge Handler Object (Class ID 2B_H)

The Acknowledge Handler Object is used to manage the reception of message acknowledgments. This object communicates with a message producing Application Object within a device. The Acknowledge Handler Object notifies the producing application of acknowledge reception, acknowledge timeouts, and production retry limit errors.

Class Attributes

The Acknowledge Handler Object provides no class attributes.

Instances

A module provides only a single instance (instance 1) of the Acknowledge Handler Object. This instance is associated with instance 4 of the Connection Object, the slave COS connection to a higher level master.

Instance Attributes

Table C.28 Acknowledge Handler Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Default Value
1	Get/Set	Acknowledge Timer	UINT	16ms
2	Get/Set	Retry Limit	USINT	1
3	Get	COS Producing Connection Instance	UINT	4

Services

Table C.29 Acknowledge Handler Object Services

Service Code	Class/Instance Usage	Name
0E _h	Instance	Get_Attribute_Single
10 _h	Instance	Set_Attribute_Single

Alarm Object (Class ID 31D_H)

The Alarm Object models a two-stage (alert and danger levels) alarm.

Class Attributes

Table C.30 Alarm Object Class Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
1	Get	Revision	USINT	Revision of the implemented object.	2 (indicates that Threshold Multiplier is a REAL instead of USINT)

Instances

There are 2 instances of this object.

Instance Attributes

Table C.31 Alarm Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
3	Get	Alarm Status	3 BITS	The current status of the alarm.	0 = Normal 1 = Alert (alarm) 2 = Danger (shutdown) 3 = Disarm 4 = Xdcr Fault 5 = Module Fault
4	Get/Set	Alarm Enable	BOOL	Indicates whether this alarm object is enabled.	0 = Disabled 1 = Enabled

Table C.31 Alarm Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
6	Get	Threshold Units	USINT	Indicates whether the threshold and hysteresis value are specified in units of measure.	Set to 1 1 = Measurement units
7	Get/Set	Condition	USINT	Indicates on which side of the threshold values the alarm and danger conditions exist.	0 = Greater than 1 = Less than 2 = Inside range 3 = Outside range
8	Get/Set	Alert Threshold (High)	REAL	The threshold value for the alert (alarm) condition (greater threshold for range types).	
9	Get/Set	Danger Threshold (High)	REAL	The threshold value for the danger (shutdown) condition (greater threshold for range types).	
10	Get/Set	Alert Threshold Low	REAL	The lesser threshold value for the alert (alarm) condition for the range condition types.	
11	Get/Set	Danger Threshold Low	REAL	The lesser threshold value for the danger (shutdown) condition for the range condition types.	
12	Get/Set	Hysteresis	REAL	The amount on the safe side of a threshold by which the value must recover to clear the alarm.	
13	Get/Set	Threshold (Setpoint Multiplier)	REAL	Indicates how the thresholds should be adjusted when the setpoint multiplication function is invoked.	0 = Disable alarm > 0 = Multiply the thresholds by the value
14	Get/Set	Startup Period	UINT	The amount of time that the Threshold (Setpoint) Multiplier is applied after the startup signal is received.	Seconds
18	Get/Set	Name	STRING2	A name to help identify this alarm.	

Services

Table C.32 Alarm Object Services

Service Code	Class/Instance Usage	Name	Description
0E _h	Instance	Get_Attribute_Single	Returns a single attribute.
10 _h	Instance	Set_Attribute_Single	Sets a single attribute. ¹

¹ Attributes can only be set while the device is in Program Mode. See the description of the Device Mode Object for more information.

Device Mode Object (Class ID 320_H)

The Device Mode Object is used to control access to the configuration parameters in the module. This object's Device Mode attribute must be in PROGRAM mode to allow the module's configuration parameters to be "Set" (see Services). Attempts to set the configuration parameters while the Device Mode is in RUN mode will return an error. Note that the module collects measurements while in RUN mode but not while it is in PROGRAM mode.

Class Attributes

The Device Mode Object provides no class attributes.

Instance Attributes

Table C.33 Device Mode Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
3	Get/Set	Device Mode	UINT	The operating mode of the module.	0 = Power Up 1 = RUN 2 = PROGRAM
199	Set	Backdoor Service	USINT	Setting this attribute is equivalent to requesting the specified service.	Set to one of the following values to perform the specified service: 0x05 = Reset 0x09 = Delete 0x15 = Restore 0x16 = Save

Setting the **Device Mode** attribute to "1" (RUN) is equivalent to executing the **Start** service. Setting the **Device Mode** attribute to "2" (PROGRAM) is equivalent to executing the **Stop** service.

Services

Table C.34 Device Mode Object Services

Service Code	Class/Instance Usage	Name	Description
0E _h	Instance	Get_Attribute_Single	Return the value of a single attribute.
10 _h	Instance	Set_Attribute_Single	Set the value of a single attribute.
07 _h	Instance	Stop	Transitions from Run to the Program state.
06 _h	Instance	Start	Validate the device configuration settings and transition to the Run state if OK.
05 _h	Instance	Reset	Transition to the Power Up state. Load the non-volatile configuration and transition to the Run state if saved configuration restored.
16 _h	Instance	Save	Validate the device configuration settings if necessary and save them to non-volatile memory.
09 _h	Instance	Delete	Delete the saved configuration from non-volatile memory.
15 _h	Instance	Restore	Load the saved configuration or the factory default configuration from non-volatile memory.

Relay Object (Class ID 323_H)

The Relay Object models a relay (actual or virtual). A relay can be activated or deactivated based on the status of one or more alarms.

Class Attributes

Table C.35 Relay Object Class Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
3	Get	Number of Instances	UINT	Number of Instances in this class.	5
100	Set	Reset All	USINT	Setting this attribute is equivalent to executing the Class Reset service	Reset All is an attribute that provides a way to perform a Class level Reset service via the Set_Attribute_Single service. Setting this attribute to any value is equivalent to performing the Class level Reset service. Reading the Reset All attribute always returns zero.

Instances

There are 5 instances of this object.

Instance Attributes

Table C.36 Relay Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
3	Get	Relay Status	BOOL	The current status of the relay.	0 = Off 1 = On
4	Get/Set	Relay Enable	BOOL	Indicates whether this relay object is enabled.	0 = Disabled 1 = Enabled
5	Get/Set	Latch Enable	BOOL	Indicates whether this relay latches (requires a reset command to deactivate).	0 = Nonlatching 1 = Latching
6	Get/Set	Failsafe Enable	BOOL	Indicates whether this relay is normally energized (activated during power loss).	0 = Non-failsafe (not normally energized) 1 = Failsafe (normally energized)
7	Get/Set	Delay	USINT	The time period that the voting logic must be true before the relay is activated.	0 to 25.5 seconds (specified in tenths of seconds)
8	Get/Set	Name	STRING2	A name to help identify the relay.	18 characters maximum

Table C.36 Relay Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
9	Get/Set	Alarm Level	BYTE	Specifies what alarm status values will cause the relay to activate.	0 = Normal 1 = Alert 2 = Danger 3 = Disarm 4 = Xdcr Fault 5 = Module Fault
10	Get/Set	Alarm Identifier A	EPATH	Identifies the first alarm status the relay monitors.	See Parameter Object instances 6 to 10.
11	Get/Set	Alarm Identifier B	EPATH	Identifies the second alarm status the relay monitors.	See Parameter Object instances 11 to 15.
12	Get/Set	Logic	USINT	Indicates the number of associated alarms that must have a status value specified by Alarm Level in order to activate the relay.	0 = Ignore Alarm Identifier B and activate the relay based on the status of Alarm Identifier A . 1 = Activate the relay if the status of either Alarm Identifier A or B matches any of the statuses specified by Alarm Level . 2 = Activate the relay if the status of both Alarm Identifier A and B match any of the statuses specified by Alarm Level .
14	Get	Relay Installed	BOOL	Indicates whether an actual relay is associated with this instance.	0 = Not installed 1 = Installed

Services

Table C.37 Relay Object Services

Service Code	Class/Instance Usage	Name	Description
05 _h	Class/Instance	Reset	Resets latched relay.
0E _h	Class/Instance	Get_Attribute_Single	Returns a single attribute.
10 _h	Class/Instance	Set_Attribute_Single	Sets a single attribute. ¹

¹ Attributes can only be set while the device is in Program Mode. See the description of the Device Mode Object for more information.

Transducer Object (Class ID 328_H)

The Transducer Object models a transducer.

Class Attributes

The Transducer Object provides no class attributes.

Instances

There are 2 instances of this object.

Instance Attributes

Table C.38 Transducer Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
3	Get	DC Bias	REAL	The measured average DC bias of the transducer signal in volts.	Volts
4	Get	Status	BOOL	Indicates whether a transducer fault exists (the measured DC Bias is outside the range specified by Fault High and Low).	0 = No fault 1 = A transducer fault exists
5	Get/Set	Sensitivity Value	REAL	Value of the sensitivity of the transducer in millivolts per Sensitivity Units .	
6	Get/Set	Sensitivity Units	ENGUNIT	Units of the denominator of the Sensitivity Value .	See DeviceNet Specification Volume 1 Appendix K. Also see Parameter Object instances 1 and 2. Valid values: mils = 0800 hex degrees of rotation = 1703 hex mm = 2203 hex
7	Get/Set	Fault High	REAL	The maximum expected DC Bias voltage from the transducer in volts.	Volts
8	Get/Set	Fault Low	REAL	The minimum expected DC Bias voltage from the transducer in volts.	Volts

Table C.38 Transducer Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
11	Get/Set	Target Angle	REAL	The angle of the target relative to the shaft in degrees.	0 to 90 degrees
12	Get/Set	Upscale	BOOL	Indicates the movement of the target relative to the transducer which is considered positive displacement.	0 = Away 1 = Towards
13	Get/Set	DC Bias Time Constant	REAL	The time constant value used for exponential averaging of the DC Bias value (a low pass filter/output smoothing filter).	Seconds
14	Get/Set	Name	STRING2	A name to help identify this transducer or channel.	18 characters maximum

Services

Table C.39 Transducer Object Services

Service Code	Class/Instance Usage	Name	Description
0E _h	Instance	Get_Attribute_Single	Returns a single attribute.
10 _h	Instance	Set_Attribute_Single	Sets a single attribute. ¹

¹ Attributes can only be set while the device is in Program Mode. See the description of the Device Mode Object for more information.

4-20mA Output Object (Class ID 32A_H)

The 4-20mA Output Object models the configuration of a 4-20mA output signal.

Class Attributes

The 4-20mA Output Object provides no class attributes.

Instances

There are 2 instances of this object.

Instance Attributes

Table C.40 4-20mA Output Object Instance Attributes

Attr ID	Access Rule	Name	Data Type	Description	Semantics
3	Get/Set	Value	REAL	The current output value.	mA
4	Get/Set	Enable	BOOL	Indicates whether this 4-20mA output is enabled.	0 = Disabled 1 = Enabled
5	Get/Set	Max Range	REAL	The measured value associated with 20mA.	
6	Get/Set	Min Range	REAL	The measured value associated with 4mA.	

Services

Table C.41 4-20mA Output Object Services

Service Code	Class/Instance Usage	Name	Description
0E _h	Instance	Get_Attribute_Single	Returns a single attribute.
10 _h	Instance	Set_Attribute_Single	Sets a single attribute. ¹

¹ Attributes can only be set while the device is in Program Mode. See the description of the Device Mode Object for more information.

alarm

An alarm alerts you to a change in a measurement. For example, an alarm can notify you when the measured vibration level for a machine exceeds a pre-defined value.

Automatic Device Replacement (ADR)

A means for replacing a malfunctioning device with a new unit, and having the device configuration data set automatically. The ADR scanner uploads and stores a device's configuration. Upon replacing a malfunctioning device with a new unit (MAC ID 63), the ADR scanner automatically downloads the configuration data and sets the MAC ID (node address).

baud rate

The baud rate is the speed at which data is transferred on the DeviceNet network. The available data rates depend on the type of cable and total cable length used on the network:

Cable	Maximum Cable Length		
	125K	250K	500K
Thick Trunk Line	500m (1,640ft.)	250m (820ft.)	100m (328ft.)
Thin Trunk Line	100m (328ft.)	100m (328ft.)	100m (328ft.)
Maximum Drop Length	6m (20ft.)	6m (20ft.)	6m (20ft.)
Cumulative Drop Length	156m (512ft.)	78m (256ft.)	39m (128ft.)

The XM measurement modules' baud rate is automatically set by the bus master. You must set the XM-440 Relay module baud rate. You set the XM-440 Relay Master to 125kb, 250kb, 500kb, or Autobaud if another device on the network has set the baud rate.

Bit-Strobe

A multicast transfer of data sent by a master device to all the XM slaves on the network. The bit-strobe command message contains a bit string of 64 bits (8 bytes) of output data, one output bit per node address on the network.

bus off

A bus off condition occurs when an abnormal rate of errors is detected on the Control Area Network (CAN) bus in a device. The bus-off device cannot receive or transmit messages on the network. This condition is often caused by corruption of the network data signals due to noise or baud rate mismatch.

Change of State (COS)

DeviceNet communications method in which the XM module sends data based on detection of any changed value within the input data (alarm or relay status).

current configuration

The current configuration is the most recently loaded set of configuration parameters in the XM module's memory. When power is cycled, the current configuration is loaded with either the saved configuration (in EEPROM) or the factory defaults (if there is no saved configuration). In addition, the current configuration contains any configuration changes that have been downloaded to the module since power was applied.

DeviceNet network

A DeviceNet network uses a producer/consumer Controller Area Network (CAN) to connect devices (for example, XM modules). A DeviceNet network can support a maximum of 64 devices. Each device is assigned a unique node address (MAC ID) and transmits data on the network at the same baud rate.

A cable is used to connect devices on the network. It contains both the signal and power wires. General information about DeviceNet and the DeviceNet specification are maintained by the Open DeviceNet Vendor's Association (ODVA). ODVA is online at <http://www.odva.org>.

disarm state

See Program mode.

EEPROM

See NVS (Non-Volatile Storage).

Electronic Data Sheet (EDS) Files

EDS files are simple text files that are used by network configuration tools such as RSNetWorx for DeviceNet to describe products so that you can easily commission them on a network. EDS files describe a product device type, revision, and configurable parameters.

Help window

A window that contains help topics that describe the operation of a program. These topics may include:

- An explanation of a command.
- A description of the controls in a dialog box or property page.
- Instructions for a task.
- Definition of a term.

MAC ID

See node address.

master device

A device which controls one or more slave devices. The XM-440 Master Relay module is a master device.

node address

A DeviceNet network can have as many as 64 devices connected to it. Each device on the network must have a unique node address between 0 and 63. Node address 63 is the default used by uncommissioned devices. Node address is sometimes called "MAC ID."

NVS (Non-Volatile Storage)

NVS is the permanent memory of an XM module. Modules store parameters and other information in NVS so that they are not lost when the module loses power (unless Auto Save is disabled). NVS is sometimes called "EEPROM."

online help

Online help allows you to get help for your program on the computer screen by pressing **F1**. The help that appears in the Help window is context sensitive, which means that the help is related to what you are currently doing in the program.

Polled

DeviceNet communications method in which module sends data in response to a poll request from a master device.

Program mode

The XM module is idle. Typically this occurs when the module configuration settings are being updated with the XM Configuration program. In Program mode, the signal processing/measurement process is stopped, and the status of the alarms is set to the disarm state to prevent a false alert or danger status.

Run mode

In Run mode, the module collects measurement data and monitors each measurement device.

settling time

The amount of time it takes a measurement to reach 90% of the final value given a step change in the input signal.

slave device

A device that receives and responds to messages from a Master device but does not initiate communication. Slave devices include the XM measurement modules, such as the XM-120 Dynamic Measurement module and the XM-320 Position module.

Strobe

See Bit-Strobe.

transducer

A transducer is a device for taking measurements. These include accelerometers, velocity pickups, displacement probes, and temperature sensors.

trend

A set of records of one or more measurement parameter(s) collected at regular intervals of a base parameter such as time.

trigger

An event that prompts the collection of trend data.

triggered trend

A time-base trend that is collected in an XM module when a relay on the module is activated, or when the module receives a trigger event.

virtual relay

A virtual relay is a non-physical relay. It has the same capabilities (monitor alarms, activation delay, change status) as a physical relay only without any physical or electrical output. The virtual relay provides additional relay status inputs to a controller, PLC, or an XM-440 Master Relay module (firmware revision 5.0 and later).

XM configuration

XM configuration is a collection of user-defined parameters for XM modules.

XM Serial Configuration Utility software

XM Serial Configuration Utility software is a tool for monitoring and configuring XM modules. It can be run on computers running Windows 2000 service pack 2, Windows NT 4.0 service pack 6, or Windows XP operating systems.

Numerics

24V common grounding requirements 14

4-20mA Output Object 106

4-20mA output parameters 62

Enable 62

Max Range 62

Min Range 62

4-20mA outputs, wiring 29

A

Acknowledge Handler Object 98

Alarm Object 99

alarm parameters 55

Alert Threshold (High) 56

Alert Threshold (Low) 56

Condition 56

Danger Threshold (High) 56

Danger Threshold (Low) 56

Enable 55

Hysteresis 57

Name 55

Number 55

Startup Period 57

Threshold Multiplier 57

Analog Input Point Object 93

Assembly Object 87

Automatic Device Replacement (ADR) 80

B

baud rate 39

bit-strobe message format 79

C

channel parameters 46

Calibration Bias 48

Channel Name 46

DC Bias Time Constant 47

Eng. Units 46

Fault High 46

Fault Low 46

Measurement Mode 49

Mode 49

Output Data Unit 46

Sensitivity 46

Target Angle 47

Upscale 47

Channel Status indicator 42

Class Instance Editor 75

components

terminal base XM-940 3

XM-320 Position module 4

XM-441 Expansion Relay module 4

configuration parameters 45

4-20mA output parameters 62

alarm parameters 55

channel parameters 46

data parameters 66

device mode parameters 68

I/O data parameters 65

relay parameters 58

triggered trend parameters 63

connecting wiring 19

4-20mA outputs 29

DeviceNet 38

power supply 22

relays 23

remote relay reset signal 27

serial port 36

setpoint multiplication switch 29

short circuit protected outputs 26

terminal base XM-941 19

transducers 30

Connection Object 90

COS message format 78

D

data parameters 66

4-20mA Output A 66

4-20mA Output B 66

Alarm Status 67

Channel Status 66

Measurement Value 66

Relay Status 67

Transducer DC Bias 66

Transducer Fault 66

description

configuration parameters 45

terminal base XM-940 3

XM-320 module 4

XM-441 module 4

Device Mode Object 101

Device Mode parameter 68, 73

device mode parameters 68

Autobaud 68

Device Mode 68, 73

DeviceNet connection

- baud rate 39
- node address 39
- wiring 38

DeviceNet grounding requirements 14**DeviceNet information**

- automatic device replacement (ADR) 80
- EDS files 73
- I/O message formats 77
- invalid device configuration errors 76
- setting the Device Mode parameter 73
- XM services 75

DeviceNet Object 85**DeviceNet objects**

- 4-20mA Output 106
- Acknowledge Handler 98
- Alarm 99
- Analog Input Point 93
- Assembly 87
- Connection 90
- Device Mode 101
- DeviceNet 85
- Discrete Input Point 92
- Identity 84
- Parameter 95
- Relay 102
- Transducer 105

DIN Rail Grounding Block 11**DIN rail grounding requirements 10****Discrete Input Point Object 92****document conventions 5****E****Electronic Data Sheet (EDS) files 73****G****grounding requirements 10**

- 24V common 14
- DeviceNet 14
- DIN rail 10
- panel/wall mount 12
- switch input 15
- transducers 14

H**head-to-head mode 51****I****I/O data parameters 65**

- Assembly Instance Table 65
- COS Output 65
- COS Size 65
- Custom Assembly 65
- Poll Output 65
- Poll Response Assembly 65
- Poll Size 65

I/O message formats

- bit-strobe messages 79
- change of state (COS) messages 78
- poll messages 77
- XM status values 78

Identity Object 84**indicators 41**

- Channel Status 42
- Module Status 41
- Network Status 42
- Relay 42
- Setpoint Multiplier 42

installation requirements

- grounding 10
- power 8
- wiring 8

interconnecting terminal base units 17**introduction 1****invalid device configuration errors 76****K****keyswitch 39****M****modes**

- head-to-head 49, 51, 95
- normal 49, 95
- radial cancel 49, 54, 95

Module Status (MS) indicator 41**mounting**

- terminal base unit on DIN rail 15
- terminal base unit on panel/wall 18
- XM-320 module on terminal base 39

N**Network Status (NS) indicator 42****node address 39****normal mode 49**

normally closed relay contacts 23

normally open relay contacts 23

O

operating mode

program mode 41, 73

run mode 41, 73

P

panel/wall mount grounding requirements 12

Parameter Object 95

poll message format 77

power requirements 8

power supply, wiring 22

program mode 41, 73

R

radial cancel mode 54

relay contacts

normally closed 23

normally open 23

Relay indicator 42

Relay Object 102

relay parameters 58

Activation Delay 59

Activation Logic 59

Alarm A 59

Alarm B 59

Alarm Identifier A 59

Alarm Identifier B 59

Alarm Levels 60

Alarm Status to Activate On 60

Enable 58

Failsafe 61

Latching 59

Name 58

Number 58

Relay Installed 60

relays

resetting 27, 43

wiring 23

remote relay reset signal, wiring 27

reset switch 43

run mode 41, 73

S

self-test, status 43

serial port connection

mini-connector 37

terminal base unit 36

setpoint multiplication switch, wiring 29

Setpoint Multiplier indicator 42

short circuit protected output, wiring 26

specifications 69

switch input grounding requirements 15

T

terminal base

interconnecting units 17

mounting on DIN rail 15

mounting on panel/wall 18

terminal block assignment 20

transducer grounding requirements 14

Transducer Object 105

transducer wiring 30

cam potentiometer 33

linear variable differential transformer (LVDT) 32

non-contact sensor 30

non-contact sensor and LVDT 35

transition to program mode, DeviceNet 74

transition to run mode, DeviceNet 74

triggered trend parameters 63

Enable Triggered Trend Measurements 63

Latch Enable 63

Manual Trigger 64

Number of Records 63

Post Trigger 64

Record Interval 64

Relay Number 64

Reset Trigger 64

Select Measurements 63

Status 64

Trend Span 64

View Trend Data 64

W

wiring

to separate power connections 8

to terminal base 19

wiring connections

- 4-20mA outputs 29
- DeviceNet 38
- power supply 22
- relays 23
- remote relay reset signal 27
- serial port 36
- setpoint multiplication switch 29
- short circuit protected output 26
- transducers 30

wiring requirements 8

X

XM Services 75

XM status values 78

XM-320 I/O message formats 77

XM-320 Position Module

- components 3
- configuration parameters 45
- description 4
- grounding requirements 10
- indicators 41
- introduction 1
- mounting 39
- power requirement 8
- reset switch 43
- self-test 43
- specifications 69
- wiring requirements 8

XM-441 Expansion Relay Module 4, 44, 58

XM-941 terminal base

- description 3
- mounting 15
- wiring 19

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products. At <http://support.rockwellautomation.com>, you can find technical manuals, a knowledge base of FAQs, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnect support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://support.rockwellautomation.com>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your product up and running.

United States	1.440.646.3434 Monday – Friday, 8am – 5pm EST
Outside United States	Please contact your local Rockwell Automation representative for any technical support issues.

New Product Satisfaction Return

Rockwell Automation tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor in order to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication GMS110-UM005C-EN-P - May 2010

Supersedes Publication GMS110-UM005B-EN-E - March 2006

Copyright © 2010 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.