

LEVEL	I/O CAT. NO.	MODULE LABEL																	
UPPER	1794-IE8	I-0	V-0	I-1	V-1	I-2	V-2	I-3	V-3	I-4	V-4	I-5	V-5	I-6	V-6	I-7	V-7		
MIDDLE		V+	+V F0	+V F1	+V F2	+V F3	+V F4	+V F5	+V F6	+V F7	_____						COM	_____	
LOWER		_____							SH	_____							SH	_____	
UPPER	1794-IF4I	I-0	I-0 RET	V-0	V-0 RET	I-1	I-1 RET	V-1	V-1 RET	I-2	I-2 RET	V-2	V-2 RET	I-3	I-3 RET	V-3	V-3 RET		
MIDDLE		V+	+V F0	+V F1	+V F2	+V F3	+V F4	+V F5	+V F6	+V F7	_____						COM	_____	
LOWER		_____							SH	_____							SH	_____	
UPPER	1794-IF2XOF2I	IN I-0	I-0 RET	IN V-0	V-0 RET	IN I-1	I-1 RET	IN V-1	V-1 RET	OUT I-0	I-0 RET	OUT V-0	V-0 RET	OUT I-1	I-1 RET	OUT V-1	V-1 RET		
MIDDLE		V+	+V F0	+V F1	+V F2	+V F3	+V F4	+V F5	+V F6	+V F7	_____						COM	_____	
LOWER		_____							SH	_____							SH	_____	
UPPER	1794-IE4XOE2	IN I-0	IN V-0	IN I-1	IN V-1	IN I-1	IN V-2	IN I-3	IN V-3	OUT I-0	I-0 RET	OUT V-0	V-0 RET	OUT I-1	I-1 RET	OUT V-1	V-1 RET		
MIDDLE		V+	+V F0	+V F1	+V F2	+V F3	+V F4	+V F5	+V F6	+V F7	_____						COM	_____	
LOWER		_____							SH	_____							SH	_____	
UPPER	NUMERIC	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
MIDDLE		17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34
LOWER		35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52