

## SW2, SW2-US Auxiliary Switch Kit for HVAC Damper Actuators MNXX20, MNXX34, MSXX10, MSXX20

- D Montageanweisung
- DK Installasjonsinstruktus
- ES Instrucciones de Montaje
- F Instructions d'Installation
- I Istruzioni di Montaggio
- N Installations Instruktioer
- NL Installatievoorschrift
- S Installation Instruktioner
- FI Asennusohje

### INSTALLATION INSTRUCTIONS

<p><b>1</b></p> <p>100 Vac, 5 (3) A</p> <p>M25331</p>	<p><b>2</b></p> <p>M25332</p>	<p><b>3 (MSXX05, MSXX10, MSXX20)</b></p> <p>M25333</p>
<p><b>4</b></p> <p>100 Vac, 5 (3) A</p> <p>M25331</p>	<p><b>5</b></p> <p>24 V + 24 V ✓</p> <p>M25335</p>	<p><b>6</b></p> <p>M25336</p>
<p><b>7</b></p> <p>6 Nm</p> <p>M25337</p>	<p><b>8</b></p> <p>AS1 AS2</p> <p>A S3 S6 C B S1 S4 D C S2 S5 D</p> <p>0 45 90 0</p> <p>M25338</p>	<p><b>9 Setting AS1, AS2</b></p> <p>10-15</p> <p>M25339</p>



<p><b>10 Setting AS1 (e.g. to 30°)</b></p> <p>M25340</p>	<p><b>11</b></p> <p>M25341</p>	<p><b>12 Result (10 + 11)</b></p> <p>M25342</p>																																								
<p><b>13 Setting AS2 (e.g. to 75°)</b></p> <p>M25343</p>	<p><b>14</b></p> <p>M25344</p>	<p><b>15 Result (13 +14)</b></p> <p>M25345</p>																																								
<p><b>16</b></p> <p>M25346</p>	<table border="0"> <tr> <td>E</td> <td>result</td> <td>setting</td> <td>e. g. to</td> </tr> <tr> <td>D</td> <td>ergebnis</td> <td>eistellen</td> <td>z. b. auf</td> </tr> <tr> <td>DK</td> <td>resultat</td> <td>justering</td> <td>f. eks</td> </tr> <tr> <td>ES</td> <td>resultado</td> <td>ajuste</td> <td>e. g. en</td> </tr> <tr> <td>F</td> <td>résultat</td> <td>ajustement</td> <td>p. a. au</td> </tr> <tr> <td>I</td> <td>risultato</td> <td>aggiustaggio</td> <td>p. e. in</td> </tr> <tr> <td>N</td> <td>resultat</td> <td>justering</td> <td>f. eks</td> </tr> <tr> <td>NL</td> <td>resultat</td> <td>instellen</td> <td>b. v.</td> </tr> <tr> <td>S</td> <td>resultat</td> <td>inställning</td> <td>ex.</td> </tr> <tr> <td>FI</td> <td>tulos</td> <td>asetta</td> <td>esim</td> </tr> </table>	E	result	setting	e. g. to	D	ergebnis	eistellen	z. b. auf	DK	resultat	justering	f. eks	ES	resultado	ajuste	e. g. en	F	résultat	ajustement	p. a. au	I	risultato	aggiustaggio	p. e. in	N	resultat	justering	f. eks	NL	resultat	instellen	b. v.	S	resultat	inställning	ex.	FI	tulos	asetta	esim	
E	result	setting	e. g. to																																							
D	ergebnis	eistellen	z. b. auf																																							
DK	resultat	justering	f. eks																																							
ES	resultado	ajuste	e. g. en																																							
F	résultat	ajustement	p. a. au																																							
I	risultato	aggiustaggio	p. e. in																																							
N	resultat	justering	f. eks																																							
NL	resultat	instellen	b. v.																																							
S	resultat	inställning	ex.																																							
FI	tulos	asetta	esim																																							

**Automation and Control Solutions**

Honeywell International Inc.  
 1985 Douglas Drive North  
 Golden Valley, MN 55422  
 customer.honeywell.com

Honeywell Limited-Honeywell Limitée  
 35 Dynamic Drive  
 Toronto, Ontario M1V 4Z9

