


Features

- **Comfort series** •
- •
- 4 mm non-flush
- Usable up to SIL2 acc. to IEC 61508 •





BF 12 Mounting flange, 12 mm


Subject to modifications without notice Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1



Technical Data

loonnoul Butu		
General specifications		
Switching element function		NAMUR, NC
Rated operating distance	s _n	4 mm
Installation		non-flush
Output polarity		NAMUR
Assured operating distance	sa	0 3.24 mm
Reduction factor r _{Al}		0.4
Reduction factor r _{Cu}		0.3
Reduction factor r ₃₀₄		0.85
Nominal ratings		
Nominal voltage	U _o	8 V
Switching frequency	f	0 1500 Hz
Current consumption		> 0 m 4
Measuring plate not detected		≥ 3 mA
Measuring plate detected		≤ 1 mA
Ambient conditions		
Ambient temperature		-25 100 °C (-13 212 °F)
Mechanical specifications		
Connection type		cable PVC , 5 m
Core cross-section		0.34 mm ²
Housing material		PBT
Sensing face		PBT
Protection degree General information		IP68
Use in the hazardous area		see instruction manuals
Category		2G; 1D
Compliance with standards and directives		
Standard conformity		
NAMUR		EN 60947-5-6:2000
		IEC 60947-5-6:1999
Standards		EN 60947-5-2:2007 IEC 60947-5-2:2007
Approvals and certificates		
FM approval		
Control drawing		116-0165F
UL approval		cULus Listed, General Purpose
CSA approval		cCSAus Listed, General Purpose
CCC approval		Products with a maximum operating voltage of ≤36 V do not bear a CCC marking because they do not require approval.

ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Specific conditions

Protection from mechanical danger

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2009, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions $C \in 0102$

⟨€x⟩ II 2G Ex ia IIC T6 Gb

PTB 00 ATEX 2048 X NJ 4-12GK-N... ≤ 45 nF ; a cable length of 10 m is considered.

 \leq 50 μ H ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 $^\circ C$ the sensor should be protected from knocks by the provision of an additional housing.

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



ATEX 1D

Instruction

Device category 1D Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Maximum housing surface temperature

Installation, Comissioning

Maintenance

Specific conditions Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust 94/9/EG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions C€0102

 $\textcircled{\mbox{\sc bs}}$ II 1D Ex iaD 20 T 108 °C (226.4 °F) The Ex-relevant identification may also be printed on the accompanying adhesive label.

ZELM 03 ATEX 0128 X NJ 4-12GK-N...

 \leq 45 nF ; a cable length of 10 m is considered.

 \leq 50 μ H ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed.

The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

The intrinsically safe circuit has to be protected against influences due to lightning. When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

If the Ex-relevant identification is exclusively printed on the included adhesive label, this must be applied in the direct vicinity of the sensor! The surface to which the label is to applied must be clean and free from grease! The applied adhesive label must be durable adlegible to protect it against the possibility of chemical corrosion! No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

Subject to modifications without notice Pepperl+Fuchs Group

Pepperl+Fuchs Group USA: +1 33 www.pepperl-fuchs.com fa-info@us.pep

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



3