# **CE** 0102 c(N US

**Dimensions** 


#### **Model Number**

NJ5-30GK-S1N-10M

### Features

- 5 mm flush in ST37 / 1.0037
- Usable up to SIL 3 acc. to IEC 61508

#### Connection



#### Accessories

BF 30 Mounting flange, 30 mm

## Application

STOF

### Danger!

In safety-related applications the sensor must be operated with a qualified fail safe interface from Pepperl+Fuchs, such as KFD2-SH-EX1.

Consider the "exida Functional Safety Assessment" document which is available on www.pepperl-fuchs.com as an integral part of this product's documentation.

M30x1,5 **C** 

Technical Data		
General specifications		
Switching element function		NAMUR, NO
Rated operating distance	Sn	5 mm
Installation		flush in mild steel
Output polarity		Safety Function
Assured operating distance	sa	0 4.05 mm
Reduction factor r <sub>Al</sub>		1
Reduction factor r <sub>Cu</sub>		1
Reduction factor r <sub>304</sub>		0
Nominal ratings		
Nominal voltage	Uo	8 V
Switching frequency	f	0 150 Hz
Suitable for 2:1 technology		yes, with reverse polarity protection diode
Current consumption		
Measuring plate not detected		≤ 1 mA
Measuring plate detected		≥ 3 mA
Ambient conditions		
Ambient temperature		-25 100 °C (-13 212 °F)
Mechanical specifications		
Connection type		cable silicon , 10 m
Core cross-section		0.75 mm <sup>2</sup>
Housing material		PP
Sensing face		PP
Protection degree		IP68
Note		only for non-ferrous metal
General information		
Use in the hazardous area		see instruction manuals
Category		1G; 2G; 1D
Compliance with standards and di	rectives	6
Standard conformity		
Standards		EN 60947-5-2:2007
		IEC 60947-5-2:2007
Approvals and certificates		
UL approval		cULus Listed, General Purpose
CSA approval		cCSAus Listed, General Purpose
CCC approval		Products with a maximum operating voltage of $\leq$ 36 V do not bear a
		CCC marking because they do not require approval.

Subject to modifications without notice Pepperl+Fuchs Group

www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



ATEX 1G	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1G	
Directive conformity	for use in hazardous areas with gas, vapour and mist 94/9/EG
Directive conformity Standard conformity	94/3/EG EN 60079-0:2009, EN 60079-11:2007, EN 60079-26:2007
Standard contorning	Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
CE marking	C € 0102
Ex-identification	₪ II 1G Ex ia IIC T6 Ga
EC-Type Examination Certificate	PTB 00 ATEX 2049 X
Appropriate type	NJ 5-30GK-S1N
Effective internal capacitance C <sub>i</sub>	$\leq$ 100 nF ; a cable length of 10 m is considered.
Effective internal inductance Li	$\leq$ 200 $\mu H$ ; a cable length of 10 m is considered.
Cable length	Dangerous electrostatic charges on the fixed connection cable must be taken into account for lengths equal to and exceeding the following values:
Explosion group IIA	69 cm
Explosion group IIB	34 cm
Explosion group IIC	5 cm
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!
Highest permissible ambient temperature	The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Specific conditions	
Protection from mechanical danger	When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charging

When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



#### ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance Ci Effective internal inductance Li General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

#### Specific conditions

Protection from mechanical danger

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2009, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions €0102

⟨€x⟩ II 1G Ex ia IIC T6 Ga

PTB 00 ATEX 2049 X

NJ 5-30GK-S1N...

 $\leq$  100 nF; a cable length of 10 m is considered.

 $\leq$  200  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20  $^{\circ}\text{C}$  the sensor should be protected from knocks by the provision of an additional housing.

Subject to modifications without notice

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com



## ATEX 1D

Instruction

Device category 1D Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C<sub>i</sub> Effective internal inductance L General

Maximum housing surface temperature

Installation, Comissioning

Maintenance

Specific conditions Electrostatic charging NJ5-30GK-S1N-10M

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust 94/9/EG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions **C**€0102

(Ex) II 1D Ex iaD 20 T 108 °C (226.4 °F)

The Ex-significant identification is on the enclosed adhesive label ZELM 03 ATEX 0128 X

NJ 5-30GK-S1N...

 $\leq$  100 nF ; a cable length of 10 m is considered.

 $\leq$  200  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed.

The special conditions must be adhered to! The maximum surface temperature of the housing is given in the EC-Type Exami-

nation Certificate

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

The intrinsically safe circuit has to be protected against influences due to lightning. When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use

Subject to modifications without notice USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

