








Model Number

SJ3,5-H-Y17012


Features


- **Comfort series**
- 3.5 mm slot width

Connection



Dimensions





Technical Data

General specifications Switching element function NAMUR, NC Slot width 3.5 mm Depth of immersion (lateral) 5 ... 7 typ. 6 mm Installation Output polarity NAMUR

Nominal ratings

Nominal voltage 8 V Operating voltage Switching frequency 5 ... 25 V 0 ... 3000 Hz UB Hysteresis 0.8 ... 1.1 mm Current consumption Measuring plate not detected \geq 3 mA

Measuring plate detected \leq 1 mA

Ambient conditions

Ambient temperature -25 ... 70 °C (-13 ... 158 °F) Mechanical specifications

Connection type flexible leads PTFE, 500 mm Core cross-section 0.14 mm² PBT

Housing material Protection degree IP67 General information

Use in the hazardous area

see instruction manuals 2G

Category Compliance with standards and directives

Standard conformity

NAMUR EN 60947-5-6:2000

EN 60947-5-2:2007 IEC 60947-5-2:2007 Standards

Approvals and certificates

UL approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose

ATEX 2G

Instruction

Device category 2G

Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance Ci Effective internal inductance L

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Specific conditions

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2009, EN 60079-11:2007 Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions €0102

⟨ II 2G Ex ia IIC T6 Gb

PTB 99 ATEX 2219 X

SJ3,5-H..

 \leq 50 nF ; a cable length of 10 m is considered.

 \leq 250 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

www.pepperl-fuchs.com