

Tap RS-TPR-Ex

Coax right-angle "T"-Tap
Cable length 1 m



Tap RS-TPS-Ex

Coax straight "T"-Tap
Cable length 1 m



Tap RS-TPYR-Ex

Coax right-angle "Y"-Tap
Cable length 1 m



Tap RS-TPYS-Ex

Coax straight "Y"-Tap
Cable length 1 m



Dummy Node RS-TCAP-Ex

is connected instead of the ControlNet gateway to a tap which is intended for expansion at a later date.



ControlNet Termination Resistor RS-FT-Ex

is required at the end of each bus branch.

