

Installation and Operating Instructions

Bulletin 440P-WM4 Metal Spring Rod

IMPORTANT: SAVE THESE INSTRUCTIONS FOR FUTURE USE.

This publication does not include all specifications, dimensions, or any special installation considerations.
Refer to the product catalog pages for additional information.



ATTENTION: To avoid electrical shock and unintended operation of equipment, disconnect all power to the limit switch and the controlled equipment before proceeding with any repair or adjustment of the limit switch.


General Data

- Designed for 440P-M metal spring rod limit switches
- Spring rod diameter 11 mm (0.43 in.)
- Spring rod length 113 mm (4.45 in.)

Principles, Standards and Implementation

Operating specifications must be followed. Actuators should be displaced beyond the point where direct opening action occurs. If adjustable actuators become loose they may defeat the direct opening action feature of the limit switch. These devices are not to be used to directly control a motor.

IMPORTANT: Installation of Allen-Bradley limit switches should be in accordance with local and/or national codes. Servicing energized industrial control equipment can be hazardous if not in accordance to recommended safety procedures.




Metal spring rod shown installed.



ATTENTION: Operator heads with adjustable actuators should **NOT** be used for safety applications.


Approximate Dimensions [mm (in.)]



Instructions

1. Remove old spring rod by holding the rubber gasket at the base of the spring rod and turning the spring rod counter-clockwise.
2. Thread the replacement spring rod onto the threaded post shaft extending vertically from the operator head.
3. While holding the rubber gasket at the base of the spring rod torque the spring rod clockwise to 1...1.4 N·m (8.85...12.39 lb·in).

Mounting Dimensions [mm (in.)]



ATTENTION: Under no circumstances must the switch be actuated beyond the mechanical travel specified. Serious damage to the device and property could result.

Maintenance

These devices require little maintenance, but routine visual inspection is recommended to keep foreign debris from collecting on the exterior actuators and rollers.

Removing the operator head is not recommended as loose internal components may be lost or improperly re-installed.

Actuation Guidelines

The method of actuation and over travel has significant influence on the service life of the limit switch. To maximize the service life, it is recommended to provide an actuator with a 30° pressure angle and a surface hardness of RC-45 max.

Torque Specifications

Location	Torque
Metal spring rod	1...1.4 N·m (8.85...12.39 lb·in)

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
 Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
 Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846