(E 0102


Model Number

NJ6-22-N-388-10M


Features

- Comfort series
- 6 mm embeddable

Connection



Dimensions



_				
10	ch	nic	วเ เ)ata
10	CII		aı L	<i>r</i> ata

Category

General specifications				
Switching element function		NAMUR NC		
Rated operating distance s _n		6 mm		
Installation		embeddable		
Output polarity		NAMUR		
Assured operating distance s _a		0 4.86 mm		
Reduction factor r _{Al}		0.4		
Reduction factor r _{Cu}		0.3		
Reduction factor r _{V2A}		0.85		
Nominal ratings				
Nominal voltage	Uo	8 V		
Switching frequency	f	0 2000 Hz		
Hysteresis H		typ. %		
Current consumption				
Measuring plate not detected		≥ 3 mA		
Measuring plate detected		≤ 1 mA		
Standard conformity				
EMC in accordance with		IEC / EN 60947-5-2:2004		
Standards		DIN EN 60947-5-6 (NAMUR)		
Ambient conditions				
Ambient temperature		-25 100 °C (248 373 K)		
Mechanical specifications				
Connection type		10 m, PVC cable		
Core cross-section		0.75 mm ²		
Housing material		steel, nickel-plated		
Sensing face		PBT		
Protection degree		IP68		
General information				
Use in the hazardous area		see instruction manuals		

2G

ATEX 2G

Instruction

Device category 2G

Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate

Appropriate type

Effective internal capacitance Ci

Effective internal inductance Li

General

Highest permissible ambient temperature

Installation Comissioning

Maintenance

[Fett]Special conditions

Protection from mechanical danger

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

EN 50014:1997, EN 50020:1994 Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions € €0102

⟨Ex⟩ II 2G EEx ia IIC T6

PTB 00 ATEX 2048 X

NJ 6-22-N...

≤ 130 nF; a cable length of 10 m is considered.

 $\leq 100~\mu H$; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of $\! > \! 60~^\circ \text{C}$ was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20°C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges on the metal housing components must be avoided. Dangerous electrostatic charges on the metal housing components can be avoided by incorporating these components in the equipotential bonding.