	Technical data	Technical data		
-	General specifications			
	Sensing range	250 2500 mm		
	Adjustment range	250		
		200 2000 mm		
	Standard target plate	100 mm x 100 mm		
	Transducer froquency			
	Nominal ratings	αρμισλ. του κτις		
	Time delay before availability t	050 mg		
		250 ms		
		000		
	Permissible cable length	max. 300 m		
	Indicators/operating means	-		
	LED green	Power on		
	LED yellow 1	solid: switching state switch output 1		
		nasning: misaajustment		
	LED yellow 2	solid: switching state switch output 2		
	Electrical specifications			
	Bated operational voltage LL	24 \/ DC		
c Us		12 20 V (including ripplo)		
	Operating voltage 0B	In supply voltage interval 12 20 V reduced sensitivity by		
	Bipple	< 10 %		
Model Number	No-load supply current la	< 60 mA		
	Input			
UC2500-F65-E8R2-V15	Input type	1 program input		
	input type	Teach-In of Smin		
Features	Input voltage			
a loval indiastics		\Rightarrow Operating voltage		
 Level indication 	Levei	high level : 0 5 V (Teach-IN active)		
2 switch outputs	Pulse length	> 150 ms		
- onnon outputo	Output			
Program input	Output type	2 switch outputs PNP NO		
D	Bated operational current I	150 mA short circuit/overload protected		
 Programmable by means of Inter- 	Default actting	Switching dictance "full" S is 20 mm		
face (see accessories) and SON-	Delault setting	Switching distance "ampty" C + 450 mm		
PROG		Switching distance empty, S _{min} : 450 mm		
Synchronization options		Switching hysteresis "full", H _{Smax} : 100 mm		
• Synchronization options		Switching hysteresis "empty", H _{Smin} : 200 mm		
 Temperature compensation 		average value "full", M _{Smax} : 20		
		average value "empty", M _{Smin} : 110		
Diagrama	Voltage drop U _d	\leq 3 V		
Diagrams	Switch-on delay t _{on}	200 ms		
	Repeat accuracy	±5 mm		
Characteristic response curve	Off-state current Ir	0.01 mA		
	Temperature influence	≤±1.5 %		
Distance V [mm]	Ambient conditions			
	Ambient temperature	-25 70 °C (-13 158 °F)		
500	Storage temperature	-40 85 °C (-40 185 °F)		
400	Shock resistance	30 g , 11 ms period		
300	Vibration resistance	10 55 Hz , Amplitude ± 1 mm		
200	Mechanical specifications			
	Connection type	Device connector M12 x 1 , 5-pin		
-100 2 1	Protection degree	IP65		
-200	Material			
-300	Housing	PBT		
-400	Transducer	epoxy resin/hollow glass sphere mixture; polyurethane foam		
-500	Installation position	any position		
0 500 1000 1500 2000 2500 3000 3500 4000 4500 5000	Mass	500 g		
Distance X [mm]	Compliance with standards and			
	directives			
∠ × X	Standard conformity			
	Standards	EN 60947-5-2:2007		
Curve 1: flat surface 100 mm x 100 mm		IEC 60947-5-2:2007		
Guive 2. IOuliu Dai, Ø 23 MM				
	Approvals and certificates			
	UL approval	cULus Listed, General Purpose		
	CSA approval	cCSAus Listed, General Purpose		

Subject to reasonable modifications due to technical advances.

Copyright Pepperl+Fuchs, Printed in Germany

Dimensions



Electrical Connection



Pinout



Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)
5	GY	(gray)

Subject to reasonable modifications due to technical advances.

Copyright Pepperl+Fuchs, Printed in Germany

Function of the switching outputs



Accessories

V15-G-2M-PUR

Cable socket, M12, 5-pin, PUR cable

V15-G-2M-PVC Cable socket, M12, 5-pin, PVC cable

V15-W-2M-PUR Cable socket, M12, 5-pin, PUR cable

V15-W-2M-PVC

Cable socket, M12, 5-pin, PVC cable

3RX4000-PF PC interface

Applications

The design and functionality makes this sensor best suitable for level detection applications in small containers or tanks. The device provides 2 switching outputs Q1 (Smin) and Q2 (Smax). Special distances can be assigned to each of them - e. g. the minimum and maximum levels in a tank can be evaluated and displayed. The parameters can be programmed with SONPROG or with an automatic setup (Teach-In).

Mounting and Connection

All parts are accommodated in a fully enclosed housing. The ultrasonic transducer is set back in the housing, so it is protected. Because of the built-in sealing the sensor can be used as a closure with integrated level detection. The opening of the tank must have a diameter of 26 mm. The sensor is fixed by means of two M5 screws. The sensor has a 5 pin M12 x 1 connector. The BERO has built-in polarity reversal as well as short-circuit and overload protection. Where there is electrical interference, shielded cables are recommended.

Setup

The two ranges, the associated hysteresis and the average value are preset at the factory (see technical data). The parameters can be programmed with SONPROG or with an automatic setup (teach-in). Teach-in can be done by means of the keys of the interface (accessories) or the function input XI.

Automatic Setup (Teach-in)

- With this function the minimum level Smin can be set. The following steps must be performed in the correct order:
- 1. Fill the tank up to the required minimum level or place an object at the required distance.
- 2. Apply "low" signal (0 to 3 V) to the function input XI e.g. connect XI via a key to 0 V, or connect it via a PLC to "LOW"). The LED "Smin" flashes, then. The sensor is disabled; it's learning the distance. The signal duration must be at least 150 ms.
- 3. Remove signal from XI e.g. disconnect it from the function input XI, connect it to +UB or connect it via a PLC to "HIGH").
- Important! As long as the function input XI is connected to "low", the sensor is disabled.

SONPROG

With SONPROG the following parameters can be programmed:

- Start or end of both switching ranges Smin and Smax
- Hysteresis (HS_{max}, HS_{min})
- . Blind zone
- Sensing range
- Average value
- Switching output Smin NC / NO

Customer specific programming is available on request.

Operation

The level of liquid inside a tank is detected within the sensing range. If the level reaches one of the two switching levels (S_{min}, S_{max}), then the corresponding output will be set active. Both switching levels are equipped with a switching hysteresis (HS_{min}, HS_{max}). The switching status of each output is indicated by the corresponding yellow LED. If the filling level is in between the 2 switching levels, both of the outputs are in off state.

Objects inside the blind zone will cause error signals. Therefore the user has to mount the sensor that way that the level cannot be inside the blind zone.