Bulletin 1609-U Industrial Uninterruptible Power Supply

			- ,
Spe	cific	atic	n

Ele	ectrical Ratings	1609-U500N	1609-U500E	Notes			
	V nom.	120V	230V	_			
Input	Capacity	500VA (325 W)		Transfer points adjustable via software. Low transfer points for the 120V/230V are: 106V, 103V, 100V, 97V and 208V, 200V, 192V respectively. High transfer points for the 120V/230V are: 127V, 130V, 133V, 136V and 253V, 257V, 261V, 265V respectively.			
	Voltage Range, default	81143V	160287V	Transfer points adjustable via software.			
	Voltage Range, widest, on line	75153V	150300V	-			
	Current nom.	4.12 A	2.20 A	_			
	Capacity Frequency	4763 Hz		Auto-adjusting			
	PFC	Load power factor is reflected in the input line current		_			
• • •	V nom.	120V 208/230V		_			
Output	Capacity	500VA (325 W)		_			
On Line	Output Range, default	106127V	208253V	This voltage range is the default, controlled by transfer points coded in the UPS			
	Output Voltage Range, widest	97136V	196265V	By setting the highest, high transfer point and the lowest, low transfer point with software			
	Transfer Point Accuracy	+/- (2% of the transfer voltage + 1.3)	+/- (2% of the transfer voltage + 2.6)	In volts AC			
	Frequency	Nominal +/- 3 Hz (Locked), Nominal +/- 0.5 Hz (Free-running) +/- 2%		Typical			
On Battery	THD	<5% at full (line	ear) load +/- 2%	Typical			
	Crest Factor	3:	:1	_			
Efficiency	On Battery	77%		Typical with resistive load			
Enciency	On Line	96	5%	Typical with resistive load			
Protection	Surge	EN50091-2		_			
	Overload	On Line: alarm at 107%, limited by breakers On Battery: shutdown at 107%		-			
	Output Short On Line	Input circuit breakers and/or premises branch protection		—			
	Output Short On Battery	Electric current limit, shutdown outputs, and latch off		_			
	Thermal Protection	None		-			
	Bypass	N/A		—			
Regulatory	Safety	UL 1778, CSA, IEC 60950	UL 1778, CSA, IEC 60950-1, EN50091-1-1	-			
	EMC	FCC (Class A)	EN50091-2 (Class A)	_			
	Markings	UL, CSA, FCC, CE	UL, CSA, FCC, CE	_			
	Bun Time	9.0 minutes (0.67 p.f.) 18 minutes (0.67 p.f.)		325 W full load			
				163 W half load			
	Туре	Standard: Sealed Lead Acid, valve regulated High Temp.: Sealed Lead Battery		Hot swappable, user replaceable			
Dattery Pack	Voltage	24V		—			
	Charger	Temperature compensated current limited, float charger		_			
	Recharge Time	Less than 3 hours to 90% capacity		—			
	Lifetime	24 years @ 25 °C ambient		—			
Environment	Temperature	040 °C (operating), 050 °C (operating - high temp. option) -2060 °C (short-term storage)		-			
	Altitude	10 000 ft (operating)		Maximum power is derated at higher altitudes			
	Humidity	095% non-condensing (operating)					
	Heat Output	On Line, Full Load: 137 BTU per hour On Line, Full Load, Charging: 190 BTU per hour On Battery, Full Load: 1706 BTU per hour		_			
	Audible Noise	<45 dB @ 1 meter (full load)		Typical			
Communication	DB9	Serial and Contact Closures		Serial communication only when USB is unused			
	Dry Contact	Low battery, on battery		N.O., N.C. options for both			
	EPO	Via Dry Contact Closure		_			
	Network	Via optional Smart-Slot Card (1609-NMC)					
	• Wiring of the LIPS should be performed by a gualified electrician. Use appropriate size wires						

should be performed by a qualified electrician. Use appropriate size wires.

ATTENTION • In 230V AC applications, the UPS must be protected with a circuit breaker that complies with European standards for branch rated protection per the country of installation.

- In 208V AC applications, the 1609-U500E must be protected by a dual-pole, 10 A branch rated, UL 489 circuit breaker. • The 120V AC 1609-U500N has supplementary circuit breaker protection. The unit should be protected by a single-pole, 15 A branch rated, UL 489 circuit breaker.
 - Allen-Bradley part number 1492-MCAA115 is suggested.
- The branch circuit breaker must be off prior to wiring the unit.

Note

208V AC applications: The 1609-U500E ships ready for 230V AC sources. When operating the UPS in 208V AC applications, the UPS low transfer voltage settings are adjusted through the PowerChute® software or the Network Management Card.

Refer to the PowerChute® User Guide or the Network Management Card instructions for details.



Allen-Bradley