




# **Model Number**

# PL2-F25-N4-S

# **Features**

- For installation in housing
- PL2... without valve connection
- Screw terminals

# Connection



## **Accessories**

BT32

Activator for F25 series

BT32XS

Activator for F25 series

BT32XAS

Activator for F25 series


**BT33** 

Activator for F25 series

BT34

Activator for F25 series

## **Dimensions**



# **Technical Data**

General specifications		
Switching element function		DC Dual NC
Rated operating distance	s <sub>n</sub>	3 mm
Installation		embeddable mountable
Output polarity		NAMUR
Assured operating distance	sa	0 2.43 mm
Reduction factor r <sub>Al</sub>		0.5
Reduction factor r <sub>304</sub>		1
Reduction factor r <sub>St37</sub>		1.2
Nominal ratings		
Nominal voltage	Uo	8.2 V ( $R_i$ approx. 1 k $\Omega$ )
Operating voltage	UB	5 25 V
Switching frequency	f	0 100 Hz
Hysteresis	Н	typ. 5 %
Reverse polarity protected		reverse polarity protected
Short-circuit protection		yes
0		

Current consumption Measuring plate not detected ≥ 3 mA Measuring plate detected ≤ 1 mA No-load supply current Indication of the switching state ≤ 3 mA LED, yellow

Ambient conditions

-25 ... 100 °C (-13 ... 212 °F) -40 ... 100 °C (-40 ... 212 °F) Ambient temperature Storage temperature

Mechanical specifications

Connection type screw terminals Core cross-section (system side) up to 2.5 mm<sup>2</sup> Housing material PBT

PBT Sensing face Note Installation in housing

**General information** 

Use in the hazardous area see instruction manuals 1G; 2G Category

Compliance with standards and directives

Standard conformity

EN 60947-5-6:2000 NAMUR

Electromagnetic compatibility NE 21:2007

www.pepperl-fuchs.com

Type code: PL2-F25-N4-S

Printed circuit boards PL2-F25-N4-S

PL2 Without valve connection

PL2-F25-N4-S Sensor type

> F25 proximity switch Standard series F25

Electrical design PL2-F25-N4-S

> N4 Electrical design according to EN 50227

Connection method PL2-F25-N4-S

> S Pluggable screw

## ATEX 1G

Instruction

Device category 1G

Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance  $C_i$ 

Effective internal inductance L<sub>i</sub>

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

## Special conditions

Protection from mechanical danger

Electrostatic charging

Lead insertion

### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2006, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions

**C**€0102

⟨ II 1G Ex ia IIC T6

TÜV 99 ATEX 1479 X

PL.-F25.-N4...

 $\leq$  100 nF A cable length of 10 m is considered. The value is applicable for the sensor circuit.

 $\leq$  100  $\mu H$  A cable length of 10 m is considered.

The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed. The special conditions

must be adhered to!
Directive 94/9/EG and hence also EC-Type Examination Certificates apply in gene-

ral only to the use of electrical apparatus under atmospheric conditions.

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20  $^{\circ}\text{C}$  the sensor should be protected from knocks by the provision of an additional housing.

When used in group IIB/IIC non-permissible electrostatic charges should be avoided on the plastic housing parts..

The connection cables should either be fixed when laid and mechanically protected or installed in such a way, that a force of 30 N applied in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11. Depending on the type of installation, a suitable cable in accordance with Type A oder B of IEC 60079-14, must be used.

www.pepperl-fuchs.com

#### ATEX 2G

Instruction

#### Device category 2G

Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate

Appropriate type

Effective internal capacitance Ci

Effective internal inductance L

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

#### Special conditions

Protection from mechanical danger

Electrostatic charging

Lead insertion

## Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2006, EN 60079-11:2007 Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions **C**€0102

(Ex) II 1G Ex ia IIC T6

TÜV 99 ATEX 1479 X

PL.-F25.-N4...

≤ 100 nF; a cable length of 10 m is considered. The value is applicable for the sensor circuit.

 $\leq 100~\mu H$  ; a cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions

The use in ambient temperatures of > 60  $^{\circ}\text{C}$  was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible

When used in the temperature range below -20  $^{\circ}$ C the sensor should be protected from knocks by the provision of an additional housing.

When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts

The connection cables should either be fixed when laid and mechanically protected or installed in such a way, that a force of 30 N applied in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11. Dependent ding on the type of installation, a suitable cable in accordance with Type A oder B of IEC 60079-14, must be used.