
Inductive proximity switches




CE

| eneral specifications | |
|---|--------------------------|
| Switching element function | NAMUR NC |
| Rated operating distance s _n | 1.5 mm |
| Installation | embeddable |
| Assured operating distance sa | 0 1.215 mm |
| Reduction factor r _{AI} | 0.22 |
| Reduction factor r _{Cu} | 0.19 |
| Reduction factor r _{V2A} | 0.65 |
| Nominal ratings | |
| Nominal voltage U _o | 8 V |
| Switching frequency f | 0 5000 Hz |
| Hysteresis H | typ. 5% |
| Current consumption | |
| Measuring plate not detected | ≥ 3 mA |
| Measuring plate detected | ≤ 1 mA |
| Standard conformity | |
| EMC in accordance with | IEC / EN 60947-5-2:2004 |
| Standards | DIN EN 60947-5-6 (NAMUR) |
| Ambient conditions | |
| Ambient temperature | -25 70 °C (248 343 K) |
| Mechanical specifications | |
| Connection type | 110 mm lead PVC |
| Core cross-section | 0.14 mm ² |
| Housing material | Stainless steel |
| Sensing face | PBT |
| Protection degree | IP67 |
| General information | |
| Use in the hazardous area | see instruction manuals |
| Category | 2G |

Connection type:





PEPPERL+FUCHS GmbH

Inductive proximity switches

ATEX 2G

Instruction

Device category 2G Directive conformity

Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

[Fett]Special conditions Protection from mechanical danger

Electrostatic charging

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 50014:1997, EN 50020:1994 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions $C \in 0.002$

⟨€x⟩ II 2G EEx ia IIC T6

PTB 00 ATEX 2048 X NJ 1,5-6,5...-N... ≤ 30 nF ; a cable length of 10 m is considered.

 \leq 50 µH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EU prototype test certificate must be observed. The special conditions must be adhered to!

Directive 94/9EG and hence also EU prototype test certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EU prototype test certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20°C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

2006-01-26 - 106349_ENG.xm

Copyright Pepperl+Fuchs, Printed in Germany

PEPPERL+FUCHS GmbH