

CE 0102


Model Number


SJ3,5-N-Y40853

Features

- Comfort series
- 3.5 mm slot width

Connection





Technical Data

Dimensions

| General specifications | |
|------------------------------|----|
| Switching element function | |
| Slot width | |
| Depth of immersion (lateral) | |
| Installation | |
| Output polarity | |
| Nominal ratings | |
| Nominal voltage | Uo |
| Operating voltage | UB |
| Switching frequency | f |
| Hysteresis | н |
| Current consumption | |
| Measuring plate not detected | |
| Measuring plate detected | |
| Standard conformity | |
| EMC in accordance with | |
| Standards | |
| Ambient conditions | |
| Ambient temperature | |
| Mechanical specifications | |
| Connection type | |
| Core cross-section | |
| Housing material | |
| Protection degree | |
| General information | |
| Use in the hazardous area | |

Category

| NA | MU | JR, M | 1C |
|-----|----|-------|-----|
| 3.5 | mr | n | |
| 5 | 7 | tvn | 6 m |

5 ... 7 typ. 6 mm NAMUR

| 8 V |
|-------------|
| 5 25 V |
| 0 3000 Hz |
| 0.41 0.6 mm |

≥ 3 mA ≤ 1 mA

IEC / EN 60947-5-2:2004 DIN EN 60947-5-6 (NAMUR)

-25 ... 100 °C (-13 ... 212 °F)

flexible leads LIY , 500 mm 0.14 mm² PBT/PPS IP67

see instruction manuals 2G



ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Special conditions

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 50014:1997, EN 50020:1994 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions €0102

⟨€x⟩ II 2G EEx ia IIC T6

PTB 99 ATEX 2219 X SJ3,5-...-N... \leq 50 nF ; a cable length of 10 m is considered. \leq 250 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

