
# Inductive proximity switches


### Comfort series



# **(** € 0102

General specifications	
Switching element function	NAMUR NC
Slot width	5 mm
Depth of immersion (lateral)	4 6 typ.
Installation	
Nominal ratings	
Nominal voltage U <sub>o</sub>	8 V
Operating voltage U <sub>B</sub>	5 25 V
Switching frequency f	0 2000 Hz
Hysteresis H	0.05 0.65 mm
Current consumption	
Measuring plate not detected	≥ 3 mA
Measuring plate detected	≤ 1 mA
Standard conformity	
EMC in accordance with	IEC / EN 60947-5-2:2004
Standards	DIN EN 60947-5-6 (NAMUR)
Ambient conditions	
Ambient temperature	-25 100 °C (248 373 K)
Mechanical specifications	
Connection type	165 mm, flexible lead LIY
Core cross-section	0.14 mm <sup>2</sup>
Housing material	PBT
Protection degree	IP67
General information	
Use in the hazardous area	see instruction manuals
Category	2G

## Connection type:



## Inductive proximity switches

Instruction

#### Device category 2G

Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance Ci Effective internal inductance Li

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

[Fett]Special conditions

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

EN 50014:1997, EN 50020:1994 Ignition protection "Intrinsic safety"

Use is restricted to the following stated conditions

€0102

(Ex) II 2G EEx ia IIC T6

PTB 99 ATEX 2219 X

SJ5-...-N...

≤ 50 nF; a cable length of 10 m is considered.  $\leq$  250  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EU prototype test certificate must be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EU prototype test certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.