


# **Model Number**

RJ15-14-N-5M


# **Features**

- 15 mm inside diameter
- **Comfort series**

# Connection



# **Dimensions**



16	eci	1111	Cai	ט	ื่ลเล	

General specifications						
Switching element function	NAMUR, NC					
Installation						
Output polarity	NAMUR					
Inside diameter	15 mm					
Measuring cylinder	9S20K					
Diameter	3 mm					
Length	4 mm					

Nominal ratings							
Nominal voltage	$U_o$	8 V					
Operating voltage	UB	5 25 V					
Switching frequency	f	0 1500 Hz					
Current consumption							

Measuring plate not detected  $\geq$  3 mA Measuring plate detected ≤ 1 mA

**Ambient conditions** -25 ... 70 °C (-13 ... 158 °F) Ambient temperature Mechanical specifications

cable PVC , 5 m Connection type Core cross-section 0.14 mm<sup>2</sup> PBT Housing material Protection degree IP67 General information

Use in the hazardous area see instruction manuals Category

Compliance with standards and directives

Standard conformity NAMUR EN 60947-5-6:2000 IEC 60947-5-6:1999 Standards EN 60947-5-2:2007

Approvals and certificates

UL approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose

IEC 60947-5-2:2007

www.pepperl-fuchs.com

### ATEX 2G

Instruction

### Device category 2G

Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance Ci Effective internal inductance L

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Specific conditions

### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2009, EN 60079-11:2007 Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions €0102

⟨ II 2G Ex ia IIC T6 Gb

PTB 99 ATEX 2128 X

RJ15-...-N...

 $\leq$  130 nF; a cable length of 10 m is considered.

 $\leq$  20  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.