

 (\mathbf{m})

CE

Model Number

NJ5-18GM50-E2-3G-3D

Features

- 5 mm flush
- ATEX-approval for zone 2 and zone 22

Connection



Δ	C	c	ρ	s	s	n	ri	e	<
~	5			9	Э	U		C	5

BF 18 Mounting flange, 18 mm EXG-18 Quick mounting bracket with dead stop **Dimensions**



Technical Data

General specifications			
Switching element function		PNP	NO
Bated operating distance	S.	5 mm	
Installation	Sn	flush	
Output polarity		DC	
Assured operating distance	Se	0 4.05 mr	m
Reduction factor r	-a	0.2	
Reduction factor rou		0.15	
Reduction factor r ₃₀₄		0.62	
Nominal ratings			
Installation conditions			
А		0 mm	
В		0 mm	
С		15 mm	
Operating voltage	UB	10 60 V D)C
Switching frequency	f	0 1500 H	Z
Hysteresis	Н	1 15 typ.	6 %
Reverse polarity protected		reverse pola	arity protected
Short-circuit protection		pulsing	
Voltage drop	Ud	≤ 3 V	
Operating current	۱L	0 200 mA	
Lowest operating current	Im	0 mA	
Off-state current	l _r	0 0.5 mA	typ. 0.01 mA
No-load supply current	I ₀	≤9 mA	
Indication of the switching state		LED, yellow	
Functional safety related parameter	ers		
MTTF _d		1100 a	
Mission Time (T _M)		20 a	
Diagnostic Coverage (DC)		0 %	
Ambient conditions			
Ambient temperature		-25 70 °C	; (-13 158 °F)
Storage temperature		-40 85 °C	; (-40 185 °F)
Mechanical specifications			
Connection type		cable PVC ,	, 2 m
Core cross-section		0.5 mm ²	
Housing material		Stainless ste	eel 1.4305 / AISI 303
Sensing face		PBI	
Protection degree		IP67	
General information			
Use in the hazardous area		see instructi	ion manuals
Category		3G; 3D	
Compliance with standards and di	rective	S	
Standard conformity			
Standards		EN 60947-5	-2:2007
		IEC 60947-5	5-2:2007
Approvals and certificates			
UL approval		cULus Liste	d, General Purpose
CSA approval		cCSAus List	ted. General Purpose
CCC approval		Certified by	China Compulsory Certification (CCC)

Subject to modifications without notice Pepperl+Fuchs Group

USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



ATEX 3G (nA) Instruction

Instruction

Device category 3G (nA) Directive conformity Standard conformity

CE symbol

Ex-identification

General

Installation, Comissioning Maintenance

Special conditions

Maximum operating current IL

Maximum operating voltage U_{Bmax}

 $\begin{array}{l} \text{Maximum permissible ambient temperature } T_{\text{Umax}} \\ \text{at } U_{\text{Bmax}} = \!\!60 \text{ V}, \text{ I}_{\text{L}} = \!\!200 \text{ mA} \\ \text{at } U_{\text{Bmax}} = \!\!60 \text{ V}, \text{ I}_{\text{L}} = \!100 \text{ mA} \\ \text{at } U_{\text{Bmax}} = \!\!30 \text{ V}, \text{ I}_{\text{L}} = \!200 \text{ mA} \end{array}$ Protection from mechanical danger

Protection from UV light

Electrostatic charging

Protection of the connection cable

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2006, EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions CE

€x II 3G Ex nA IIC T6 X

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed! Laws and/or regulations and standards governing the use or intended usage goal must be observed. No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted. The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not permissible. dependant of the load current I_L and the max. operating voltage U_{Bmax}. Information can be taken from the following list.

48 °C (118.4 °F) 52 °C (125.6 °F) 52 °C (125.6 °F) The sensor must not be exposed to **ANY FORM** of mechanical danger. The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas. Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cable must be prevented from being subjected to tension and torsional loading.



ATEX 3D

Note	This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note the ex-marking on the sensor or on the enclosed adhesive label					
Instruction	Manual electrical apparatus for hazardous areas					
Device category 3D	for use in hazardous areas with non-conducting combustible dust					
Directive conformity	94/9/EG					
Standard conformity	EN 50281-1-1					
	Protection via housing					
	Use is restricted to the following stated conditions					
CE symbol	(6					
Ex-identification	€ II 3D IP67 T 94 °C (201.2 °F) X					
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!					
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed.					
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.					
Special conditions						
Maximum operating current IL	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.					
Maximum operating voltage $\mathrm{U}_{\mathrm{Bmax}}$	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.					
Maximum heating (Temperature rise)	dependant of the load current I _L and the max. operating voltage U _{Bmax.} Information can be taken from the following list. The maximum surface temperature at maximum ambient temperature is given in the Ex identification of the apparatus.					
at U _{Bmax} =60 V, I _L =200 mA	24 K					
at U _{Bmax} =60 V, I _I =100 mA	19 K					
at U _{Bmax} =30 V, I _I =200 mA	19 K					
Protection from mechanical danger	The sensor must not be mechanically damaged.					
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.					
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.					



ATEX 3D (tD)	
Note	This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD"
CE symbol	CE
Ex-identification	⟨ⓑ⟩ II 3D Ex tD A22 IP67 T80°C X
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip- ment.
	The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Maximum operating current I_L	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.
Maximum operating voltage U_{Bmax}	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.
Maximum permissible ambient tempera- ture T _{Umax}	dependant of the load current I_L and the max. operating voltage $U_{Bmax.}$ Information can be taken from the following list.
at U _{Bmax} =60 V, I _L =200 mA	45 °C (113 °F)
at U _{Bmax} =60 V, I _I =100 mA	51 °C (123.8 °F)
at U _{Bmax} =30 V, I _I =200 mA	51 °C (123.8 °F)
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

