
Dimensions



((






Model Number

NBB8-18GM50-E2-3G-3D

Features

- Increased operating distance
- 8 mm flush
- ATEX-approval for zone 2 and zone 22

Connection



Accessories

BF 18

Mounting flange, 18 mm

EXG-18

Quick mounting bracket with dead stop

Technical Data

General specifications				
Switching element function		PNP	NO	
Rated operating distance	s _n	8 mm		
Installation		flush		
Output polarity		DC		
Assured operating distance	sa	0 6.48 n	nm	
Reduction factor r _{Al}		0.45		
Reduction factor r _{Cu}		0.4		
Reduction factor r ₃₀₄		0.7		
Nominal ratings				
a				

10 ... 30 V DC Operating voltage U_{B} Switching frequency 0 ... 500 Hz Hysteresis typ. 5 % Reverse polarity protected reverse polarity protected Short-circuit protection pulsing Voltage drop U_{d} ≤ 3 V 0 ... 200 mA 0 ... 0.5 mA typ. 0.1 μA at 25 °C Operating current Off-state current

No-load supply current ≤ 15 mA Indication of the switching state LED, yellow

Functional safety related parameters

2240 a $MTTF_d$ Mission Time (T_M)
Diagnostic Coverage (DC) 0 %

Ambient conditions

Ambient temperature -25 ... 70 °C (-13 ... 158 °F)

Mechanical specifications

Connection type cable PVC, 2 m Core cross-section Housing material 0.34 mm² brass, nickel-plated Sensing face Protection degree

General information

Use in the hazardous area see instruction manuals

Category 3G; 3D

Compliance with standards and directives

Standard conformity

EN 60947-5-2:2007 Standards IEC 60947-5-2:2007

Approvals and certificates

UL approval cULus Listed, General Purpose cCSAus Listed, General Purpose CSA approval CCC approval Products with a maximum operating voltage of ≤36 V do not bear a CCC marking because they do not require approval.

www.pepperl-fuchs.com

ATEX 3G (nA)

General

Maintenance

Instruction Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist Device category 3G (nA)

Directive conformity 94/9/EG

EN 60079-0:2006, EN 60079-15:2005 Standard conformity

Ignition protection category "n" Use is restricted to the following stated conditions

(€ CE symbol

Ex-identification II 3G Ex nA IIC T6 X

> The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

Installation, Comissioning

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list. High load currents and load

short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per-

dependant of the load current I_L and the max. operating voltage $U_{\mbox{\footnotesize Bmax}}$

Maximum permissible ambient tempera-

Protection of the connection cable

ture T_{Umax}

Information can be taken from the following list. at U_{Bmax} =30 V, I_{L} =200 mA 47 °C (116.6 °F)

52 °C (125.6 °F) at U_{Bmax} =30 V, I_{L} =100 mA

Protection from mechanical danger The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor Protection from UV light is used in internal areas.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the Electrostatic charging

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection cable must be prevented from being subjected to tension and torsional loading.

FPEPPERL+FUCHS

ATEX 3D

This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with non-conducting combustible dust

Directive conformity 94/9/EG EN 50281-1-1 Standard conformity Protection via housing

Use is restricted to the following stated conditions

CE symbol (€

Ex-identification II 3D IP67 T 92 °C (197.6 °F) X

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. General The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. Maintenance

Special conditions

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

Maximum heating (Temperature rise)

dependant of the load current I_L and the max. operating voltage U_{Bmax} . Information can be taken from the following list. The maximum surface temperature at maximum ambient temperature is

given in the Ex identification of the apparatus.

22 K at U_{Bmax} =30 V, I_{L} =200 mA at U_{Bmax}=30 V, I_L=100 mA 18 K

The sensor must not be mechanically damaged. Protection from mechanical danger

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Electrostatic charging

The connection cable must be prevented from being subjected to tension and torsional loading.

Protection of the connection cable

www.pepperl-fuchs.com

ATEX 3D (tD)

Note

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

for use in hazardous areas with combustible dust Device category 3D

Directive conformity 94/9/EG

EN 61241-0:2006, EN 61241-1:2004 Standard conformity

Protection via housing "tD"

Use is restricted to the following stated conditions

(€ CE symbol

Ex-identification ⟨ II 3D Ex tD A22 IP67 T80°C X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Repairs to these apparatus are not possible.

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Maintenance No changes can be made to apparatus, which are operated in hazardous areas.

Special conditions

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

Maximum permissible ambient temperature T_{Umax}

Protection of the connection cable

dependant of the load current I_L and the max. operating voltage U_{Bmax} Information can be taken from the following list.

at U_{Bmax} =30 V, I_{L} =200 mA 47 °C (116.6 °F)

at U_{Bmax} =30 V, I_{L} =100 mA 52 °C (125.6 °F)

Protection from mechanical danger The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor Protection from UV light

is used in internal areas.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding

The connection cable must be prevented from being subjected to tension and torsional loading.

FPEPPERL+FUCHS