








# **Model Number**

NJ2-11-N-G-Y10515


# **Features**

- Comfort series
- 2 mm flush

# Connection



### **Dimensions**



L	е	cr	n	ıcaı	U	ata

General specifications		
Switching element function		NAMUR, NC
Rated operating distance	s <sub>n</sub>	2 mm
Installation		flush
Output polarity		NAMUR
Assured operating distance	sa	0 1.62 mm
Reduction factor r <sub>Al</sub>		0.4
Reduction factor r <sub>Cu</sub>		0.3
Reduction factor r <sub>304</sub>		0.85
Nominal ratings		

Nominal ratings		
Nominal voltage	U <sub>o</sub>	8 V
Switching frequency	f	0 3000 Hz
Hysteresis	Н	0.5 3.5 typ. 2 %
Current consumption		
Measuring plate not detected		≥ 3 mA

Functional safety related parameters	
MTTF <sub>d</sub>	11770 a
Mission Time (T <sub>M</sub> )	20 a
Diagnostic Coverage (DC)	0 %

Measuring plate detected

Diagnostic Coverage (DC)	0 %
Ambient conditions	
Ambient temperature	-25 100 °C (-13 212 °

ıv	iechanicai specifications	
	Connection type	cable PVC , 2 m
	Core cross-section	0.34 mm <sup>2</sup>
	Housing material	Stainless steel 1.4305 / AISI 303
	Sensing face	PVDF
	Drotaction degree	IDCO

≤ 1 mA

Containing race		
Protection degree	IP68	
General information		
Use in the hazardous area	see instruction manuals	
Category	2G	
Compliance with standards and directives		

Standard conformity	
NAMUR	EN 60947-5-6:2000 IEC 60947-5-6:1999
Standards	EN 60947-5-2:2007

NAMUR	IEC 60947-5-6:2000
Standards	EN 60947-5-2:2007 IEC 60947-5-2:2007

Approvals and certificates		
UL approval	cULus Listed, General Purpose	
CSA approval	cCSAus Listed, General Purpose	

www.pepperl-fuchs.com

### ATEX 2G

Instruction

#### Device category 2G

Directive conformity Standard conformity

CE symbol

Ex-identification

 $\begin{tabular}{ll} EC-Type Examination Certificate \\ Appropriate type \\ Effective internal capacitance $\,C_i$ \\ Effective internal inductance $L_i$ \\ \end{tabular}$ 

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

#### Special conditions

Protection from mechanical danger

Electrostatic charging

### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 50014:1997, EN 50020:1994
Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions

€ 0102

⟨ы⟩ II 1G EEx ia IIC T6

PTB 00 ATEX 2048 X

NJ 2-11-N-G...

≤ 30 nF; a cable length of 10 m is considered.

 $\leq 50~\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20  $^{\circ}$ C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

www.pepperl-fuchs.com