

## CE


## **Model Number**

## PL2-F25-SN4-K

## **Features**

- For installation in housing
- PL2... without valve connection
- Pluggable cage clamp terminals
- Usable up to SIL 3 acc. to IEC 61508
- Satisfies machinery directive

### Connection



### **Accessories**

BT32 Activator for F25 series

BT32XS

Activator for F25 series


BT32XAS

Activator for F25 series **BT33** 

Activator for F25 series

**BT34** Activator for F25 series

# **Dimensions**



	Switching element function		DC	Dual NC
	Rated operating distance	s <sub>n</sub>	3 mm	
	Installation		embedd	able mountable
Output polarity		Safety Function		
	Assured operating distance	sa	0 2.43	3 mm
	Reduction factor r <sub>Al</sub>		0.38	
	Reduction factor r <sub>Cu</sub>		0.43	
	Reduction factor r <sub>303</sub>		1	
	Reduction factor r <sub>St37</sub>		1.4	
	Reduction factor r <sub>Brass</sub>		0.58	
Nominal ratings				
	Nominal voltage	Uo	8.2 V (R	i approx. 1 kΩ)
	Operating voltage	UB	5 25 \	V
	Switching frequency	f	0 150	0 Hz
	Hysteresis	Н	typ. 5 %	
	Reverse polarity protected		no	
	Short-circuit protection		no	
	Suitable for 2:1 technology		yes, Re	verse polarity protection diode not required
	Current consumption			

Measuring plate not detected  $\geq$  3 mA Measuring plate detected  $\leq 1 \text{ mA}$ 

**Ambient conditions** -25 ... 100 °C (-13 ... 212 °F) -40 ... 100 °C (-40 ... 212 °F) Ambient temperature Storage temperature

**Technical Data** 

**General specifications** 

Mechanical specifications Connection (system side) Cage tension\_spring terminals

Core cross-section (system side) up to 2.5 mm<sup>2</sup> Housing material Sensing face Sensor: PBT Sensor: PBT

General information

Use in the hazardous area see instruction manuals

Category

Compliance with standards and directives

Standard conformity

EN 60947-5-6:2000 NAMUR

### ATEX 1G

Instruction

Device category 1G

Directive conformity

Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate

Appropriate type

Effective internal capacitance  $\,C_{i}\,$ 

Effective internal inductance La

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

### Special conditions

Protection from mechanical danger

Electrostatic charging

Lead insertion

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2006, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

**C**€0102

⟨ы⟩ II 1G Ex ia IIC T6

TÜV 99 ATEX 1479 X

PL.-F25.-SN4..

 $\leq$  100 nF A cable length of 10 m is considered.

The value is applicable for the sensor circuit.

 $\leq$  150  $\mu H$  A cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed. The special conditions

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

When used in group IIB/IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.

The connection cables should either be fixed when laid and mechanically protected or installed in such a way, that a force of 30 N applied in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11. Depending on the type of installation, a suitable cable in accordance with Type A oder B of IEC 60079-14, must be used.

**PEPPERL+FUCHS** 

www.pepperl-fuchs.com

### ATEX 2G

Instruction

### Device category 2G

Directive conformity Standard conformity

CE symbol

Ex-identification

EC-Type Examination Certificate
Appropriate type

Effective internal capacitance  $\,C_{i}\,$ 

Effective internal inductance Li

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

### Special conditions

Protection from mechanical danger

Electrostatic charging

Lead insertion

### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2006, EN 60079-11:2007 Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions

C €0102

II 1G Ex ia IIC T6

TÜV 99 ATEX 1479 X

PL.-F25.-SN4...

 $\leq$  100 nF ; a cable length of 10 m is considered. The value is applicable for the sensor circuit.

 $\leq$  150  $\mu H$  ; a cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

be observed. The special conditions must be adhered to!
Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions.

The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20  $^{\circ}$ C the sensor should be protected from knocks by the provision of an additional housing.

When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.

The connection cables should either be fixed when laid and mechanically protected or installed in such a way, that a force of 30 N applied in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11. Depending on the type of installation, a suitable cable in accordance with Type A oder B of IEC 60079-14, must be used.

Pepperl+Fuchs Group

www.pepperl-fuchs.com

## ATEX 3G (nA)

Special conditions Protection from UV light Electrostatic charging

### ATEX 3G (nL)

Note

#### Instruction

### Device category 3G (nL)

Directive conformity
Standard conformity

CE symbol

Ex-identification

Effective internal capacitance Ci

Effective internal inductance Li

General

Installation, Comissioning

### Maintenance

### Special conditions

Maximum permissible ambient temperature  $T_{Umax}$  at Ui = 20 V

for Pi=34 mW, Ii=25 mA, T6
for Pi=34 mW, Ii=25 mA, T5
for Pi=34 mW, Ii=25 mA, T4-T1
for Pi=64 mW, Ii=25 mA, T6
for Pi=64 mW, Ii=25 mA, T5
for Pi=64 mW, Ii=25 mA, T4-T1
for Pi=169 mW, Ii=52 mA, T6
for Pi=169 mW, Ii=52 mA, T5
for Pi=169 mW, Ii=52 mA, T5
For Pi=169 mW, Ii=52 mA, T4-T1
Protection from mechanical danger

Lead insertion

This instruction is only valid for products according to EN 60079-15:2003, valid until 31-May-2008

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-15:2003 Ignition protection category "n" Use is restricted to the following stated conditions C € 0102

II 3G EEx nL IIC T6 X

 $\leq$  100 nF ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.

 $\leq$  150  $\mu H$  ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group complies with the connected, supplying, power limiting circuit. The sensor must be installed in a housing in such a way, that a protection class of at least IP20 is achieved in accordance with IEC 60529.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Each sensor circuit van be operated with the stated maximum values.

62 °C (143.6 °F) 77 °C (170.6 °F) 95 °C (203 °F) 62 °C (143.6 °F) 77 °C (170.6 °F) 95 °C (203 °F) 51 °C (123.8 °F) 66 °C (150.8 °F) 87 °C (188.6 °F)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The connecting cable must be protected from tension and torsional loading or installed in such a way, that an applied force of 30 N, acting in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11.

www.pepperl-fuchs.com

### ATEX 3G (ic)

Instruction

### Device category 3G (ic)

Directive conformity Standard conformity

CE symbol

Ex-identification

Effective internal capacitance C

Effective internal inductance L

General

Installation, Comissioning

#### Maintenance

#### Special conditions

Maximum permissible ambient temperature  $T_{Umax}$  at Ui = 20 V

for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1

Protection from mechanical danger

Electrostatic charging

Lead insertion

### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/FG

EN 60079-11:2007 Ignition protection category "ic" Use is restricted to the following stated conditions €0102

⟨ II 3G Ex ic IIC T6 X

 $\leq$  100 nF ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.

 $\leq$  150  $\mu H$  ; A cable length of 10 m is considered. The value is applicable for the sensor circuit.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Directive 94/9EG is generally applicable only to the use of electrical apparatus operating at atmospheric conditions

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group complies with the connected, supplying, power limiting circuit. The sensor must be installed in a housing in such a way, that a protection class of at least IP20 is achieved in accordance with IEC 60529.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Each sensor circuit van be operated with the stated maximum values.

77 °C (170.6 °F) 95 °C (203 °F) 62 °C (143.6 °F) 77 °C (170.6 °F) 95 °C (203 °F) 51 °C (123.8 °F) 66 °C (150.8 °F) 87 °C (188.6 °F)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.

The connecting cable must be protected from tension and torsional loading or installed in such a way, that an applied force of 30 N, acting in the direction of the cable inlet for one hour, does not lead to any visible displacement of the cable connections, even though the cable sheathing is displaced, see also IEC 60079-11.

FPEPPERL+FUCHS