Inductive sensor




Model Number

NCB20-L2-N0-V1

Features

- 20 mm flush •
- Quick mounting bracket •
- Usable up to SIL2 acc. to IEC 61508 •







Pinout



Wire colors in accordance with EN 60947-5-6





Technical Data

General specifications		
Switching element function		NAMUR, NC
Rated operating distance	s _n	20 mm
Installation		flush
Output polarity		DC
Assured operating distance	Sa	0 16.2 mm
Reduction factor r _{Al}		0.33
Reduction factor r _{Cu}		0.31
Reduction factor r ₃₀₄		0.74
Nominal ratings		
Nominal voltage	Uo	8.2 V (R _i approx. 1 kΩ)
Switching frequency	f	0 300 Hz
Hysteresis	Н	typ. 5 %
Reverse polarity protection		reverse polarity protected
Short-circuit protection		yes
Current consumption		
Measuring plate not detected		≥ 2.2 mA
Measuring plate detected		≤ 1 mA
Switching state indication		LED, yellow
Functional safety related parameter	ers	
MTTF _d		1660 a
Mission Time (T _M)		20 a
Diagnostic Coverage (DC)		0 %
Ambient conditions		
Ambient temperature		-25 100 °C (-13 212 °F)
Storage temperature		-40 100 °C (-40 212 °F)
Mechanical specifications		
Connection type		Device connector M12 x 1, 4-pin
Housing material		PA
Sensing face		PA
Protection degree		IP69K
General information		
Use in the hazardous area		see instruction manuals
Category		1G; 2G; 3G; 3D
Compliance with standards and di	irective	S
Standard conformity		
NAMUR		EN 60947-5-6:2000
NAMOR		IEC 60947-5-6:1999
Chandauda		EN 60947-5-2:2007
Standards		IEC 60947-5-2:2007
		120 00947-5-2.2007
Approvals and certificates		cULus Listed, General Purpose
Approvals and certificates UL approval		
••		cCSAus Listed, General Purpose

Date of issue: 2013-02-11 182705_eng.xml Release date: 2013-02-10 21:48

Subject to modifications without notice USA: +1 330 486 0001 Pepperl+Fuchs Group

www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

ATEX 1G	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1G	
	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-0:2009, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
CE marking	€ € 0102
Ex-identification	⟨͡͡͡x⟩ II 1G Ex ia IIC T6 Ga
EC-Type Examination Certificate	PTB 00 ATEX 2032 X
Appropriate type	NCB20-L2-N0
Effective internal capacitance C _i	\leq 110 nF ; a cable length of 10 m is considered.
Effective internal inductance L _i	\leq 200 μH ; a cable length of 10 m is considered.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of $> 60 ^{\circ}$ C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the per-
	missible minimum ignition energies may have to be taken into consideration.
Highest permissible ambient temperature	The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Specific conditions	
Protection from mechanical danger	When used in the temperature range below -20 $^\circ\mathrm{C}$ the sensor should be protected from knocks by the provision of an additional housing.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.

parts.



ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE marking

Ex-identification EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Specific conditions

Protection from mechanical danger

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2009, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions $C \in 0102$

(Ex) II 1G Ex ia IIC T6 Ga PTB 00 ATEX 2032 X NCB20-L2-N0...

 \leq 110 nF ; a cable length of 10 m is considered.

 \leq 200 μH ; a cable length of 10 m is considered. The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in gene-

ral only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 $^\circ C$ the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Pepperl+Fuchs Group USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com



ATEX 3D	
Note	This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note the ex-marking on the sensor or on the enclosed adhesive label
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with non-conducting combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 50281-1-1 Protection via housing Use is restricted to the following stated conditions
CE marking	C € 0102
Ex-identification	⟨ II 3D IP69K T 112 °C (233.6 °F) X
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Specific conditions	
Minimum series resistance R_{V}	A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.
Maximum operating voltage U_{Bmax}	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.
Maximum heating (Temperature rise)	Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.
at U _{Bmax} =9 V, R_V =562 Ω	12 K
using an amplifier in accordance with EN 60947-5-6	12 K
Plug connector	The plug connector must not be disconnected under voltage. The proximity switch is marked as follows: "DO NOT DISCON- NECT UNDER VOLTAGE!" When the plug connector is disconnected the ingress of dirt into the inner areas (i.e. the areas, which are not accessible in the plugged-in condition) must be prevented. The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting accessory from Pepperl + Fuchs).
Protection from mechanical danger	The sensor must not be mechanically damaged.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

ATEX 3D (tD) Note	This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004
NOLE	Note the ex-marking on the sensor or on the enclosed adhesive label
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with non-conducting combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD" Use is restricted to the following stated conditions
CE marking	CE
Ex-identification	⟨€x⟩ II 3D Ex tD A22 IP67 T80°C X
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equipment.
	The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Specific conditions	
Minimum series resistance R_{V}	A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier.
Maximum operating voltage U_{Bmax}	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.
Maximum permissible ambient tempera- ture T _{Umax}	Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.
at U _{Bmax} =9 V, R _V =562 Ω	57 °C (134.6 °F)
using an amplifier in accordance with EN 60947-5-6	57 °C (134.6 °F)
Plug connector	The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented. (i.e. the area that is inaccessible when the connector is inserted) The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting accessory from Pepperl + Fuchs).
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.



ATEX 3G (nL) Instruction

Device category 3G (nL) Directive conformity Standard conformity

CE marking

General

Installation, Comissioning

Maintenance

Specific conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T5 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW, Ii=76 mA, T4-T1 Protection from mechanical danger

Protection from UV light

Electrostatic charging

Connection parts

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions $C \in 0102$

 $\label{eq:list} \begin{array}{l} & \underbrace{ \text{K}_{X} \ } \\ \leq 110 \ \text{nF} \ ; \ a \ cable \ \text{length of } 10 \ \text{m is considered}. \\ \leq 200 \ \mu\text{H} \ ; \ A \ cable \ \text{length of } 10 \ \text{m is considered}. \end{array}$

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

NCB20-L2-N0-V1

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group complies with the connected, supplying, power limiting circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

66 °C (150.8 °F)
81 °C (177.8 °F)
100 °C (212 °F)
66 °C (150.8 °F)
81 °C (177.8 °F)
100 °C (212 °F)
45 °C (113 °F)
60 °C (140 °F)
89 °C (192.2 °F)
30 °C (86 °F)
45 °C (113 °F)
74 °C (165.2 °F)

The sensor must not be exposed to **ANY FORM** of mechanical danger. When used in the temperature range below -20 $^\circ$ C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

ATEX 3G (ic)

Instruction

Device category 3G (ic) Directive conformity Standard conformity

CE marking

 $\begin{array}{l} \mbox{Ex-identification} \\ \mbox{Effective internal capacitance } C_i \\ \mbox{Effective internal inductance } L_i \end{array}$

General

Installation, Comissioning

Maintenance

Specific conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T5 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW, Ii=76 mA, T4-T1 Protection from mechanical danger

Electrostatic charging

Connection parts

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2009, EN 60079-11:2007 Ignition protection category "ic" Use is restricted to the following stated conditions € € □

 $\label{eq:linear} \begin{gathered} &\fbox{ 11 3G Ex ic IIC T6 Gc X} \\ &\leq 110 \ nF \ ; \ a \ cable \ length \ of \ 10 \ m \ is \ considered. \\ &\leq 200 \ \mu H \ ; \ A \ cable \ length \ of \ 10 \ m \ is \ considered. \\ \end{gathered}$

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group complies with the connected, supplying, power limiting circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

66 °C (150.8 °F)
81 °C (177.8 °F)
100 °C (212 °F)
66 °C (150.8 °F)
81 °C (177.8 °F)
100 °C (212 °F)
45 °C (113 °F)
60 °C (140 °F)
89 °C (192.2 °F)
30 °C (86 °F)
45 °C (113 °F)
74 °C (165.2 °F)

The sensor must not be mechanically damaged. When used in the temperature range below -20 $^\circ C$ the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Pepperl+Fuchs Group USA: +1 33 www.pepperl-fuchs.com fa-info@us.pep Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

