








# **Model Number**

NCN40-L2-N0-V1

# **Features**

- 40 mm non-flush
- **Quick mounting bracket**
- Usable up to SIL2 acc. to IEC 61508

# Connection



Wire colors in accordance with EN 60947-5-6

BN (brown) 2 BU (blue)

# **Accessories**

V1-G

4-pin, M12 female field-attachable connector

V1-W 4-pin, M12 female field-attachable connector


V1-G-N-2M-PUR

Cable socket, M12, 2-pin, NAMUR, PUR cable V1-W-N-2M-PUR

Cable socket, M12, 2-pin, NAMUR, PUR cable

MHW 01 Modular mounting bracket

# **Dimensions**



# **Technical Data**

0	
Generai	specifications

Switching element function		NAMUR, NC
Rated operating distance	s <sub>n</sub>	40 mm
Installation		non-flush
Output polarity		DC
Assured operating distance	sa	0 32.4 mm
Reduction factor r <sub>Al</sub>		0.31
Reduction factor r <sub>Cu</sub>		0.3
Reduction factor r <sub>304</sub>		0.74

**Nominal ratings** 

8.2 V (R<sub>i</sub> approx. 1 kΩ) Nominal voltage  $U_{o}$ Switching frequency 0 ... 150 Hz Hysteresis Reverse polarity protection typ. 5 % reverse polarity protected

Short-circuit protection yes

Current consumption  $\geq$  2.2 mA Measuring plate not detected Measuring plate detected ≤ 1 mA

LED, yellow Switching state indication Functional safety related parameters

MTTF<sub>d</sub> Mission Time (T<sub>M</sub>) 1670 a 20 a Diagnostic Coverage (DC)

**Ambient conditions** 

Ambient temperature -25 ... 100 °C (-13 ... 212 °F) Storage temperature -40 ... 100 °C (-40 ... 212 °F)

Mechanical specifications

Connection type Device connector M12 x 1, 4-pin

Housing material PA IP69K Sensing face Protection degree

General information

Use in the hazardous area see instruction manuals 1G; 2G; 3G; 3D Category

Compliance with standards and directives

Standard conformity

Standards FN 60947-5-2:2007 IEC 60947-5-2:2007

Approvals and certificates

**UL** approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose

CCC approval Products with a maximum operating voltage of ≤36 V do not bear a

CCC marking because they do not require approval.

#### ATEX 1G

Instruction

Device category 1G

Directive conformity

Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate

Appropriate type

Effective internal capacitance Ci

Effective internal inductance Li

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

## Specific conditions

Protection from mechanical danger

Electrostatic charging

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

94/9/EG

EN 60079-0:2009, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

**C**€0102

⟨ II 1G Ex ia IIC T6 Ga

PTB 00 ATEX 2032 X

NCN40-L2-N0..

 $\leq$  105 nF; a cable length of 10 m is considered.

≤ 300 µH; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions

The use in ambient temperatures of > 60  $^{\circ}\text{C}$  was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type  ${\color{blue} {\sf EC}}$ Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related

apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy the requirements of category ia.

Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible

When used in the temperature range below -20  $^{\circ}\text{C}$  the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing

2

## ATEX 2G

Instruction

# Device category 2G

Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate

Appropriate type

Effective internal capacitance Ci

Effective internal inductance Li

General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

#### Specific conditions

Protection from mechanical danger

Electrostatic charging

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG

EN 60079-0:2009, EN 60079-11:2007
Ignition protection "Intrinsic safety"
Use is restricted to the following stated conditions

C € 0102

(EX) II 1G Ex ia IIC T6 Ga PTB 00 ATEX 2032 X NCN40-L2-N0...

 $\leq$  105 nF; a cable length of 10 m is considered.

 $\leq$  300  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions.

The use in ambient temperatures of > 60  $^{\circ}$ C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20  $^{\circ}\text{C}$  the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Pepperl+Fuchs Group

ATEX 3D Note

This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

for use in hazardous areas with non-conducting combustible dust Device category 3D

Directive conformity 94/9/EG Standard conformity EN 50281-1-1 Protection via housing

Use is restricted to the following stated conditions

CE marking **C** €0102

Ex-identification ⟨ы⟩ II 3D IP69K T 112 °C (233.6 °F) X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Maintenance No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Specific conditions

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance Minimum series resistance Bu

with the following list. This can also be assured by using a switch amplifier. The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

Maximum operating voltage U<sub>Bmax</sub>

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series Maximum heating (Temperature rise)

resistance Rv

at  $U_{Bmax}$ =9 V,  $R_V$ =562  $\Omega$ 12 K

using an amplifier in accordance with 12 K EN 60947-5-6

The plug connector must not be disconnected under voltage. The proximity switch is marked as follows: "DO NOT DISCON-Plug connector

NECT UNDER VOLTAGE!" When the plug connector is disconnected the ingress of dirt into the inner areas (i.e. the areas,

which are not accessible in the plugged-in condition) must be prevented.

The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting

accessory from Pepperl + Fuchs).

Protection from mechanical danger The sensor must not be mechanically damaged.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

ATEX 3D (tD)

Note

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004

Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

for use in hazardous areas with non-conducting combustible dust Device category 3D

Directive conformity 94/9/EG

EN 61241-0:2006, EN 61241-1:2004 Standard conformity

Protection via housing "tD"

Use is restricted to the following stated conditions

CE marking (€

Ex-identification ⟨Ex⟩ II 3D Ex tD A22 IP67 T80°C X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Maintenance No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Specific conditions

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance Minimum series resistance R<sub>V</sub>

with the following list. This can also be assured by using a switch amplifier.

The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances Maximum operating voltage U<sub>Bmax</sub> are not permitted.

Maximum permissible ambient temperature  $T_{Umax}$ 

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.

57 °C (134.6 °F) at U\_Bmax=9 V, R\_V=562  $\Omega$ using an amplifier in accordance with  $\,$  57 °C (134.6 °F)

EN 60947-5-6

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT Plua connector SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented. (i.e.

the area that is inaccessible when the connector is inserted)

The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting

accessory from Pepperl + Fuchs).

Protection from mechanical danger

Protection from UV light

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Electrostatic charging

Pepperl+Fuchs Group

## ATEX 3G (nL)

Instruction

#### Device category 3G (nL)

Directive conformity Standard conformity

CE marking

Ex-identification

Effective internal capacitance C Effective internal inductance Li

General

Installation, Comissioning

#### Maintenance

#### Specific conditions

Maximum permissible ambient temperature T<sub>Umax</sub> at Ui = 20 V for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW Ji=25 mA T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6

for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW. Ii=76 mA. T4-T1 Protection from mechanical danger

Protection from UV light

Electrostatic charging

Connection parts

## Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/FG

EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions €0102

II 3G Ex nL IIC T6 X

≤ 105 nF; a cable length of 10 m is considered.

 $\leq 300~\mu H$  ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group complies with the connected, supplying, power limiting circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

66 °C (150.8 °F) 81 °C (177.8 °F) 100 °C (212 °F) 66 °C (150.8 °F) 81 °C (177.8 °F) 100 °C (212 °F) 45 °C (113 °F) 60 °C (140 °F) 89 °C (192.2 °F) 30 °C (86 °F) 45 °C (113 °F) 74 °C (165.2 °F)

The sensor must not be exposed to  $\bf ANY\ FORM$  of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

## ATEX 3G (ic)

Instruction

# Device category 3G (ic)

Directive conformity Standard conformity

CE marking

Ex-identification

Effective internal capacitance Ci Effective internal inductance Li

General

Installation, Comissioning

Maintenance

## Specific conditions

Maximum permissible ambient temperature  $T_{Umax}$  at Ui = 20 V

for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW. Ii=25 mA. T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW. Ii=52 mA. T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW, Ii=76 mA, T4-T1 Protection from mechanical danger

Electrostatic charging

Connection parts

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

EN 60079-0:2009, EN 60079-11:2007 Ignition protection category "ic" Use is restricted to the following stated conditions

CEI

II 3G Ex ic IIC T6 Gc X

 $\leq$  105 nF; a cable length of 10 m is considered.

 $\leq 300~\mu H$  ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group complies with the connected, supplying, power limiting circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

66 °C (150.8 °F) 81 °C (177.8 °F) 100 °C (212 °F) 66 °C (150.8 °F) 81 °C (177.8 °F) 100 °C (212 °F) 45 °C (113 °F) 60 °C (140 °F) 89 °C (192.2 °F) 30 °C (86 °F) 45 °C (113 °F) 74 °C (165.2 °F)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of

IP20 is achieved, in accordance with IEC 60529