
Dimensions



ϵ








Model Number

NCB10-30GM40-Z0-V1-3G-3D

Features

- 10 mm flush
- ATEX-approval for zone 2 and zone 22

Connection



Pinout



Wire colors in accordance with EN 60947-5-2

1	BN	(brown)
2	WH	(white)
3	BU	(blue)
4	BK	(black)

Accessories

Mounting flange, 30 mm

4-pin, M12 female field-attachable connector

V1-G

4-pin, M12 female field-attachable connector

Technical Data

General specifications		
Switching element function		DC NO
Rated operating distance	s _n	10 mm
Installation		flush
Output polarity		DC
Assured operating distance	sa	0 8.1 mm
Reduction factor r _{Al}		0.32
Reduction factor r _{Cu}		0.28
Reduction factor r ₃₀₄		0.7
Nominal ratings		
Operating voltage	U_B	5 60 V DC
Switching frequency	f	0 150 Hz
Hysteresis	Н	1 15 tvn 5 %

1 ... 15 typ. 5 % tolerant Reverse polarity protected Short-circuit protection pulsing Voltage drop . ≤ 5 V 2 ... 100 mA 0 ... 0.5 mA typ. Operating current Off-state current Indication of the switching state Multihole-LED, yellow

Functional safety related parameters

MTTF_d
Mission Time (T_M) 1830 a 20 a 0 % Diagnostic Coverage (DC)

Ambient conditions

Ambient temperature -25 ... 70 °C (-13 ... 158 °F)

Mechanical specifications

Connection type Device connector M12 x 1, 4-pin Housing material Stainless steel 1.4305 / AISI 303 PRT

Sensing face Protection degree

General information

Use in the hazardous area see instruction manuals 3G; 3D

Category

Compliance with standards and directives

Standard conformity

EN 60947-5-2:2007 Standards IEC 60947-5-2:2007

Approvals and certificates

UL approval cULus Listed, General Purpose CSA approval cCSAus Listed, General Purpose

CCC approval Certified by China Compulsory Certification (CCC)

IP67

www.pepperl-fuchs.com

ATEX 3G (nA)

General

Instruction

Manual electrical apparatus for hazardous areas for use in hazardous areas with gas, vapour and mist

Device category 3G (nA)

Directive conformity

Standard conformity EN 60079-0:2006, EN 60079-15:2005

Ignition protection category "n"

Use is restricted to the following stated conditions

< € | CE symbol

Ex-identification

The Ex-relevant identification may also be printed on the accompanying adhesive label.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

94/9/EG

Special conditions

Protection from UV light

Maintenance

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax}

The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per-

Maximum permissible ambient temperadependant of the load current I_L and the max. operating voltage U_{Bmax} .

ture T_{Umax} Information can be taken from the following list

at U_{Bmax} =60 V, I_{L} =100 mA 55 °C (131 °F)

at U_{Bmax} =60 V, I_{L} =50 mA 60 °C (140 °F)

The plug connector must not be disconnected under voltage. The proximity switch is marked as follows: "DO NOT DISCON-Plug connector NECT UNDER VOLTAGE!" When the plug connector is disconnected the ingress of dirt into the inner areas (i.e. the areas,

which are not accessible in the plugged-in condition) must be prevented.

Protection from mechanical danger The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the Electrostatic charging

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

www.pepperl-fuchs.com

ATEX 3D

This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

for use in hazardous areas with non-conducting combustible dust Device category 3D

Directive conformity 94/9/EG EN 50281-1-1 Standard conformity Protection via housing

Use is restricted to the following stated conditions

CE symbol (€

Ex-identification ⟨ы⟩ II 3D IP67 T 85 °C (185 °F) X

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. General The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Maintenance

Repairs to these apparatus are not possible.

Special conditions

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.

Maximum heating (Temperature rise)

dependant of the load current I_L and the max. operating voltage U_{Bmax} . Information can be taken from the following list. The maximum surface temperature at maximum ambient temperature is

given in the Ex identification of the apparatus.

15 K

at U_{Bmax} =60 V, I_{L} =100 mA at U_{Bmax} =60 V, I_{L} =50 mA

The plug connector must not be disconnected under voltage. The proximity switch is marked as follows: "DO NOT DISCONNECT UNDER VOLTAGE!" When the plug connector is disconnected the ingress of dirt into the inner areas (i.e. the areas, which are not accessible in the plugged-in condition) must be prevented. Plug connector

The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting

accessory from Pepperl + Fuchs).

The sensor must not be mechanically damaged. Protection from mechanical danger

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the Electrostatic charging

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Pepperl+Fuchs Group

www.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com

ATEX 3D (tD) Note

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

for use in hazardous areas with combustible dust Device category 3D

Directive conformity 94/9/EG

Standard conformity EN 61241-0:2006, EN 61241-1:2004

Protection via housing "tD"

Use is restricted to the following stated conditions

(E CE symbol

Ex-identification ⟨Ex⟩ II 3D Ex tD A22 IP67 T80°C X

The Ex-relevant identification may also be printed on the accompanying adhesive label.

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immediate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Maintenance Repairs to these apparatus are not possible.

Special conditions

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

Maximum permissible ambient temperadependant of the load current I_L and the max. operating voltage U_{Bmax} .

Information can be taken from the following list. ture T_{Umax}

at U_{Bmax} =60 V, I_{L} =100 mA 55 °C (131 °F) 60 °C (140 °F) at U_{Bmax} =60 V, I_{L} =50 mA

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented. (i.e. Plug connector

the area that is inaccessible when the connector is inserted)

The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting accessory from Pepperl + Fuchs).

Protection from mechanical danger

Protection from UV light

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com