Dimensions




Model Number

NJ15-30GK-SN-15M

Features

- **Comfort series** ٠
- 15 mm non-flush •
- Usable up to SIL 3 acc. to IEC 61508 •





Accessories

BF 30 Mounting flange, 30 mm


Application



Danger!

In safety-related applications the sensor must be operated with a qualified fail safe interface from Pepperl+Fuchs, such as KFD2-SH-EX1.

Consider the "exida Functional Safety Assessment" document which is available on www.pepperl-fuchs.com as an integral part of this product's documentation.



Technical Data

| Installation Output polarity Assured operating distance s Reduction factor r _{Al} Reduction factor r _{Cu} Reduction factor r ₃₀₄ | S _n | NAMUR, NC 15 mm non-flush Safety Function 0 12.15 mm 0.4 |
|--|----------------|--|
| Rated operating distance s Installation Output polarity Assured operating distance s Reduction factor r _{Al} Reduction factor r _{Cu} Reduction factor r ₃₀₄ Reduction factor r ₃₀₄ | | 15 mm non-flush Safety Function 0 12.15 mm |
| Installation Output polarity Assured operating distance s Reduction factor r_{Al} Reduction factor r_{Cu} Reduction factor r_{304} | | non-flush Safety Function 0 12.15 mm |
| Installation Output polarity Assured operating distance s Reduction factor r _{Al} Reduction factor r _{Cu} Reduction factor r ₃₀₄ | | Safety Function 0 12.15 mm |
| $\begin{array}{llllllllllllllllllllllllllllllllllll$ | Sa | 0 12.15 mm |
| $\begin{array}{c} \text{Reduction factor } r_{\text{Al}} \\ \text{Reduction factor } r_{\text{Cu}} \\ \text{Reduction factor } r_{304} \end{array}$ | S _a | |
| Reduction factor r _{Cu} Reduction factor r ₃₀₄ | | 0.4 |
| Reduction factor r ₃₀₄ | | |
| | | 0.3 |
| | | 0.85 |
| Nominal ratings | | |
| Nominal voltage | ٦° | 8 V |
| Operating voltage | J _B | 5 25 V |
| Switching frequency f | | 0 100 Hz |
| Current consumption | | |
| Measuring plate not detected | | ≥ 3 mA |
| Measuring plate detected | | ≤1 mA |
| Functional safety related parameters | 3 | |
| MTTFd | | 9191 a |
| Mission Time (T _M) | | 20 a |
| Diagnostic Coverage (DC) | | 0% |
| Ambient conditions | | |
| Ambient temperature | | -40 100 °C (-40 212 °F) |
| Mechanical specifications | | 40 100 0 (40 212 1) |
| • | | and the attraction of the second s |
| Connection type Core cross-section | | cable silicon , 15 m 0.75 mm ² |
| Housing material | | PP |
| Sensing face | | PP |
| Protection degree | | IP68 |
| General information | | IF00 |
| | | and instruction means la |
| Use in the hazardous area | | see instruction manuals |
| Category | | 1G; 2G; 3G; 1D; 3D |
| Compliance with standards and direct | ctives | |
| Standard conformity | | |
| NAMUR | | EN 60947-5-6:2000 |
| | | IEC 60947-5-6:1999 |
| Standards | | EN 60947-5-2:2007 |
| Otalidardo | | IEC 60947-5-2:2007 |
| Approvals and certificates | | .20 000 0 2.200. |
| •• | | |
| UL approval | | cULus Listed, General Purpose |
| CSA approval | | cCSAus Listed, General Purpose |
| CCC approval | | Products with a maximum operating voltage of \leq 36 V do not bear a CCC marking because they do not require approval. |

Subject to modifications without notice

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com



| ATEX 1G | |
|---|---|
| Instruction | Manual electrical apparatus for hazardous areas |
| Device category 1G | |
| | for use in hazardous areas with gas, vapour and mist |
| Directive conformity | 94/9/EG |
| Standard conformity | EN 60079-0:2009, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions |
| CE marking | C € 0102 |
| Ex-identification | 🐵 II 1G Ex ia IIC T6 Ga |
| EC-Type Examination Certificate | PTB 00 ATEX 2049 X |
| Appropriate type | NJ 15-30GK-SN |
| Effective internal capacitance Ci | \leq 120 nF ; a cable length of 10 m is considered. |
| Effective internal inductance Li | \leq 180 μH ; a cable length of 10 m is considered. |
| Cable length | Dangerous electrostatic charges on the fixed connection cable must be taken into account for lengths equal to and exceeding the following values: |
| Explosion group IIA | 78 cm |
| Explosion group IIB | 39 cm |
| Explosion group IIC | 6 cm |
| General | The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! |
| Highest permissible ambient temperature | The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1. |
| Installation, Comissioning | Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. |
| Maintenance | No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. |
| Specific conditions | |
| Protection from mechanical danger | When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing. |
| | |

Electrostatic charging

When used in group IIC non-permissible electrostatic charges should be avoided on the plastic housing parts.

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com



ATEX 2G

Instruction

Device category 2G Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Highest permissible ambient temperature

Installation, Comissioning

Maintenance

Specific conditions

Protection from mechanical danger

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-0:2009, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions $C \in 0102$

PTB 00 ATEX 2049 X

NJ 15-30GK-SN...

 \leq 120 nF ; a cable length of 10 m is considered.

 \leq 180 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 $^{\circ}\text{C}$ the sensor should be protected from knocks by the provision of an additional housing.

Pepperl+Fuchs Group USA: +1 330 4 www.pepperl-fuchs.com fa-info@us.peppe



ATEX 1D

Instruction

Device category 1D Directive conformity Standard conformity

CE marking

Ex-identification

EC-Type Examination Certificate Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Maximum housing surface temperature

Installation, Comissioning

Maintenance

Specific conditions

Electrostatic charging

for use in hazardous areas with combustible dust 94/9/EG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions C€0102

(Ex) II 1D Ex iaD 20 T 108 °C (226.4 °F)

The Ex-significant identification is on the enclosed adhesive label ZELM 03 ATEX 0128 X

NJ 15-30GK-SN...

 \leq 120 nF ; a cable length of 10 m is considered.

 \leq 180 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. The intrinsically safe circuit has to be protected against influences due to lightning.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

USA: +1 330 486 0001 Ger fa-info@us.pepperl-fuchs.com fa-i

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com



| ATEX 3D | |
|---|---|
| Note | This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note the ex-marking on the sensor or on the enclosed adhesive label |
| Instruction | Manual electrical apparatus for hazardous areas |
| Device category 3D | for use in hazardous areas with non-conducting combustible dust |
| Directive conformity | 94/9/EG |
| Standard conformity | EN 50281-1-1 Protection via housing Use is restricted to the following stated conditions |
| CE marking | C€ 0102 |
| Ex-identification | ⟨↔⟩ II 3D IP68 T 111 °C (231.8 °F) X The Ex-significant identification is on the enclosed adhesive label |
| General | The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to! |
| Installation, Comissioning | Laws and/or regulations and standards governing the use or intended usage goal must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! |
| | The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion! |
| Maintenance | No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. |
| Specific conditions | |
| Minimum series resistance R_{V} | A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier. |
| Maximum operating voltage U _{Bmax} | The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted. |
| Maximum heating (Temperature rise) | Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv. |
| at U _{Bmax} =9 V, R_V =562 Ω | 11 K |
| using an amplifier in accordance with EN 60947-5-6 | 11 K |
| Protection from mechanical danger | The sensor must not be mechanically damaged. |
| Protection of the connection cable | The connection cable must be prevented from being subjected to tension and torsional loading. |

 Subject to modifications without notice

 Pepperl+Fuchs Group
 US

 www.pepperl-fuchs.com
 fa-info

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



5

| ATEX 3D (tD) | |
|--|--|
| Note | This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label |
| Instruction | Manual electrical apparatus for hazardous areas |
| Device category 3D | for use in hazardous areas with non-conducting combustible dust |
| Directive conformity | 94/9/EG |
| Standard conformity | EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD" |
| CE marking | Use is restricted to the following stated conditions |
| Ex-identification | ⟨ᡚ II 3D Ex tD A22 IP67 T80°C X |
| | The Ex-significant identification is on the enclosed adhesive label |
| General | The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip- ment. |
| | The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to! |
| Installation, Comissioning | Laws and/or regulations and standards governing the use or intended usage goal must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! |
| | The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion! |
| Maintenance | No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. |
| Specific conditions | |
| Minimum series resistance R_{V} | A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance with the following list. This can also be assured by using a switch amplifier. |
| Maximum operating voltage U _{Bmax} | The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted. |
| Minimum permissible ambient tempera- ture T _{Umin} | -25 °C (-13 °F) |
| Maximum permissible ambient tempera- ture T _{Umax} | Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv. |
| at U _{Bmax} =9 V, R _V =562 Ω | 58 °C (136.4 °F) |
| using an amplifier in accordance with EN 60947-5-6 | 58 °C (136.4 °F) |
| Protection from mechanical danger | The sensor must not be exposed to ANY FORM of mechanical danger. |
| Protection from UV light | The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas. |
| Protection of the connection cable | The connection cable must be prevented from being subjected to tension and torsional loading. |



ATEX 3G (nL)

Instruction

Device category 3G (nL) Directive conformity Standard conformity

CE marking

Ex-identification

Effective internal capacitance Ci

Effective internal inductance Li

General

Installation, Comissioning

Maintenance

Specific conditions

Minimum permissible ambient temperature T_{Umin} Maximum permissible ambient temperature T_{Umax} at Ui = 20 V for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T4-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW, Ii=76 mA, T4-T1

Protection from mechanical danger

Protection from UV light

Protection of the connection cable

Connection parts

for use in hazardous areas with gas, vapour and mist 94/9/EG EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions €€0102

 $\overleftarrow{\mbox{(sc)}}$ II 3G Ex nL IIC T6 X The Ex-significant identification is on the enclosed adhesive label

 \leq 120 nF ; A cable length of 10 m is considered.

 \leq 180 μ H ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-15. The explosion group depends on the connected and energy-limited supply circuit.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

-25 °C (-13 °F)

55 °C (131 °F) 55 °C (131 °F) 55 °C (131 °F) 55 °C (131 °F) 55 °C (131 °F) 55 °C (131 °F) 41 °C (105.8 °F) 41 °C (105.8 °F) 41 °C (105.8 °F) 29 °C (84.2 °F) 29 °C (84.2 °F)29 °C (84.2 °F)

The sensor must not be exposed to **ANY FORM** of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional loading.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Subject to modifications without notice Pepperl+Fuchs Group

www.pepperl-fuchs.com fa-info@us.pe

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com



ATEX 3G (ic) Instruction

Device category 3G (ic) Directive conformity Standard conformity

CE marking

Ex-identification

Effective internal capacitance Ci Effective internal inductance L

General

Installation, Comissioning

Maintenance

Specific conditions

Maximum permissible ambient temperature T_{Umax} at Ui = 20 V for Pi=34 mW, li=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, li=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW. li=25 mA. T5 for Pi=64 mW, li=25 mA, T4-T1 for Pi=169 mW, li=52 mA, T6 for Pi=169 mW, li=52 mA, T5 for Pi=169 mW, li=52 mA, T4-T1 for Pi=242 mW li=76 mA T6 for Pi=242 mW, li=76 mA, T5

Connection parts

for Pi=242 mW, Ii=76 mA, T4-T1 Protection from mechanical danger

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

94/9/EG EN 60079-0:2009, EN 60079-11:2007 Ignition protection category "ic" Use is restricted to the following stated conditions <€

(b) II 3G Ex ic IIC T6 Gc X The Ex-significant identification is on the enclosed adhesive label

≤ 120 nF ; a cable length of 10 m is considered.

 \leq 180 μ H ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11.

The explosion group complies with the connected, supplying, power limiting circuit. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

| 55 °C (131 °F) |
|------------------|
| 55 °C (131 °F) |
| 41 °C (105.8 °F) |
| 41 °C (105.8 °F) |
| 41 °C (105.8 °F) |
| 29 °C (84.2 °F) |
| 29 °C (84.2 °F) |
| 29 °C (84.2 °F) |
| The sensor mus |

not be mechanically damaged. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

