










# **Model Number**

NJ10-30GM50-E2-3G-3D-5M

## **Features**

- **Comfort series**
- 10 mm embeddable

## Connection



# **Accessories**


# BF 30

Mounting flange, 30 mm

**EXG-30** 

Quick mounting bracket with dead stop

# **Dimensions**



# **Technical Data**

General specifications		
Switching element function		PNP NO
Rated operating distance	s <sub>n</sub>	10 mm
Installation		embeddable
Output polarity		DC
Assured operating distance	sa	0 8.1 mm
Reduction factor r <sub>Al</sub>		0.32
Reduction factor r <sub>Cu</sub>		0.32
Reduction factor r <sub>304</sub>		0.72
Reduction factor r <sub>Brass</sub>		0.43
Nominal ratings		
Operating voltage	U <sub>B</sub>	10 60 V
Switching frequency	f	0 650 Hz
Hysteresis	Н	1 15 typ. 5 %
Reverse polarity protected		reverse polarity protected

Short-circuit protection pulsing ≤ 2.8 V 0 ... 200 mA Voltage drop
Operating current 0 ... 0.5 mA typ. 0.01 mA Off-state current No-load supply current Indication of the switching state ≤ 9 mA

LED, yellow **Ambient conditions** 

-25 ... 70 °C (-13 ... 158 °F) -25 ... 85 °C (-13 ... 185 °F) Ambient temperature Storage temperature

Mechanical specifications

cable PVC 5 m 0.75 mm<sup>2</sup> Connection type Core cross-section Housing material Stainless steel 1.4305 / AISI 303 Sensing face

IP67 Protection degree

General information

Use in the hazardous area see instruction manuals 3G; 3D Category

Compliance with standards and directives

Standard conformity

Standards EN 60947-5-2:2007 IEC 60947-5-2:2007

Approvals and certificates

**UL** approval cULus Listed, General Purpose

CSA approval cCSAus Listed, General Purpose

CCC approval Certified by China Compulsory Certification (CCC)

www.pepperl-fuchs.com

#### ATEX 3G (nA)

Instruction Manual electrical apparatus for hazardous areas

Device category 3G (nA) for use in hazardous areas with gas, vapour and mist

Directive conformity 94/9/EG

Standard conformity EN 60079-0:2006, EN 60079-15:2005

Ignition protection category "n"
Use is restricted to the following stated conditions

CE symbol ( €

Ex-identification (x) II 3G Ex nA IIC T6 X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Laws and/or regulations and standards governing the use of intended usage goal must be obser

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

Maintenance

Installation, Comissioning

Maximum operating current I<sub>L</sub> The maximum permissible load current must be restricted to the values given in the following list. High load currents and load

short-circuits are not permitted

Maximum operating voltage U<sub>Bmax</sub>

The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not permissible.

missible. dependant of the load current  $I_L$  and the max. operating voltage  $U_{Bmax}$ 

Maximum permissible ambient tempera-

Protection of the connection cable

ture T<sub>Umax</sub>

Information can be taken from the following list. 53 °C (127.4 °F)

at  $U_{Bmax}$ =60 V,  $I_{L}$ =200 mA 53 °C (127.4 °F) at  $U_{Bmax}$ =30 V,  $I_{L}$ =100 mA 59 °C (138.2 °F)

Protection from mechanical danger The sensor must not be exposed to **ANY FORM** of mechanical danger.

Protection from UV light

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection cable must be prevented from being subjected to tension and torsional loading.

www.pepperl-fuchs.com

ATEX 3D

This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with non-conducting combustible dust

Directive conformity 94/9/EG EN 50281-1-1 Standard conformity Protection via housing

Use is restricted to the following stated conditions (€

CE symbol

Ex-identification II 3D IP67 T 87 °C (188.6 °F) X

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. General The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. Maintenance

Special conditions Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U<sub>Bmax</sub> The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.

Maximum heating (Temperature rise)

dependant of the load current  $I_L$  and the max. operating voltage  $U_{Bmax}$ . Information can be taken from the following list. The maximum surface temperature at maximum ambient temperature is

given in the Ex identification of the apparatus.

17 K at  $U_{Bmax}$ =60 V,  $I_{L}$ =200 mA at U<sub>Bmax</sub>=30 V, I<sub>L</sub>=100 mA 11 K

The sensor must not be mechanically damaged. Protection from mechanical danger

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Electrostatic charging

The connection cable must be prevented from being subjected to tension and torsional loading.

Protection of the connection cable

Pepperl+Fuchs Group

www.pepperl-fuchs.com

USA: +1 330 486 0001

fa-info@us.pepperl-fuchs.com

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com

ATEX 3D (tD)

Note

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

for use in hazardous areas with combustible dust Device category 3D

Directive conformity 94/9/EG

EN 61241-0:2006, EN 61241-1:2004 Standard conformity

Protection via housing "tD"

Use is restricted to the following stated conditions

(€ CE symbol

Ex-identification ⟨ II 3D Ex tD A22 IP67 T80°C X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Maintenance No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible. Special conditions

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U<sub>Bmax</sub> The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

Maximum permissible ambient temperadependant of the load current  $I_L$  and the max. operating voltage  $U_{Bmax}$ 

ture T<sub>Umax</sub>

Protection of the connection cable

Information can be taken from the following list. 53 °C (127.4 °F)

at  $U_{Bmax}$ =60 V,  $I_{L}$ =200 mA at  $U_{Bmax}$ =30 V,  $I_{L}$ =100 mA 59 °C (138.2 °F)

Protection from mechanical danger The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor Protection from UV light

is used in internal areas.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding

The connection cable must be prevented from being subjected to tension and torsional loading.