










Model Number

NJ5-18GM50-E2-3G-3D-5M

Features

- · Comfort series
- 5 mm flush

Connection



Accessories


BF 18

Mounting flange, 18 mm

EXG-18

Quick mounting bracket with dead stop

Dimensions



Technical Data

	PNP NO
s _n	5 mm
	flush
	DC
sa	0 4.05 mm
	0.2
	0.15
	0.62

lantallation condition

Installation conditions		
A		0 mm
В		0 mm
С		15 mm
Operating voltage	U_B	10 60 V
Switching frequency	f	0 1500 Hz
Hysteresis	Н	1 15 typ. 6 %
Reverse polarity protected		reverse polarity pro
Short-circuit protection		nuleina

Short-circuit protection		pulsing
Voltage drop	U _d	≤ 3 V
Operating current	IL.	0 200 mA
Lowest operating current	I _m	0 mA
Off-state current	I _r	0 0.5 mA typ. 0.01 mA
No-load supply current	I ₀	≤ 9 mA
Indication of the switching state		LED, yellow

Functional safety related parameters MTTF_d 1100 a Mission Time (T_M) 20 a Diagnostic Coverage (DC) 0 %

Ambient conditions -25 ... 70 °C (-13 ... 158 °F) Storage temperature -25 ... 70 °C (-40 ... 185 °F)

Mechanical specifications

Connection type	cable PVC , 5 m
Core cross-section	0.5 mm ²
Housing material	Stainless steel 1.4305 / AISI 303
Sensing face	PBT
Protection degree	IP67

General information

Use in the hazardous area	see instruction manuals
Category	3G: 3D

Compliance with standards and directives

Standard conformity

Standards	EN 60947-5-2:2007
	IEC 60047-5-2:2007

Approvals and certificates

UL approval	cULus Listed, General Purpose
CSA approval	cCSAus Listed, General Purpose

CCC approval Certified by China Compulsory Certification (CCC)

www.pepperl-fuchs.com

ATEX 3G (nA)

Instruction Manual electrical apparatus for hazardous areas

Device category 3G (nA) for use in hazardous areas with gas, vapour and mist

Directive conformity 94/9/EG

Standard conformity EN 60079-0:2006, EN 60079-15:2005

Ignition protection category "n"

Use is restricted to the following stated conditions (€

CE symbol

Ex-identification II 3G Ex nA IIC T6 X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

Maintenance

Installation, Comissioning

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list. High load currents and load

short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per-

dependant of the load current I_L and the max. operating voltage U_{Bmax}

Maximum permissible ambient tempera-

ture T_{Umax}

Information can be taken from the following list. at U_{Bmax} =60 V, I_{L} =200 mA 48 °C (118.4 °F) 52 °C (125.6 °F) at U_{Bmax} =60 V, I_{L} =100 mA

at U_{Bmax}=30 V, I_L=200 mA

52 °C (125.6 °F) The sensor must not be exposed to ANY FORM of mechanical danger.

Protection from mechanical danger Protection from UV light

Protection of the connection cable

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection cable must be prevented from being subjected to tension and torsional loading.

ATEX 3D

This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

for use in hazardous areas with non-conducting combustible dust Device category 3D

Directive conformity 94/9/EG EN 50281-1-1 Standard conformity Protection via housing

Use is restricted to the following stated conditions

CE symbol (€

Ex-identification II 3D IP67 T 94 °C (201.2 °F) X General

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Installation, Comissioning No changes can be made to apparatus, which are operated in hazardous areas. Maintenance

Repairs to these apparatus are not possible.

Special conditions

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

Maximum heating (Temperature rise)

dependant of the load current I_L and the max. operating voltage U_{Bmax} . Information can be taken from the following list. The maximum surface temperature at maximum ambient temperature is given in the Ex identification of the apparatus.

24 K at U_{Bmax} =60 V, I_{L} =200 mA 19 K at U_{Bmax} =60 V, I_{L} =100 mA 19 K at U_{Bmax} =30 V, I_{L} =200 mA

Protection from mechanical danger The sensor must not be mechanically damaged.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the Electrostatic charging

mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cable must be prevented from being subjected to tension and torsional loading

Protection of the connection cable

fa-info@us.pepperl-fuchs.com

ATEX 3D (tD)

Note

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

for use in hazardous areas with combustible dust Device category 3D

Directive conformity 94/9/EG

Standard conformity EN 61241-0:2006, EN 61241-1:2004

Protection via housing "tD"

Use is restricted to the following stated conditions

(€ CE symbol

Ex-identification ⟨ II 3D Ex tD A22 IP67 T80°C X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Maintenance No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible. Special conditions

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

Maximum permissible ambient temperadependant of the load current I_L and the max. operating voltage U_{Bmax}

ture T_{Umax}

Information can be taken from the following list. at U_{Bmax} =60 V, I_{L} =200 mA 45 °C (113 °F)

at U_{Bmax} =60 V, I_{L} =100 mA 51 °C (123.8 °F) at U_{Bmax}=30 V, I_L=200 mA 51 °C (123.8 °F)

The sensor must not be exposed to ANY FORM of mechanical danger. Protection from mechanical danger

Protection from UV light The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the Electrostatic charging

mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cable must be prevented from being subjected to tension and torsional loading.

Protection of the connection cable

www.pepperl-fuchs.com