


### **Model Number**

NJ8-18GM50-E2-3D-5M

### **Features**

- Comfort series
- 8 mm not embeddable

## Connection




### **Accessories**

### **BF 18**

Mounting flange

### **Dimensions**



_	-	-		
Too	hn	100	l Data	•
166	ш	ILa	Dala	1

General specifications		
Switching element function		PNP Make function
Rated operating distance	s <sub>n</sub>	8 mm
Installation		not embeddable
Output polarity		DC
Assured operating distance	s <sub>a</sub>	0 6.48 mm
Reduction factor r <sub>Al</sub>		0.42
Reduction factor r <sub>Cu</sub>		0.4
Reduction factor rygy		0.72

# **Nominal ratings**

Mounting conditions

A		10 mm
В		54 mm
С		24 mm
Operating voltage	$U_B$	10 60 V
Switching frequency	f	0 1000 Hz
Hysteresis	Н	1 15 typ. 7.5 %
Reverse polarity protection		protected against reverse polarity
Short-circuit protection		pulsing
Voltage drop	$U_d$	≤3 V
Operating current	ΙL	0 200 mA
Off-state current	l <sub>r</sub>	0 0.5 mA typ. 0.01 mA
No-load supply current	$I_0$	≤ 9 mA
Indication of the switching state		LED, yellow
Standard conformity		

### Standard conformity

IEC / EN 60947-5-2:2004 Standards

## **Ambient conditions**

-25 ... 70 °C (248 ... 343 K) Ambient temperature Storage temperature -40 ... 85 °C (233 ... 358 K)

### **Mechanical specifications**

Connection type 5 m, PVC cable Core cross-section  $0.5 \text{ mm}^2$ Housing material Stainless steel Sensing face PBT IP67 Protection degree

### **General information**

Use in the hazardous area see instruction manuals Category

#### ATEX 3D

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with non-conducting combustible dust

Directive conformity 94/9/FG Standard conformity EN 50281-1-1 Protection via housing

Use is restricted to the following stated conditions

CE symbol

Ex-identification ⟨Ex⟩ II 3D IP67 T 94 °C X

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. General

The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

[Fett]Special conditions

Maintenance

Installation, Comissioning

The maximum permissible load current must be restricted to the values given in the following list. Maximum operating current IL

High load currents and load short-circuits are not permitted.

Maximum operating voltage UBmax The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Toleran-

ces are not permitted.

Maximum heating (Temperature rise)

dependant of the load current  $I_L$  and the max. operating voltage  $U_{Bmax}$ . Information can be taken from the following list. The maximum surface temperature at maximum ambient temperature

is given in the Ex identification of the apparatus.

24 °C at  $U_{Bmax}$ =60 V,  $I_{L}$ =200 mA at  $U_{Bmax}$ =60 V,  $I_{L}$ =100 mA 20 °C at  $U_{Bmax}$ =30 V,  $I_{L}$ =200 mA 19 °C

Protection from mechanical danger The sensor must not be mechanically damaged

Electrostatic charging Electrostatic charges on the metal housing components must be avoided. Dangerous electrostatic charges on the metal

housing components can be avoided by incorporating these components in the equipotential bonding.

Protection of the connection cable The connection cable must be prevented from being subjected to tension and torsional loading