






## **Model Number**

NBB2-12GM60-A2-3G-3D

## **Features**

- · 2 mm embeddable
- ATEX-approval for zone 2 and zone 22

## Connection



## **Accessories**


BF 12

Mounting flange, 12 mm

EXG-12

Quick mounting bracket with dead stop

## **Dimensions**



# **Technical Data**

General specifications		
Switching element function		PNP NO/NC
Rated operating distance	s <sub>n</sub>	2 mm
Installation		embeddable
Output polarity		DC
Assured operating distance	sa	0 1.62 mm
Reduction factor r <sub>Al</sub>		0.25
Reduction factor r <sub>Cu</sub>		0.15
Reduction factor r <sub>303</sub>		0.66
Nominal ratings		
Operating voltage	U <sub>B</sub>	10 30 V DC
Switching frequency	f	0 1000 Hz
Hysteresis	Н	typ. 5%
Reverse polarity protected		reverse polarity protected
Short-circuit protection		pulsing
Voltage drop	$U_d$	≤ 3 V
Operating current	ΙL	0 200 mA
Off-state current	l <sub>r</sub>	0 0.5 mA typ. 0.1 μA at 25 °C
No-load supply current	I <sub>0</sub>	≤ 20 mA
Indication of the switching state		LED, yellow
Ambient conditions		
Ambient temperature		-25 70 °C (-13 158 °F)

-40 ... 85 °C (-40 ... 185 °F) Storage temperature

#### Mechanical specifications

Connection type cable PVC, 2 m Core cross-section Housing material Sensing face Protection degree 0.14 mm<sup>2</sup> brass, nickel-plated PBT IP67

## General information

Use in the hazardous area see instruction manuals Category 3G; 3D

### Compliance with standards and directives

Standard conformity

EN 60947-5-2:2007 Standards IEC 60947-5-2:2007

## Approvals and certificates

UL approval	cULus Listed, General Purpose
CSA approval	cCSAus Listed, General Purpose
CCC approval	Products with a maximum operating voltage of ≤36 V do not bear a
	CCC marking because they do not require approval.

www.pepperl-fuchs.com

#### ATEX 3G (nA)

Instruction Manual electrical apparatus for hazardous areas

Device category 3G (nA) for use in hazardous areas with gas, vapour and mist

Directive conformity 94/9/EG

Standard conformity EN 60079-0:2006, EN 60079-15:2005

Ignition protection category "n" Use is restricted to the following stated conditions

(€ CE symbol

Ex-identification II 3G Ex nA IIC T6 X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Special conditions

Maintenance

Installation, Comissioning

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list. High load currents and load

short-circuits are not permitted.

Maximum operating voltage U<sub>Bmax</sub> The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per-

Maximum permissible ambient tempera-

ture T<sub>Umax</sub>

dependant of the load current  $I_L$  and the max. operating voltage  $U_{\mbox{\footnotesize Bmax}}$ 

Information can be taken from the following list.

at  $U_{Bmax}$ =30 V,  $I_{L}$ =200 mA 46 °C (114.8 °F) 51 °C (123.8 °F) at  $U_{Bmax}$ =30 V,  $I_{L}$ =100 mA 53 °C (127.4 °F) at  $U_{Bmax}$ =30 V,  $I_{L}$ =50 mA

The sensor must not be exposed to ANY FORM of mechanical danger. Protection from mechanical danger

Protection from UV light The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cable must be prevented from being subjected to tension and torsional loading.

Protection of the connection cable

www.pepperl-fuchs.com

#### ATEX 3D (tD)

Instruction Manual electrical apparatus for hazardous areas

**Device category 3D** for use in hazardous areas with combustible dust

Directive conformity 94/9/EG

Standard conformity EN 61241-0:2006, EN 61241-1:2004

Protection via housing "tD"

Use is restricted to the following stated conditions

CE symbol

Ex-identification (x) II 3D Ex tD A22 IP67 T80°C X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

ment.

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Special conditions

Maintenance

Installation, Comissioning

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage U<sub>Bmax</sub> The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

Maximum permissible ambient temperadependant of the load current  $I_L$  and the max. operating voltage  $U_{Bmax}$ .

ture T<sub>Umax</sub> Information can be taken from the following list. at U<sub>Rmax</sub>=30 V. I<sub>I</sub>=200 mA 46 °C (114.8 °F)

Protection from mechanical danger The sensor must not be exposed to ANY FORM of mechanical danger.

Protection from UV light The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

s used in internal areas.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cable must be prevented from being subjected to tension and torsional loading.

Protection of the connection cable

www.pepperl-fuchs.com