Inductive sensor

cUL us CE (\mathbf{m})


Model Number

NCB5-18GM40-Z0-3G-3D-10M

Features

- Comfort series
- 5 mm embeddable

Connection



Α	~	0	~	c	0	ri	0	c

BF 18 Mounting flange, 18 mm EXG-18 Quick mounting bracket with dead stop


Pepperl+Fuchs Group

Subject to modifications without notice USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com







Technical Data

General specifications			
Switching element function		DC	NO
Rated operating distance	s _n	5 mm	
Installation		embedda	able
Output polarity		DC	
Assured operating distance	sa	0 4.05	5 mm
Reduction factor r _{Al}		0.37	
Reduction factor r _{Cu}		0.33	
Reduction factor r ₃₀₄		0.7	
Nominal ratings			
Operating voltage	UB	5 60 V	
Switching frequency	f	0 350	
Hysteresis	н	1 10 t	typ. 5 %
Reverse polarity protected		tolerant	
Short-circuit protection		pulsing	
Voltage drop	Ud	≤5 V	
Operating current	۱ _L	2 100	mA
Lowest operating current	l _m	2 mA	
Off-state current	l _r	0 0.5	
Indication of the switching state		all direct	ion LED, yellow
Ambient conditions			
Ambient temperature		-25 70) °C (-13 158 °F)
Mechanical specifications			
Connection type		cable PV	/C , 10 m
Cable version		PA	
Core cross-section		0.34 mm	•
Housing material			s steel 1.4305 / AISI 303
Sensing face		PBT	
Protection degree		IP67	
General information			
Use in the hazardous area		see instr	uction manuals
Category		3G; 3D	
Compliance with standards and d	irective	S	
Standard conformity			
Standards			17-5-2:2007 47-5-2:2007
Approvals and certificates		IEC 0094	+1-0-2.2001
UL approval			isted, General Purpose
CSA approval CCC approval			Listed, General Purpose by China Compulsory Certification (CCC)

1

ATEX 3G (nA)					
Instruction					
Dovice esterony 2C (nA	`				

Device category 3G (nA)	for use in hazardous areas with gas, vapour and mist 94/9/EG
Directive conformity Standard conformity	94/9/EG EN 60079-0:2006, EN 60079-15:2005
Standard conformity	Ignition protection category "n"
	Use is restricted to the following stated conditions
CE symbol	
Ex-identification	⟨͡↔⟩ II 3G Ex nA IIC T6 X
	The Ex-relevant identification may also be printed on the accompanying adhesive label.
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.
	The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed.
	If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immedi- ate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from
	are vicinity of the sensor: The background surface to which the adhesiverable is to be applied must be clear and the norm grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas.
	Repairs to these apparatus are not possible.
Special conditions	
Maximum operating current IL	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load
	short-circuits are not permitted. The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per-
Maximum operating voltage U _{Bmax}	missible.
Maximum permissible ambient tempera-	dependant of the load current I _L and the max. operating voltage $U_{Bmax.}$
ture T _{Umax}	Information can be taken from the following list.
at U _{Bmax} =60 V, I _L =100 mA	50 °C (122 °F)
at U _{Bmax} =60 V, I _L =50 mA	56 °C (132.8 °F)
at U _{Bmax} =60 V, I _L =25 mA	60 °C (140 °F)
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.

Manual electrical apparatus for hazardous areas

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com



ATEX 3D (tD)						
Instruction	Manual electrical apparatus for hazardous areas					
Device category 3D Directive conformity Standard conformity	for use in hazardous areas with combustible dust 94/9/EG EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD" Use is restricted to the following stated conditions					
CE symbol	(E					
Ex-identification	II 3D Ex tD A22 IP67 T80°C X The Ex-relevant identification may also be printed on the accompanying adhesive label.					
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip- ment.					
	The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!					
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. If the Ex-relevant identification is printed exclusively on the adhesive label provided, this label must be affixed in the immedi- ate vicinity of the sensor! The background surface to which the adhesivelabel is to be applied must be clean and free from grease! The applied label must be durable and remain legible, with due consideration of the possibility of chemical corrosion!					
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.					
Special conditions						
Maximum operating current I_L	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.					
Maximum operating voltage $\mathrm{U}_{\mathrm{Bmax}}$	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.					
Maximum permissible ambient tempera- ture T _{Umax}	dependant of the load current I _L and the max. operating voltage U _{Bmax.} Information can be taken from the following list.					
at U _{Bmax} =60 V, I _L =100 mA	50 °C (122 °F)					
at U _{Bmax} =60 V, I _L =50 mA	56 °C (132.8 °F)					
at U _{Bmax} =60 V, I _L =25 mA	60 °C (140 °F)					
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.					
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.					
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.					
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.					

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



3