

AC	ces	sor	les

BF 18 Mounting flange, 18 mm EXG-18 Quick mounting bracket with dead stop

Release date: 2012-05-31 14:29 Date of issue: 2012-05-31 211268_eng.xml

General specifications			
Switching element function		DC N	C
Rated operating distance	Sn	5 mm	5
Installation	°n	flush	
Output polarity		DC	
Assured operating distance	Sa	0 4.05 mm	
Reduction factor rAI	a	0.37	
Reduction factor r _{Cu}		0.33	
Reduction factor r ₃₀₄		0.7	
Nominal ratings			
Operating voltage	UB	5 60 V	
Switching frequency	f	0 350 Hz	
Hysteresis	Н	1 10 typ. 5	%
Reverse polarity protected		tolerant	
Short-circuit protection		pulsing	
Voltage drop	Ud	≤5 V	
Operating current	ΙL	2 100 mA	
Lowest operating current	Im	2 mA	
Off-state current	l _r	0 0.5 mA ty	
Indication of the switching state		all direction L	ED, yellow
Ambient conditions			
Ambient temperature		-25 70 °C (-13 158 °F)
Mechanical specifications			
Connection type		cable PVC , 2	m
Cable version		PA	
Core cross-section		0.34 mm ²	
Housing material			el 1.4305 / AISI 303
Sensing face		PBT	
Protection degree		IP67	
General information			
Use in the hazardous area		see instruction	n manuals
Category		3G; 3D	
Compliance with standards and directly and d	rectives		
Standard conformity			
Standards		EN 60947-5-2	
Approvale and cortificates		120 00947-5-4	2.2007
Approvals and certificates			
UL approval			General Purpose
CSA approval		cCSAus Listed, General Purpose	
CCC approval		Certified by C	hina Compulsory Certification (CCC)

Subject to modifications without notice

Pepperl+Fuchs Group USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

776-4411 Singapo chs.com fa-info@sq.i

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



ATEX 3G (nA)	
Instruction	Manual electrical apparatus for hazardous areas
Device category 3G (nA)	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-0:2006, EN 60079-15:2005 Ignition protection category "n"
	Use is restricted to the following stated conditions
CE symbol	
Ex-identification	(E) II 3G Ex nA IIC T6 X The Ex-significant identification is on the enclosed adhesive label
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas.
Maintenance	Repairs to these apparatus are not possible.
Special conditions	
Maximum operating current I_L	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.
Maximum operating voltage U_{Bmax}	The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per- missible.
Maximum permissible ambient tempera- ture T _{Umax}	dependant of the load current I_L and the max. operating voltage $U_{Bmax.}$ Information can be taken from the following list.
at U _{Bmax} =60 V, I _L =100 mA	53 °C (1274 °F)
at U _{Bmax} =60 V, I _L =50 mA	58 °C (136.4 °F)
at U _{Bmax} =60 V, I _L =25 mA	61 °C (141.8 °F)
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.



ATEX 3D (tD)	
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD" Use is restricted to the following stated conditions
CE symbol	(€)
Ex-identification	⟨E₂⟩ II 3D Ex tD A22 IP67 T80°C X The Ex-significant identification is on the enclosed adhesive label
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-
	ment. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Maximum operating current IL	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.
Maximum operating voltage U_{Bmax}	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.
Maximum permissible ambient tempera- ture T _{Umax}	dependant of the load current I_L and the max. operating voltage $U_{Bmax.}$ Information can be taken from the following list.
at U _{Bmax} =60 V, I _L =100 mA	53 °C (127.4 °F)
at U _{Bmax} =60 V, I _L =50 mA	58 °C (136.4 °F)
at U _{Bmax} =60 V, I _L =25 mA	61 °C (141.8 °F)
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.

