



CE

Model Number


NBN3-F31-Z8-K-3G-3D

Features


- Direct mounting on standard actuators
- Compact and stable housing
- **Fixed setting**
- Satisfies machinery directive

Connection

Z8-K



Dimensions



General specifications			
Switching element function		PNPDual Make function	
Rated operating distance	s_n	3 mm	
Installation		flush mountable	
Output polarity		DC	
Assured operating distance	sa	0 2.43 mm	
Reduction factor r _{Al}		0.5	
Reduction factor r _{Cu}		0.4	
Reduction factor r _{V2A}		1	
Reduction factor re		11	

Reduction factor r _{St37}	
lominal ratings	
Operating voltage	
Switching frequency	

tommu rutings		
Operating voltage	U_B	6 60 V
Switching frequency	f	0 500 Hz
Hysteresis	Н	typ. 5 %
Reverse polarity protection		tolerant
Short-circuit protection		no
Voltage drop	U_d	≤ 6 V
Operating current	ΙL	4 100 mA
Off-state current	l _r	0 1 mA typ. 0.7 mA
Indication of the switching state		LED, yellow

|--|

Tightening torque, fixing screws 0.4 Nm

Ambient conditions

Ambient temperature -25 ... 70 °C (248 ... 343 K)

Mechanical specifications

Connection (system side) 5 m, PVC cable 0.75 mm² Core cross-section (system side) PBT Housing material Sensing face PBT Protection degree IP67

General information

see instruction manuals Use in the hazardous area Category

Compliance with standards and directi-

Standard conformity

EN 60947-5-2:2007 Standards IEC 60947-5-2:2007 ATEX 3G (nA) Instruction

Manual electrical apparatus for hazardous areas

Device category 3G (nA) for use in hazardous areas with gas, vapour and mist

Directive conformity 94/9/EG

Standard conformity EN 60079-0:2006, EN 60079-15:2005

Ignition protection category "n"

Use is restricted to the following stated conditions

CE symbol (€

Ex-identification (x) II 3G Ex nA IIC T6 X

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Maintenance No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Special conditions

Maximum operating current I_L The maximum permissible load current must be restricted to the values given in the following list. High load currents and

load short-circuits are not permitted.

permissible

Maximum permissible ambient tempera-dependant of the load current I_L and the max. operating voltage U_{Bmax}.

ture T_{Umax} Information can be taken from the following list.

 $\begin{array}{lll} \text{at U}_{\text{Bmax}}\text{=}60 \text{ V, I}_{\text{L}}\text{=}100 \text{ mA} & 47 \text{ °C} \\ \text{at U}_{\text{Bmax}}\text{=}60 \text{ V, I}_{\text{L}}\text{=}50 \text{ mA} & 55 \text{ °C} \\ \text{at U}_{\text{Bmax}}\text{=}60 \text{ V, I}_{\text{L}}\text{=}25 \text{ mA} & 60 \text{ °C} \\ \end{array}$

Protection from mechanical danger

The sensor must not be exposed to ANY FORM of mechanical danger.

Protection from UV light The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the

sensor is used in internal areas.

Protection of the connection cable The connection cable must be prevented from being subjected to tension and torsional loading.

ATEX 3D (tD)

Instruction Manual electrical apparatus for hazardous areas

Device category 3D for use in hazardous areas with combustible dust

Directive conformity 94/9/EG

Standard conformity EN 61241-0:2006, EN 61241-1:2004

Protection via housing "tD"

Use is restricted to the following stated conditions

 ϵ CE symbol

Ex-identification ⟨EX⟩ II 3D Ex tD A22 IP67 T80°C X

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the General

equipment.

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Maintenance

Repairs to these apparatus are not possible.

Special conditions

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list.

High load currents and load short-circuits are not permitted.

Maximum operating voltage UBmax The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Toleran-

ces are not permitted.

Maximum permissible ambient tempera -dependant of the load current I_L and the max. operating voltage U_{Bmax},

Information can be taken from the following list. at U_{Bmax} =60 V, I_{L} =100 mA 47 °C

55 °C at U_{Bmax} =60 V, I_{L} =50 mA at U_{Bmax} =60 V, I_{L} =25 mA 60 °C

Protection from mechanical danger The sensor must not be exposed to ANY FORM of mechanical danger.

Protection from UV light The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the

sensor is used in internal areas.

Electrostatic charging Sliding contact discharges must be avoided.

Protection of the connection cable The connection cable must be prevented from being subjected to tension and torsional loading.

fa-info@us.pepperl-fuchs.com

www.pepperl-fuchs.com