Inductive sensor

NBN3-F31-E8-K-K-3G-3D



CE

Model Number


NBN3-F31-E8-K-K-3G-3D

Features

- Direct mounting on standard actuators ٠
- Compact and stable housing •
- **Fixed setting** •
- Satisfies machinery directive

Connection





Release date: 2009-10-23 16:37 Date of issue: 2009-10-23 211847_ENG.xml


Subject to modifications without notice Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Dimensions



Technical Data General specifications

General specifications		
Switching element function		PNPDual Make function
Rated operating distance	s _n	3 mm
Installation		flush mountable
Output polarity		DC
Assured operating distance	sa	0 2.43 mm
Reduction factor rAI		0.5
Reduction factor r _{Cu}		0.4
Reduction factor rV2A		1
Reduction factor r _{St37}		1.2
Nominal ratings		
Operating voltage	U _B	10 30 V
Switching frequency	f	0 500 Hz
Hysteresis	Н	typ. 5 %
Reverse polarity protection		all connections
Short-circuit protection		pulsing
Voltage drop	Ud	≤ 3 V
Operating current	ΙL	0 100 mA
Off-state current	l _r	0 0.5 mA typ. 0.1 μA at 25 °C
No-load supply current	lo	≤ 25 mA
Operating voltage display	•	LED, green
Indication of the switching state		LED, yellow
Valve status indication		LED, yellow
Ambient conditions		
Ambient temperature		-25 70 °C (248 343 K)
Mechanical specifications		
Connection (system side)		5 m, PVC cable
Core cross-section (system side)		0.75 mm ²
Connection (valve side)		0.5 m, PVC cable
Core cross-section (valve side)		0.75 mm ²
Housing material		PBT
Sensing face		PBT
Protection degree		IP67
General information		
Use in the hazardous area		see instruction manuals
Category		3G; 3D
Compliance with standards and	directi-	
ves		
Standard conformity		
Standards		EN 60947-5-2:2007
		IEC 60947-5-2:2007

ATEX 3G (nA)	
Instruction	Manual electrical apparatus for hazardous areas
Device category 3G (nA)	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-0:2006, EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions
CE symbol	CE
Ex-identification	🐼 II 3G Ex nA IIC T6 X
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. Each sensor circuit can be operated at the stated maximum values, with simultaneous operation of the valve circuits. The maximum values of the connected valve circuits, must be observed.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Maximum operating current I_L	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.
Maximum operating voltage UBmax	The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not permissible.
Maximum permissible ambient temperature T _{Umax}	a-dependant of the load current I _L and the max. operating voltage ${\sf U}_{\sf Bmax.}$ Information can be taken from the following list.
at U _{Bmax} =30 V, I _L =100 mA	43 °C
at U _{Bmax} =30 V, I _L =50 mA	47 °C
Maximum values of the valve circuit	U _i = 32 V; I _i = 240 mA
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.

ATEX 3D (tD)	
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD" Use is restricted to the following stated conditions
CE symbol	CE
Ex-identification	🐼 II 3D Ex tD A22 IP67 T80°C X
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equipment. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. Each sensor circuit can be operated at the stated maximum values, with simultaneous operation of the valve circuits. The maximum values of the connected valve circuits, must be observed.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Maximum operating current I_L	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.
Maximum operating voltage UBmax	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Toleran- ces are not permitted.
Maximum permissible ambient temper ture	a-dependant of the load current I _L and the max. operating voltage $U_{Bmax.}$ Information can be taken from the following list.
at U _{Bmax} =30 V, I _L =100 mA	43 °C
at U _{Bmax} =30 V, I _L =50 mA	47 °C
Maximum values of the valve circuit	U _i = 32 V; I _i = 240 mA
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Sliding contact discharges must be avoided.
Protection of the connection cable	The connection cable must be prevented from being subjected to tension and torsional loading.

 Subject to modifications without notice

 Pepperl+Fuchs Group
 US

 www.pepperl-fuchs.com
 fa-info

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



3