

Dimensions





Technical Data General specification

General specifications			
Switching element function		PNP N	O/NC
Rated operating distance	Sn	5 mm	
Installation		embeddabl	e
Output polarity		DC	
Assured operating distance	sa	0 4.05 m	m
Reduction factor r _{Al}		0.25	
Reduction factor r _{Cu}		0.15	
Reduction factor r ₃₀₃		0.66	
Nominal ratings			
Operating voltage	UB	10 30 V	DC
	f	0 800 Hz	1
Reverse polarity protected		reverse pol	arity protected
Short-circuit protection		pulsing	
	U _d	≤ 3 V	
	IL .	0 200 m	
	l _r		typ. 0.1 μA at 25 °C
	l ₀	≤ 20 mA	
Indication of the switching state		LED, yellow	V
Ambient conditions			
Ambient temperature		-25 70 °C	C (-13 158 °F)
Mechanical specifications			
Connection type		Device con	nector M12 x 1, 4-pin
Housing material		brass, nick	el-plated
Sensing face		PBT	
Protection degree		IP67	
General information			
Use in the hazardous area		see instruc	tion manuals
Category		3G; 3D	
Compliance with standards and dire	ectives		
Standard conformity			
Standards		EN 60947-8	5-2:2007
		IEC 60947-	5-2:2007
Approvals and certificates			
UL approval		cULus Liste	ed, General Purpose
CSA approval		cCSAus Lis	sted, General Purpose
CCC approval			ith a maximum operating voltage of \leq 36 V do not bear a ng because they do not require approval.

4

BF 18

EXG-18

V1-G

V1-W

Subject to modifications without notice Pepperl+Fuchs Group

www.pepperl-fuchs.com

WH

BU

ΒK

Accessories

Mounting flange, 18 mm

Quick mounting bracket with dead stop

4-pin, M12 female field-attachable connector

4-pin, M12 female field-attachable connector

(white)

(blue)

(black)

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

ATEX 3G (nA)	
Instruction	Manual electrical approximation for barandous areas
Instruction	Manual electrical apparatus for hazardous areas
Device category 3G (nA)	for use in hazardous areas with gas, vapour and mist
Directive conformity	94/9/EG
Standard conformity	EN 60079-0:2006, EN 60079-15:2005
	Ignition protection category "n"
	Use is restricted to the following stated conditions
CE symbol	
Ex-identification	🐼 II 3G Ex nA IIC T6 X
	The Ex-significant identification is on the enclosed adhesive label
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed.
	The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease!
	The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas.
	Repairs to these apparatus are not possible.
Special conditions	
Maximum operating current I_L	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.
Maximum operating voltage U_{Bmax}	The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not per- missible.
Maximum permissible ambient tempera-	dependant of the load current I _L and the max. operating voltage $U_{Bmax.}$
ture T _{Umax}	Information can be taken from the following list.
at U _{Bmax} =30 V, I _L =200 mA	45 °C (113 °F)
at U _{Bmax} =30 V, I _L =100 mA	49 °C (120.2 °F)
at U _{Bmax} =30 V, I _L =50 mA	50 °C (122 °F)
at U _{Bmax} =30 V, I _L =25 mA	51 °C (123.8 °F)
Plug connector	The plug connector must not be disconnected under voltage. The proximity switch is marked as follows: "DO NOT DISCON- NECT UNDER VOLTAGE!" When the plug connector is disconnected the ingress of dirt into the inner areas (i.e. the areas, which are not accessible in the plugged-in condition) must be prevented.
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.



ATEX 3D (tD)	
Note	This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note the ex-marking on the sensor or on the enclosed adhesive label
Instruction	Manual electrical apparatus for hazardous areas
Device category 3D	for use in hazardous areas with combustible dust
Directive conformity	94/9/EG
Standard conformity	EN 61241-0:2006, EN 61241-1:2004 Protection via housing "tD" Use is restricted to the following stated conditions
CE symbol	(€
Ex-identification	(₺) II 3D Ex tD A22 IP67 T80°C X The Ex-significant identification is on the enclosed adhesive label
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip- ment. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to!
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied must be clean, flat and free from grease! The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Special conditions	
Maximum operating current IL	The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.
Maximum operating voltage U_{Bmax}	The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted.
Maximum permissible ambient tempera- ture T _{Umax}	dependant of the load current I_L and the max. operating voltage $U_{Bmax.}$ Information can be taken from the following list.
at U _{Bmax} =30 V, I _L =200 mA	45 °C (113 °F)
at U _{Bmax} =30 V, I _L =100 mA	49 °C (120.2 °F)
at U _{Bmax} =30 V, I _L =50 mA	50 °C (122 °F)
at U _{Bmax} =30 V, I _L =25 mA	51 °C (123.8 °F)
Plug connector	The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented.(i.e. the area that is inaccessible when the connector is inserted) The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting accessory from Pepperl + Fuchs).
Protection from mechanical danger	The sensor must not be exposed to ANY FORM of mechanical danger.
Protection from UV light	The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



3