








Model Number

NBB4-12GM50-E2-V1-3G-3D

Features

- Increased operating distance
- 4 mm flush
- ATEX-approval for zone 2 and zone 22

Connection



Pinout




Wire colors in accordance with EN 60947-5-2

1	BN	(brown
2	WH	(white)
3	BU	(blue)
4	BK	(black)

Accessories

Dimensions



Technical Data

General specifications					
Switching element function		PNP	NO		
Rated operating distance	s _n	4 mm			
Installation		flush			
Output polarity		DC			
Assured operating distance	sa	0 3.24 n	nm		
Reduction factor r _{Al}		0.45			
Reduction factor r _{Cu}		0.35			
Reduction factor r ₃₀₄		0.7			

Nominarratings		
Operating voltage	U _B	10 30 V DC
Switching frequency	f	0 1000 Hz
Hysteresis	Н	typ. 5 %
Reverse polarity protected		reverse polarity protected
Short-circuit protection		pulsing
Voltage drop	U_d	≤3 V
Operating current	IL.	0 150 mA
Off-state current	l _r	0 0.5 mA typ. 0.1 μA at 25 °C
No-load supply current	lo.	≤ 15 mA

Multihole-LED, yellow

Indication of the switching state Functional safety related parameters

	-		
MTTF _d			1820 a
Mission Time	e (T _M)		20 a
Diagnostic C	Coverage (DC	()	0 %

Ambient conditions

Ambient temperature -25 ... 70 °C (-13 ... 158 °F)

Mechanical specifications

Connection type Device connector M12 x 1, 4-pin Cable version Housing material PBT brass, nickel-plated Sensing face Protection degree IP67

General information

Use in the hazardous area see instruction manuals

Category 3G; 3D

Compliance with standards and directives

Standard conformity

EN 60947-5-2:2007 Standards IEC 60947-5-2:2007

Approvals and certificates

UL approval cULus Listed, General Purpose cCSAus Listed, General Purpose CSA approval CCC approval Products with a maximum operating voltage of ≤36 V do not bear a CCC marking because they do not require approval.

Pepperl+Fuchs Group

www.pepperl-fuchs.com

ATEX 3G (nA)

General

Instruction Manual electrical apparatus for hazardous areas

Device category 3G (nA) for use in hazardous areas with gas, vapour and mist Directive conformity 94/9/EG

Standard conformity EN 60079-0:2006, EN 60079-15:2005

Ignition protection category "n"

Use is restricted to the following stated conditions $C \in I$

CE symbol

Ex-identification

The Ex-significant identification is on the enclosed adhesive label

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction! The special conditions must be observed!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied

must be clean, flat and free from grease!

The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Special conditions

Protection from UV light

Maintenance

Maximum operating current IL The maximum permissible load current must be restricted to the values given in the following list. High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax}

The maximum permissible operating voltage UB max is restricted to the values in the following list. Tolerances are not permissible

Maximum permissible ambient tempera-

ture T_{Umax} Information can be taken from the following list 47 °C (116.6 °F) at U_{Bmax} =30 V, I_{L} =150 mA

at U_{Bmax} =30 V, I_{L} =100 mA 51 °C (123.8 °F)

53 °C (127.4 °F) at U_{Bmax} =30 V, I_{L} =50 mA Plug connector

The plug connector must not be disconnected under voltage. The proximity switch is marked as follows: "DO NOT DISCONNECT UNDER VOLTAGE!" When the plug connector is disconnected the ingress of dirt into the inner areas (i.e. the areas,

which are not accessible in the plugged-in condition) must be prevented.

dependant of the load current I_L and the max. operating voltage U_{Bmax} .

The sensor must not be exposed to ANY FORM of mechanical danger. Protection from mechanical danger

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the Electrostatic charging

mechanical housing components can be avoided by incorporating these in the equipotential bonding

ATEX 3D (tD)

This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004 Note

Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

for use in hazardous areas with combustible dust Device category 3D

Directive conformity 94/9/EG

EN 61241-0:2006, EN 61241-1:2004 Standard conformity

Protection via housing "tD"

Use is restricted to the following stated conditions

CE symbol (€

Ex-identification

 $\mbox{\fontfamily{\fontfamily{180}}}$ II 3D Ex tD A22 IP67 T80°C X The Ex-significant identification is on the enclosed adhesive label

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The maximum surface temperature has been determined in accordance with method A without a dust layer on the equip-

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The adhesive label provided must be affixed in the immediate vicinity of the sensor! The surface to which the label is applied

must be clean, flat and free from grease!

The affixed adhesive label must be readable and durable, taking account of the possibility of chemical corrosion!

No changes can be made to apparatus, which are operated in hazardous areas.

Repairs to these apparatus are not possible.

Special conditions

Maintenance

The maximum permissible load current must be restricted to the values given in the following list. Maximum operating current I_I

High load currents and load short-circuits are not permitted.

Maximum operating voltage U_{Bmax} The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances

are not permitted.

Maximum permissible ambient tempera-

ture T_{Umax}

dependant of the load current IL and the max. operating voltage UBmax

Information can be taken from the following list.

at U_{Bmax} =30 V, I_{L} =150 mA 47 °C (116.6 °F) 51 °C (123.8 °F) at U_{Bmax} =30 V, I_{L} =100 mA at U_{Bmax} =30 V, I_{L} =50 mA 53 °C (127.4 °F)

The plug connector must not be withdrawn under voltage. The proximity switch is identified as follows: "WARNING - DO NOT SEPARATE WHEN ENERGIZED". With the plug connector disconnected, soiling of the internal area must be prevented. (i.e. Plug connector

the area that is inaccessible when the connector is inserted)

The plug connection can only be separated using a tool. This is achieved by using the locking protection V1-Clip (Mounting

accessory from Pepperl + Fuchs).

Protection from mechanical danger

Protection from UV light

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor

is used in internal areas.

Electrostatic charging Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.

www.pepperl-fuchs.com