











Model Number

VDM28-8-L/73c/136

Distance sensor with 4-pin, M12 x 1 connector

Features


- · Distance measurement using object
- Measuring method PRT (Pulse Ranging Technology)
- Accurate, clear, and reproducible measuring results
- Minimal black/white difference
- · Red laser as the light emitter
- Version with laser class 2

Product information


The VDM28 distance measurement device employs Pulse Ranging Technology (PRT). It has a repeat accuracy of 5 mm with an operating range of 0.2 ... 8 m and an absolute accuracy of 25 mm.

The compact housing of the Series 28 photoelectric sensors, with dimensions of 88 mm (height), 26 mm (width) and 54 mm (depth), make it the smallest device available in its class.

Dimensions



Electrical connection




- O = Light on
- = Dark on

Pinout



Indicators/operating means



1	Operating display	green	
2	Signal display yellow		
3	TEACH-IN button		
4	4 Mode rotary switch5 Laser output		
5			

Technical data		
General specifications		
Measurement range		0.2 8 m
Reference target		Kodak white (90%)
Light source		laser diode typ. service life 85,000 h at Ta = +25 °C
Light type		modulated visible red light
Laser nominal ratings		
Note		LASER LIGHT , DO NOT STARE INTO BEAM
Laser class		2
Wave length		660 nm
Beam divergence		1 mrad 5 ns
Pulse length Repetition rate		250 kHz
max. pulse energy		< 4 nJ
Angle deviation		max. ± 2°
Measuring method		Pulse Ranging Technology (PRT)
Diameter of the light spot		< 10 mm at a distance of 8 m at 20 °C
Ambient light limit		50000 Lux
Temperature influence		typ. ≤ 0.25 mm/K
Functional safety related param	eters	71.
MTTF _d		200 a
Mission Time (T _M)		10 a
Diagnostic Coverage (DC)		0 %
Indicators/operating means		
Operating display		LED green
Function display		2 LEDs yellow for switching state
TEACH-IN indication		TEACH-IN: LED green/yellow equiphase flashing; 2.5 Hz
		Teach Error:LED green/yellow non equiphase flashing; 8.0
Controls		5-step rotary switch for operating modes selection (threshol
		setting and operating modes)
Controls		Switch for setting the threshold values
Electrical specifications		
Operating voltage	U_B	10 30 V DC , class 2
Ripple		10 % within the supply tolerance
No-load supply current	I ₀	≤ 125 mA / 24 V DC
Time delay before availability	t _v	1.5 s
Output		
Signal output		2 push-pull (4 in 1) outputs, short-circuit protected, reverse polarity protected
Switching voltage		max. 30 V DC
Switching current		max. 100 mA
Switching frequency	f	50 Hz
Response time	•	10 ms
Measurement accuracy		is inc
Absolute accuracy		± 25 mm
Repeat accuracy		< 5 mm
Ambient conditions		V O Hilli
Ambient temperature		-30 50 °C (-22 122 °F)
Storage temperature		-30 70 °C (-22 122 °F)
· '		-50 70 0 (-22 150 1)
Mechanical specifications		IP65
Protection degree Connection		
Material		connector M12 x 1, 4-pin
Housing		Plastic ABS
Optical face		Plastic ABS Plastic pane
Mass		90 g
Compliance with standards and	directi	
Ves Directive conformity		EMC Directive 2004/108/EC
Directive conformity Standard conformity		LIVIO DIIGGUVG 2004/ 100/LO
Product standard		EN 60947-5-2:2007 IEC 60947-5-2:2007
Laser class		IEC 60847-3-2.2007 IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007
Approvals and certificates Protection class		II, rated voltage ≤ 250 V AC with pollution degree 1-2 acco
		ding to IEC 60664-1
UL approval		cULus Listed, Class 2 Power Source, Type 1 enclosure

Accessories

OMH-05

Mounting aid for round steel ø 12 mm or sheet 1.5 mm \dots 3 mm

OMH-07

Mounting aid for round steel ø 12 mm or sheet 1.5 mm ... 3 mm

OMH-21

Mounting bracket

OMH-22

Mounting bracket

OMH-MLV11-K

dove tail mounting clamp

OMH-RLK29

Mounting bracket

OMH-RLK29-HW

Mounting bracket for rear wall mounting

OMH-RL28-C

Weld slag cover model

OMH-K01

dove tail mounting clamp

OMH-K03


dove tail mounting clamp

OMH-VDM28-01

Metal enclosure for inserting protective panes or apertures

Other suitable accessories can be found at www.pepperl-fuchs.com

Curves/Diagrams



Preferences

Teach-In:

You can use the rotary switch to select the output Q1 or Q2 and the relevant switching threshold A or B for teaching in.

The yellow LEDs indicate the current state of the selected output.


To store a switching threshold (distance measured value), press and hold the "SET" button until the yellow and green LEDs flash in phase (approx. 2 s). Teach-In starts when the "SET" button is released.

A successful Teach-In is indicated by rapidly alternating flashing (2.5 Hz) of the yellow and green LEDs.

An unsuccessful Teach-In is indicated by alternating flashing (8 Hz) of the yellow and green LEDs.

After an unsuccessful Teach-In, the sensor continues to operate with the previous valid setting after the relevant visual fault signal is issued.

Different switching modes can be defined by teaching in the relevant distance measured values for the switching thresholds A and B:



Every taught-in switching threshold can be retaught (overwritten) by pressing the SET button again.

Pressing and holding the "SET" button for > 5 s completely deletes the taught-in value. The yellow and green LEDs go out simultaneously to indicate that this procedure has been completed.

Default setting:

In general, no switching points are set at the factory. The outputs are switched to low.

Reset to default settings:

- · Set the rotary switch to the "RUN" position
- Press and hold the "SET" button until the yellow and green LEDs stop flashing in phase (approx. 10 s)
- If the green LED lights up, the procedure is complete.

Error messages:

- Short circuit: In the event of a short circuit at the sensor output, the green LED flashes with a frequency of approx. 4 Hz.
- Teach error: In the event of a teach error, the yellow and green LEDs flash alternately with a frequency of approx. 8 Hz.

\bigcirc

Note!

The difference in the taught-in distance measured values for the switching thresholds A and B must be greater than the switching hysteresis set in the

On delivery, the switching hysteresis is 15 mm.

If the difference in the taught-in measured values is the same as or smaller than the set switching hysteresis, the sensor will visually signal an unsuccessful Teach-In. The last distance measured value that was taught in will not be adopted by the sensor.

Select a new distance measured value for switching threshold A or B with a greater difference between the switching thresholds.

Teach in this distance measured value on the sensor again.

www.pepperl-fuchs.com

Laser notice laser class 2

- The irradiation can lead to irritation especially in a dark environment. Do not point at people!
- Caution: Do not look into the beam!
- Maintenance and repairs should only be carried out by authorized service personnel!
- Attach the device so that the warning is clearly visible and readable.
- Caution Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

EPPERL+FUCHS