



CE

# **Model Number**

## SBL-8-H-900-SL-V-Z-4871

Background suppression sensor with 4-pin, M12 x 1 connector and fixed cable with 4-pin, M12 socket

## **Features**

- ٠ Diffused mode with background suppression
- ٠ For installation between the rollers on a roller conveyor
- ٠ Pull-in/Drop-out delay can be set
- Minimal black/white difference ٠
- Protection degree IP65
- Can be connected in series


# **Product information**


Sensors of the SBL series are used to easily control material flow on roller conveyors in material handling and other branches.

The SBL series is a precise background suppression sensor according to the 3 element method. The sensor features superior background suppression and a very good ambient light immunity. Material and transport container of all colors and opacities are reliably detected.


The special design allows the sensor to be mounted between the rollers of a roller conveyor or any other conveying unit. Mounting between the rollers is easy and protects the sensor.








### **Electrical connection**






# **Pinout**



# Indicators/operating means



1	Signal display	yellow
2	Sensing range adjuster	

Subject to modifications without notice Pepperl+Fuchs Group

USA: +1 330 486 0001 www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776-4411 fa-info@pepperl-fuchs.com

Copyright Pepperl+Fuchs Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

40 ... 900 mm

40 ... 340 mm 40 ... 900 mm

340 ... 900 mm

IRED

< 10 %

At 20°C:

1100 a

20 a 0 %

UB

I<sub>0</sub>

standard white 200 mm x 200 mm

modulated infrared light, 880 nm

max. 38 sensors per line

Detection range adjuster

24 V DC -5% / +10%

max. 10 %

dark on

5 ms 0 ... 2000 ms

max. 115 mA

max 30 V DC

max. 200 mA 100 Hz

approx. 60 mm at detection range 900 mm

LED yellow: lights when object is detected

Adjuster for switch-off delay and switch-on delay

1 PNP, short-circuit protected, reverse polarity protected

continuous light 30000 Lux, Fluorescent lamp 5000 Lux

### **Technical data**

### General specifications Detection range Detection range min. Detection range max Adjustment range Reference target Light source Light type Black/White difference (6 %/90 %) Diameter of the light spot Cascadability Ambient light limit Functional safety related parameters $\mathsf{MTTF}_{\mathsf{d}}$ Mission Time (T<sub>M</sub>) Diagnostic Coverage (DC) Indicators/operating means Function display Controls Controls **Electrical specifications** Operating voltage Ripple No-load supply current Output Switching type Signal output Switching voltage Switching current Switching frequency Response time On-delay Off-delay Pneumatic output Type of valve Operating pressure Medium Ambient conditions Ambient temperature Storage temperature Mechanical specifications Protection degree Connection

0 ... 2000 ms 2/3 way valve currentless closed 0 ... 7 bar (0 ... 101.5 psi) air -20 ... 50 °C (-4 ... 122 °F) -30 ... 60 °C (-22 ... 140 °F) IP65 connector M12 x 1, 4-pin ; Connecting cable with Socket, straight M12 x 1 ; Length: 2200 mm Material Housing plastic Optical face plastic lens Mass approx. 200 g Compliance with standards and directives EMC Directive 2004/108/EC Directive conformity Standard conformity Product standard EN 60947-5-2:2007 IEC 60947-5-2:2007 Shock and impact resistance IEC / EN 60068. half-sine, 40 g in each X, Y and Z directions Vibration resistance IEC / EN 60068-2-6. Sinus. 10 -1000 Hz, 10 g in each X, Y and Z directions Approvals and certificates UL approval cULus Listed, Class 2 Power Source, Type 1 enclosure CCC approval Products with a maximum operating voltage of  $\leq$ 36 V do not

SBL-8-H-900-SL-V-Z-4871

_	
	Accessories
	OMH-SBL-01 Mounting bracket for sensors of SBL se- ries
	V1-G-2M-PVC Cable socket, M12, 4-pin, PVC cable
	V1-G-5M-PVC Cable socket, M12, 4-pin, PVC cable
	V1-W-2M-PUR Cable socket, M12, 4-pin, PUR cable
	V1-W-5M-PUR Cable socket, M12, 4-pin, PUR cable
	V1S-TEE-V1/V1S T-Distributor, M12 connector to M12 so- cket/connector
	Schraubendreher 0,5 x 3,0 mm Screwdriver
	Additional accessories can be found in the Internet.

PEPPERL+FUCHS


2


bear a CCC marking because they do not require approval.

Copyright Pepperl+Fuchs



## **Curves/Diagrams**





# **Additional Information**

### Intended use:

The transmitter and receiver are located in the same housing for direct detection sensors with background masking. Marking of objects outside the detection range is achieved by arranging the angle between the transmitter and receiver (2 receiver elements).

Objects are detected independently of the structure and colour of the surface.

The special design of the sensors makes it possible to install them between two rollers in the roller back-up conveyor systems under the material that is being moved. This allows for installation that saves space and prevents mechanical damage of the sensor caused by material being conveyed.

### Mounting instructions:

The sensors can be directly fastened in place with the pass-through bore holes or can be attached with a support bracket or a clamp (the last two are not included in delivery).

The surface underneath must be flat to prevent the housing from moving when it is tightened into position. We recommend securing the nut and screw in place with spring washers to prevent the sensor from going out of adjustment.

# For versions SBL-8-H-SL, -V, -Z

As many as 25 sensors can be cascaded with the aid of just one power supply. A solenoid valve is energised if the corresponding sensor itself or its predecessor in the cascade does not see any object.

It is also possible to energise the values of all sensors included in the cascade with block movement ( $V_T$ ). To do this, apply the positive supply voltage (+UB) on the input  $V_T$  of the first sensor.

### Adjustment:

Align the sensor to the background. If the yellow LED is lit, the detection range should be reduced with the detection range adjuster until the yellow LED goes out.

### **Object detection:**



Position the object to be detected in the path of the beam. If the object is detected, the yellow LED lights up. If it does not light up, the detection range must be further adjusted on the potentiometer until it lights up when an object is detected.

### Version SBL-8-H-SL-V-Z only:

The two adjusting mechanisms on the front side of the sensor can be used separately for timer functions for the switching on or switching off process.

This results in a delay defined by the adjuster between the change of state (object detected -> object not detected or vice-versa) and the switching process. The duration of the delay can be set for up to 2 seconds.

#### **Cleaning:**

We recommend cleaning the optical surface and checking all connections at regular intervals.

### Note:

Use a screwdriver to adjust the sensing range. We strongly recommend to use the screwdriver given in the accessories section.

